

# Operator Manual

## Transfer Switch

**150-4000 Amps**

BTPCB (Spec A)

BTPCC (Spec A–B)

BTPCD (Spec A)

BTPCE (Spec A–B)

BTPCF (Spec A–B)

BTPCG (Spec A–B)

BTPCH (Spec A–B)

BTPCJ (Spec A)



# Table of Contents

---

<b>SAFETY PRECAUTIONS</b> .....	<b>VII</b>
<b>1. INTRODUCTION</b> .....	<b>1-1</b>
Operator's Manual .....	1-1
BTPC Bypass-Isolation Transfer Switch .....	1-1
Bypass Switch Function .....	1-1
Drawout Isolation Mechanism .....	1-1
Transfer Switch Function .....	1-1
Utility-to-Genset Operation .....	1-2
Utility-to-Utility Operation .....	1-2
Model Identification .....	1-2
How to Obtain Service .....	1-3
<b>2. DESCRIPTION</b> .....	<b>2-1</b>
Cabinet .....	2-1
Control Panel .....	2-1
Bar Graph Meter Panel .....	2-1
Switch Panel .....	2-1
Indicators .....	2-1
Pushbuttons .....	2-1
Digital Display .....	2-2
Bypass Switch .....	2-3
Contact Assemblies .....	2-3
Auxiliary Contacts .....	2-3
Bypass Switch Controls .....	2-3
Indicators (150–1000 Amp Units) .....	2-3
Bypass Handle and Select Switch .....	2-4
Indicators (1200–4000 Amp Units) .....	2-4
Drawout-Isolation Mechanism .....	2-5
Drawout Cranking Handle .....	2-5
Automatic Transfer Switch .....	2-6
Contact Assemblies .....	2-6
Linear Actuator .....	2-6
Motor Disconnect Switch (150–1000 Amp Switches) .....	2-6
Motor Disconnect Switch (1200–4000 Amp Switches) .....	2-7
Electronic Control System .....	2-7
Before Making Adjustments .....	2-7
Electronic Control Circuit Modules .....	2-7
Time Delays .....	2-10
System Sensors .....	2-11
Two-Wire Starting .....	2-12
Transfer Times .....	2-12
Testing With or Without Load .....	2-13
Generator Exercise Programs .....	2-13
Real-Time Clock .....	2-13
Control Options .....	2-13

	Relay (Signal) Module .....	2-13
	Load Monitoring .....	2-15
	Remote Test Transfer .....	2-15
	Auxiliary Relays .....	2-15
	Battery Charger Options .....	2-15
	Original Float Battery Charger Option .....	2-16
	Current Float Battery Charger Option .....	2-16
	Load Shed .....	2-19
	PowerCommand) Network Interface Module .....	2-20
	Security Key Switch .....	2-20
<b>3.</b>	<b>PROTECTIVE RELAY .....</b>	<b>3-1</b>
<b>4.</b>	<b>OPERATION .....</b>	<b>4-1</b>
	Automatic Operation .....	4-1
	150–1000 Amp Switches .....	4-1
	1200–4000 Amp Switches .....	4-1
	Bypassing the Transfer Switch .....	4-2
	Bypassing Load to Source 1 .....	4-2
	Bypassing Load to Source 2 .....	4-2
	Isolating the Transfer Switch .....	4-3
	150–1000 Amp Switches .....	4-3
	1200–4000 Amp Switches .....	4-4
	Reconnecting the Transfer Switch .....	4-6
	150–1000 Amp Switches .....	4-6
	1200–4000 Amp Switches .....	4-7
	Manual Operation	
	1200–4000 Amp Switches .....	4-8
	Manual Transfer to Source 2 .....	4-8
	Manual Transfer to Source 1 .....	4-9
	System Testing .....	4-10
	Generator Set Start Test .....	4-10
	With Load Standby Test .....	4-10
	Non-Load Break Transfer Switch Test	
	150–1000 Amp Switches .....	4-10
	Non-Load Break Transfer Switch Test	
	1200–4000 Amp Switches .....	4-11
	Generator Set Exercise .....	4-12
	Transfer Switch Maintenance .....	4-13
	Power System Functional Tests .....	4-13
	Weekly Inspection .....	4-13
	Monthly Testing .....	4-13
	Annual Maintenance and Testing .....	4-13
	Planned Maintenance Schedule .....	4-14
<b>5.</b>	<b>DIGITAL DISPLAY MENU SYSTEM .....</b>	<b>5-1</b>
	Digital Display .....	5-1
	Main Menus .....	5-1
	Setup Menus .....	5-1
	Navigation .....	5-1
	Main Menu Navigation .....	5-2
	Main Menu Descriptions .....	5-3

Source 1 and Source 2 Submenus	5-4
Load Submenus	5-5
Statistics Submenus – Prior to Software Version 1.12	5-6
Statistics Submenus – Starting with Software Version 1.12	5-7
Events Submenus	5-8
Setup Submenus	5-9
Setup Menu Navigation and Description	5-10
Saving or Restoring Setup Parameters	5-11
Changing Setup Parameters – Software Versions Prior to Version 1.12	5-11
Changing Setup Parameters – Starting with Software Version 1.12	5-12
Sensor 1 & Sensor 2 Submenus – Software Versions Prior to Version 1.12	5-13
Sensor 1 & Sensor 2 Submenus – Starting with Software Version 1.12	5-15
Sync Check Submenus	5-17
Time Delay Submenus – Software Versions Prior to Version 1.12	5-18
Time Delay Submenus – Starting with Software Version 1.12	5-19
Test Submenus	5-20
Exerciser Submenus – Software Versions Prior to 1.5.190	5-21
Exerciser Submenus – Starting with Software Version 1.5.190	5-23
Exercise Exceptions Submenus – Starting with Software Version 1.5.190	5-25
Exercise Submenus – Starting with Software Version 1.12	5-27
Exercise Exceptions Submenus – Starting with Software Version 1.12	5-29
Exercise Submenus – Starting with Software Version 1.13.244	5-31
Exercise Exceptions Submenus – Starting with Software Version 1.13.244	5-33
Mode Submenu – Prior to Software Version 1.20.250	5-35
Mode Submenu – Starting with Software Version 1.20.250	5-35
Clock Submenus	5-36
Sequencer Submenus	5-37
About Submenus – Prior to Software Version 1.20.250	5-38
About Submenus – Starting with Software Version 1.20.250	5-40
System Submenus	5-42
Active TD Submenus – Prior to Software Version 1.12	5-43
Active TD Submenus – Starting with Software Version 1.12	5-44

## 6. EVENTS

	<b>6-1</b>
Introduction	6-1
Event History	6-1
Events	6-1
ATS Common Alarm	6-1
Battery Charger Fault	6-1
Common Alarm A	6-1
Common Alarm B	6-1
Control Battery Low	6-2
CT Enabled	6-2
Emergency Start A	6-2
Emergency Start B	6-2
Exercise Active	6-2
Fail to Disconnect	6-2
Fail to Sync	6-2
Fail to Retransfer	6-3
Fail to Transfer	6-3
High Neutral Amps	6-3
Load Shed	6-3
Motor Disconnect	6-3

Network Battery Low	6-3
Network Error	6-3
Network Wink	6-3
Not in Auto	6-4
Panel Lock Switch	6-4
Phase Rotation Fail	6-4
Retransfer Inhibit	6-4
S1 Failed to Close	6-4
S1 Failed to Open	6-4
S1 Frequency Fail	6-4
S1 Imbalance Fail	6-4
S1 Loss Phase	6-4
S1 Over Voltage	6-4
S1 Stopped	6-4
S1 Under Voltage	6-4
S2 Failed to Close	6-5
S2 Failed to Open	6-5
S2 Frequency Fail	6-5
S2 Imbalance Fail	6-5
S2 Loss Phase	6-5
S2 Over Voltage	6-5
S2 Stopped	6-5
S2 Under Voltage	6-5
Sequencer Output 1 thru Sequencer Output 8	6-5
Service Tool	6-5
Source-1 Available	6-6
Source-1 Connected	6-6
Source-2 Available	6-6
Source-2 Connected	6-6
Speed Adjust	6-6
Sync Check Active	6-6
Sync Enable	6-6
TDECa (Time Delay Engine Cool-Down (A))	6-6
TDEL (Transfer Pending)	6-6
TDEN (Time Delay Source 2 (E) to Source 1 (N))	6-6
TDESa (Time Delay Engine Start A)	6-7
TDNE (Time Delay Source 1 (N) to Source 2 (E))	6-7
TDPT (Time Delay Programmed Transition)	6-7
Test In Progress	6-7
Test Start A	6-7
Test Start B	6-7
Transfer Inhibit	6-7
<b>8. TIME DELAY GLOSSARY</b>	<b>8-1</b>
<b>9. CLOSED TRANSITION ATS WIRING</b>	<b>9-1</b>

# Safety Precautions

---

This manual includes the following symbols to indicate potentially dangerous conditions. Read the manual carefully and know when these conditions exist. Then take the necessary steps to protect personnel and the equipment.

**⚠ DANGER** *This symbol warns of immediate hazards that will result in severe personal injury or death.*

**⚠ WARNING** *This symbol refers to a hazard or unsafe practice that can result in severe personal injury or death.*

**⚠ CAUTION** *This symbol refers to a hazard or unsafe practice that can result in personal injury or product or property damage.*

## ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

High voltage in transfer switch components presents serious shock hazards that can result in severe personal injury or death. Read and follow these suggestions.

Keep the transfer switch cabinet closed and locked. Make sure only authorized personnel have the cabinet and operational keys.

Due to the serious shock hazard from high voltages within the cabinet, all service and adjustments to the transfer switch must be performed only by an electrician or authorized service representative.

## UTILITY-TO-GENSET OR GENSET-TO-GENSET APPLICATIONS

If the cabinet must be opened for any reason:

1. Move the operation selector switch on the generator set to Stop.
2. Disconnect the battery charger.
3. Disconnect the starting batteries of the generator set or sets (remove the ground [-] lead first).
4. Remove AC power to the automatic transfer switch. If the instructions require otherwise, use extreme caution due to the danger of shock hazard.

## UTILITY-TO-UTILITY APPLICATIONS

If the cabinet must be opened for any reason, remove AC power to the automatic transfer switch. If the instructions require otherwise, use extreme caution due to the danger of shock hazard.

## GENERAL PRECAUTIONS

Place rubber insulative mats on dry wood platforms over metal or concrete floors when working on any electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surfaces to be damp when handling any electrical equipment.

Jewelry is a good conductor of electricity and should be removed when working on the electrical equipment.

Wear safety glasses whenever servicing the transfer switch and do not smoke near the batteries.


Do not work on this equipment when mentally or physically fatigued, or after consuming alcohol or any drug that makes the operation of equipment unsafe.

**⚠ WARNING**

**INCORRECT SERVICE OR REPLACEMENT OF PARTS CAN RESULT IN DEATH, SEVERE PERSONAL INJURY, AND/OR EQUIPMENT DAMAGE. SERVICE PERSONNEL MUST BE QUALIFIED TO PERFORM ELECTRICAL AND/OR MECHANICAL SERVICE.**



**THIS PAGE LEFT INTENTIONALLY BLANK**



# 1. Introduction

## OPERATOR'S MANUAL

This manual covers models produced under the Cummins® and Cummins Power Generation (CPG) brand names.

This operator's manual provides information necessary for operation of an BTPC automatic transfer switch. This is a bypass transfer switch that is equipped with PowerCommand® Control (PC) and it is capable of executing Open Transition with Sync Check, Programmed Transition, and Closed Transition transfer modes.

An **Open Transition with Sync Check** executes an open transition (OT) when both sources of power are within specified tolerances of frequency, voltage, and relative phase difference. If both sources meet the tolerances, a fast transfer occurs.

A **Programmed Transition** executes an OT by disconnecting the load from the source of power, pausing in the neutral position of the transfer switch (between switched positions) to allow transient currents from the load to diminish, and then the load is switched to the other source.

A **Closed Transition** executes a load transfer by momentarily paralleling both sources (a maximum of 100ms) before switching sources.

The BTPC is a bypass isolation transfer switch that can be used in either utility-to-genset or utility-to-utility control applications.

### BTPC BYPASS-ISOLATION TRANSFER SWITCH

The transfer switch combines an automatic transfer switch, a manual bypass switch and a drawout isolation mechanism in one unit.

#### Bypass Switch Function

The bypass switch allows the operator to manually connect the load to the available power source, bypassing the automatic transfer switch (Figure 1-1). When bypassed, the automatic transfer switch can be isolated for testing, maintenance, service or replacement without causing a power interruption.




FIGURE 1-1. BT TRANSFER SWITCH (TYPICAL FUNCTION)

#### Drawout Isolation Mechanism

The drawout isolation mechanism allows the transfer switch to be withdrawn for testing or service. The transfer switch is mounted on rails and is connected to the load, power sources, and controls through isolation contacts. Turning a drawout cranking handle moves the automatic transfer switch either along a rail or on rollers then engages and disengages the isolation contacts without disconnecting power or control cables.

**On 1200–4000 Amp switches, a control cable (P12) must be disconnected before removing the switch.**

#### TRANSFER SWITCH FUNCTION

Transfer switches are an essential part of a building's standby or emergency power system. Power Source 1 (Normal), commonly the utility line, is backed up by Power Source 2 (Emergency), often a generator set. The transfer switch automatically switches the electrical load from one source to the other.



## HOW TO OBTAIN SERVICE

When the transfer switch requires servicing, contact your nearest Cummins Power Generation distributor. Factory-trained Parts and Service representatives are ready to handle all your service needs.

To contact your local CPG distributor in the United States or Canada, call 1-800-888-6626 (this automated service utilizes touch-tone phones only). By selecting Option 1 (press 1), you will be automatically connected to the distributor nearest you.


If you are unable to locate a dealer or distributor,

consult the Yellow Pages. Typically, distributors are listed under:

Generators-Electric,  
Engines-Gasoline or Engines-Diesel, or  
Recreational Vehicles-Equipment,  
Parts and Service.


For outside North America, call Cummins Power Generation, 1-763-574-5000, 7:30 AM to 4:00 PM, Central Standard Time, Monday through Friday. Or, send a fax to Cummins Power Generation using the fax number 1-763-528-7229.

When contacting your distributor, always supply the complete Model Number and Serial Number as shown on the nameplate.





**THIS PAGE LEFT INTENTIONALLY BLANK**



## 2. Description

---

This section describes the standard and optional control features as well as the control cabinet and bypass transfer switch.

### CABINET

The standard cabinet meets the requirements of the National Electrical Manufacturers Association (NEMA) for a UL Type 1 cabinet. Cabinets are available in NEMA types 1, 3R, 4, 4X, and 12. The various types are designated as general-purpose, indoor or outdoor cabinets.

### CONTROL PANEL

The panel features are divided into three groups: Bar Graph Meters, Switch Panel and Digital Display. Bar Graph Meters are optional equipment.

#### Bar Graph Meter Panel

The Bar Graph Meter Panel (optional) includes a three phase AC ammeter, a power meter, a power factor meter, a frequency meter, and a three phase AC voltmeter.

**AC Ammeter (A-):** The ammeter displays the percentage of full load current in amperes (1–125%).

**Power Meter (kW):** The power meter displays the real power in percentage of full load in kilowatts (0–125%).

**Power Factor Meter (PF):** The power factor meter displays real power delivered to the load (1.0 – 0.6 lagging) and (1.0 – 0.9 leading).

**Frequency Meter (Hz):** This meter displays the output frequency (percentage of nominal frequency), of the power source connected to the load (70–110%).

**AC Voltmeter (V-):** The voltmeter displays the percentage of line to neutral voltages of either power source connected to the load (70–110%).

### SWITCH PANEL

The switch panel (Figure 2-1) contains six indicator lamps and three membrane pushbuttons.

#### Indicators

**Source 1 and Source 2 Available:** These indicators are lit when the corresponding sources have acceptable output voltage and/or frequency. These indicators can be lit simultaneously.

**Source 1 Connected:** This indicator is lit when the transfer switch is in the normal position and Source 1 is supplying power to the load.

**Source 2 Connected:** This indicator is lit when the transfer switch is in the emergency position and Source 2 is supplying power to the load.

**Not in Auto:** For all configurations, the Not in Auto indicator lights when the transfer switch is not in Auto.

The transfer switch is not in auto when any of the following signals are active:

- Motor Disconnect Switch is set to Off
- Fail-to-Disconnect event is active
- Control is locked out
- Wiring harness is disconnected from J12 on the Power Module
- Controller is set to Offline
- Bypass switch is connected
- The Operator Release key switch is in the Unlocked (Manual) position – This only applies to models that include the optional external manual operation handle.

**Test/Exercise Active:** The Test/Exercise Active indicator is lit when the transfer switch when a test or exercise routine is active.

#### Pushbuttons

**Test Switch:** For utility-to-genset applications, the Test switch sends a start signal to the generator set designated Source 2 and flashes the Test/Exercise Active indicator. After the start and transfer time delays, Source 2 starts and assumes the load pro-

vided the With Load option is enabled. Press the Test switch again to end the test; the Test/Exercise Active indicator goes out and Source 1 resumes as the source of power.

For utility-to-utility applications, the switch transfers to the non-preferred source after the appropriate time delays, provided that the With Load option is enabled. Press the Test switch again to retransfer and end the test.

**Override Switch:** The Override switch terminates most system time delays. Program Transition, Elevator signal and Engine Cool Down are not affected by this switch. Pressing this switch while the Trans-

fer or Retransfer Inhibit inputs are active, immediately transfers or retransfers the load.

**Reset/Lamp Test Switch:** The Reset/Lamp Test switch turns on all control panel indicators. This switch also acknowledges events (refer to *Section 5: Events*). Pressing this pushbutton will “wake up” the display panel if it is in a sleep mode.

### Digital Display

The Digital Display contains a 2-line by 20-character digital display module and 6 momentary contact membrane buttons. The module displays the menu system. The buttons are used to navigate through the menu system.




FIGURE 2-1. CABINET WITH OPTIONS

Each menu indicates the function of the four buttons at the sides of the display module. Not all buttons are active for each menu. Refer to *Section 4: Digital Display Menu System* for complete digital display menu details.

**Sleep Mode:** After a period of screen inactivity (35 minutes), the digital display goes blank. Screen inactivity is when there is no user interaction with the menu system and when there are no events. The digital display is reactivated when an event occurs or when an operator touches one of the menu buttons.

In order to conserve controller battery power, the loss of utility power also causes the digital display to go blank. The digital display is reactivated when a second power source becomes available.

## BYPASS SWITCH

The bypass switch, located behind (or below) the automatic transfer switch, is used to open and close the contacts connecting the load to the Normal or Emergency power source. The manually operated bypass switch is mechanically interlocked to prevent simultaneous closing to a dead source or to both power sources at the same time. Operation of the bypass switch is accomplished with the Bypass Switch Handle and the Source Select switch.

### Contact Assemblies

Like the automatic transfer switch, the bypass switch has either three or four poles. Three pole transfer switches are provided with a neutral bar. The contact assemblies are manually actuated to connect the load to one of the two power sources, bypassing the automatic transfer switch. When closed to either the Normal or the Emergency power source, the contacts are mechanically held.

### Auxiliary Contacts

Auxiliary contacts are provided on the Normal and Emergency sides of the bypass switch. The Normal side auxiliary contact switch is actuated when the bypass switch is in the Normal position. The Emergency side auxiliary contact switch is actuated when the bypass switch is in the Emergency position. The auxiliary contacts have current rat-

ings of 10 amperes at 250 VAC and are wired to terminal block TB1.

## BYPASS SWITCH CONTROLS

### Indicators (150–1000 Amp Units)

The **Drawout Position indicator** shows which position the automatic transfer switch is in. The drawout mechanism can be latched in one of three positions: Connected, Test, and Isolated (Figure 2-2 and page 2-5).

The **Bypass to Normal and Bypass to Emergency** position indicators show the position of the bypass switch contacts.




FIGURE 2-2. 150–1000 AMP BYPASS PANEL

When the Bypass switch handle is in the Bypass to Normal position, the bypass switch contacts connect the load to the Normal source and the word “Closed” is shown in the Bypass to Normal indicator slot. When the Bypass switch handle is in the Bypass to Emergency position, the bypass switch contacts connect the load to the Emergency source and the word “Closed” is shown in the Bypass to Emergency indicator slot. In both cases, the word “Open” is shown in the opposite indicator slot.

When the Bypass switch handle is in the center position, the bypass switch contacts are disconnected from both sources and the word “Open” is shown in both indicator slots.

### Bypass Handle and Select Switch

The **Source Select Switch** is a spring loaded, three-position switch used to select the source to bypass. Prior to operating the Manual Bypass handle, this switch must be turned to the source the bypass contacts will connect to.

The **Bypass Switch Handle** is used in conjunction with the *Source Select Switch*. The Source Select switch controls an interlock device, which prevents the bypass switch from connecting the load to a dead source or to both sources at the same time. Before operating the Bypass Switch Handle, the Source Select Switch must be turned to the source the load will be connected to. Mechanical and electrical interlocks control the bypass operation.

**Bypassing to the Same Source:** If the automatic transfer switch is already connected to the source to be bypassed, the operator can turn and hold the Source Select switch then move the Bypass Switch Handle, closing the bypass contacts to that same source, without interrupting the load.

**Bypassing to the Opposite Source:** If the automatic transfer switch is NOT already connected to the source to be bypassed, interlocks force the following conditions to be met:

1. The bypass operation is permitted only when the selected source is available. When bypassing to the Emergency source, for exam-

ple, it is necessary to first check that the Source 2 Available lamp is lit. (Refer to *Section 3: Operation*.)

2. As the bypass switch handle is moved to the opposite source, electrical and mechanical interlocks force the automatic transfer switch to the neutral position in a break-before-make action. This operation causes a brief power interruption. (Refer to *Section 3: Operation*.)

### Indicators (1200–4000 Amp Units)

There are five indicator lamps for the bypass switch (see Figure 2-3 for cabinet types 3R, 4, and 12 and Figure 2-4 for cabinet type 1).

**NOTE: Bypass mechanism and indicators on 1600–4000 amp switches in Nema 3, 4, or 12 cabinets are not visible from the outer door.**

- Bypass to Normal (Source 1)
- Bypass to Emergency (Source 2)
- ATS in Test
- ATS Isolated
- ATS Inhibit


The **Bypass Normal** (Source 1) lamp is lit whenever the bypass switch is connecting (bypassing) Source 1 (Normal) to the load.

The **Bypass Emergency** (Source 2) lamp is lit whenever the bypass switch is connecting (bypassing) Source 2 (Emergency) to the load.


The **ATS in Test** lamp is lit whenever the automatic transfer switch is in the Test position.

The **ATS Isolated** lamp is lit whenever the transfer switch is Isolated from either source and the bypass switch is connected.

The **ATS Inhibit** lamp is lit whenever the automatic transfer switch is disabled by the limit switches and interlocks that respond to the operation of the bypass switch and the drawout/isolation mechanism.



**FIGURE 2-3. 1200-4000 AMP INDICATORS FOR CABINET TYPES 3R, 4, AND 12 (LEFT)**



**FIGURE 2-4. 1200-4000 AMP INDICATORS FOR CABINET TYPE 1 (RIGHT)**

## DRAWOUT-ISOLATION MECHANISM

The drawout-isolation mechanism allows the automatic transfer switch to be isolated for testing or service. Three sets of primary isolation contacts (Normal source, Emergency source, and Load) connect the switching contacts to the terminal lugs. A set of secondary isolation contacts connects the automatic transfer switch controls to the available power source.

### Drawout Cranking Handle

The drawout cranking handle is used to isolate and reconnect the automatic transfer switch. The cranking handle turns a gear drive that moves the transfer switch along a mechanically guided path. **The cranking handle will operate only when power is available, and when the bypass switch is connected to one of the sources.** The operator must activate the drawout lever and push in on the crank handle to deactivate the cranking interlocks.

The **Drawout Position Indicator** shows the position the automatic transfer switch is in. The operator can use the drawout crank handle to select one of three positions: Automatic, Test, and Isolate (see Figure 2-2).

In the *Automatic* position, both the primary and the secondary isolation contacts are closed. The automatic transfer switch is in its normal operating position.

In the *Test* position, the primary isolation contacts are open and the secondary isolation contacts are closed. The load-supplying contacts of the automatic transfer switch are out of service, but the controller and linear actuator are powered and fully operational. In this position, the controller, linear actuator, and contact mechanisms can be tested.

In the *Isolate* position, both the primary and the secondary isolation contacts are open. **On 1200-4000 Amp switches, connector J12/P12 must be disconnected (see Figure 2-8).** The transfer switch mechanism is completely isolated from both the power and control circuits and can be removed for service.

**⚠WARNING** *Improper removal of the automatic transfer switch can cause severe personal injury or death. Removal of the automatic transfer switch must only be performed by trained and experienced personnel, following the procedures provided in the service manual.*

## AUTOMATIC TRANSFER SWITCH

The automatic transfer switch (Figure 2-5) opens and closes the contacts that transfer the load between the two power sources (1 and 2). The switch is mechanically interlocked to prevent simultaneous closing to both power sources. The main parts of the transfer switch discussed here are the contact assemblies, linear actuator, the auxiliary contacts, and the Motor Disconnect switch equipped on 1200–4000 Amp switches only.

### Contact Assemblies

The automatic transfer switch has either three or four poles. Three pole transfer switches are provided with a neutral bar. The contact assemblies make and break the current flow. When closed to either the Normal or the Emergency power source (1 or 2), the contacts are mechanically held. Electrical and mechanical interlocks prevent them from

closing the load to a dead source or to both power sources at the same time.

The power contacts are rated at 600 VAC. They are made of a long-life silver alloy which resists burning and pitting, and feature separate arcing surfaces.

### Linear Actuator

The linear actuator is the solenoid that moves the contact assemblies between the Normal (Source 1) power and the Emergency (Source 2) power. Linear actuator operation is initiated automatically with automatic transfer switches.

### Motor Disconnect Switch (150–1000 Amp Switches)

Moving the Drawout Lever to the Release position disables the linear actuator. The Not In Auto indicator on the front panel will light and the display indicates a Motor Disconnect event.




FIGURE 2-5. TRANSFER SWITCHES

## Motor Disconnect Switch (1200–4000 Amp Switches)

The Motor Disconnect toggle switch, on the accessory control plate, enables and disables the linear actuator (Figure 2-6).




FIGURE 2-6. MOTOR DISCONNECT SWITCH

Placing the switch in the Auto position enables the linear actuator. Placing the switch in the Off position disables the linear actuator. When placed in the Off position, the Not In Auto indicator on the front panel will light and the display indicates a Motor Disconnect event.

## ELECTRONIC CONTROL SYSTEM

This section describes the standard and optional components of the electronic control system.

### Before Making Adjustments

**⚠WARNING** *Improper calibration or adjustment of electronic control modules can cause death, severe personal injury, and equipment or property damage. Calibration and adjustment of these components must be performed by technically qualified personnel only.*

**NOTE:** When making adjustments, do not operate the linear motor more than once every two minutes.

All calibration and adjustment procedures are described in the Installation manual (shipped with the transfer switch) and in the Service manual (available through your distributor).

**⚠WARNING** *Accidental actuation of the linear motor could cause severe personal injury. Before making any adjustments, disable the linear actuator.*

**⚠WARNING** *AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform and wear safety glasses.*

## Electronic Control Circuit Modules

The BTPC transfer switch control incorporates a Digital and a Power Module. Power modules are available in four different voltage ranges. The digital module has two 3-volt batteries to power the real-time clock when no source voltage is available. Replace these batteries every two years.

**Digital Module:** The digital module contains the logic and timing circuits that control transfer switch operation. These modules also contain many customer interface circuits (including the genset start signal and network port), the RS-232 communications port for the service tool, and drivers for the control panel indicators, switches, and bar graph meter panel. See Figure 2-7.




FIGURE 2-7. DIGITAL MODULE

**Power Module:**

The power module supplies power to the digital module, and contains voltage sensing transformers, and relays. These modules also hold interface circuits for the transfer switch including position sensing switches and relay drivers. 12 VDC rectification and regulation circuits on this module are powered by both sources through transformers T1 and T2 (see Figure 2-8).


The power module contains eight transformers. Each source (1 and 2) use three transformers. Source 1 and 2 voltages are sensed by transformers T1 and T2. Both sources are connected A:N, B:N and C:N except for 120 volt switches.

Connect 120 volt switches A:N for 2-wire, and AN:CN for 3 wire single phase systems. The other transformers are used to power the 12 VDC supply on the module. One transformer is connected to Source 1 and the other Source 2 (Figure 2-8).

Power modules contain six pilot relays defined as:

- K12 Neutral to Source 1
- K13 Source 2 to Neutral
- K14 Neutral to Source 2


- K15 Source1 to Neutral
- K16 Closed Transition Normal to Emergency
- K17 Closed Transition Emergency to Normal



**FIGURE 2-8. POWER MODULE**

## Control Plate

The Control Plate contains two transformers; one for Emergency supply and one for Normal supply. Figure 2-9 shows the control plate for 150–1000 amp transfer switches. Figure 2-10 shows the control plate for 1200–4000 amp transfer switches.



**FIGURE 2-9. CONTROL PLATE (150–1000 AMP TRANSFER SWITCHES)**

On 150–1000 Amp switches, relays K1 through K7 control the opening and closing of various switches.

## Single Linear Motor (Open Transition):

- K1 Transfer to Normal
- K2 Transfer to Emergency
- K3 Programmed Transition
- K4 Optional Load Shed
- K5 Bypass to Normal
- K6 Bypass to Emergency
- K7 Not Installed

## Dual Linear Motor (Closed Transition):


- K1 Open Emergency
- K2 Open Normal
- K3 Close Emergency
- K4 Close Normal
- K5 Bypass to Normal
- K6 Bypass to Emergency
- K7 Optional Load Shed

## 1200–4000 Switches

Three bridge rectifiers (CR1, CR2, CR3) control voltage to the transfer and bypass switch. The Auto/Test signals are controlled by Relay K5 to the transfer switch. An optional relay, (K6 and CR4) may be added for the Load Shed feature.

The Motor Disconnect switch S1 disables the linear actuator.

Connectors J1, J10, and J3 are the interface and power sources for the cabinet door, the bypass switch and the transfer switch.



**FIGURE 2-10. CONTROL PLATE (1200–4000 AMP TRANSFER SWITCHES)**

## Time Delays

**Start Time Delay (TDES-A):** This brief time delay prevents the generator set from starting during short power interruptions. The delay is adjustable from 0 to 120 seconds in 1 second increments. The default value is 3 seconds. Timing begins at the Source 1 power interruption. If the duration of interruption exceeds the delay time, the control system starts the generator. The value is set with the InPower service tool or the digital display.

**Stop Time Delay (TDEC-A):** This delay is adjustable from 0 to 30 minutes in 1 minute increments. The default value is 10 minutes. It begins timing when the load is retransferred to Source 1. At the end of the delay, the stop signal is sent to the generator set. During this time delay, the generator set cools down without load before stopping. The value is set with the InPower service tool or the digital display.

**Transfer Time Delay (TDNE):** This brief time delay allows the generator set to stabilize before the load is applied. This delay begins when the Source 2 (typically the generator) voltage and frequency reaches the settings of the control. After the delay, the transfer switch transfers the load to Source 2. It has an adjustable range of 0 to 120 seconds in 1 second increments. The default value is 10 seconds. The value is set with the InPower service tool or the digital display.


**Retransfer Time Delay (TDEN):** This delay allows Source 1 to stabilize before retransfer. The delay

begins the moment Source 1 line voltage and frequency return to specified values. After the delay, the transfer switch can retransfer the load to Source 1. It has an adjustable range of 0 to 30 minutes in 1 minute increments. The default value is 10 minutes. The value is set with the InPower service tool or the digital display.

**Programmed Transition (TDPT):** Program Transition introduces a delay during transition of the switch. Programmed transition stops the switch in the neutral position for an adjustable interval of time. In this position, the load is not connected to either Source 1 or 2. This delay allows residual current from inductive loads to decay to an acceptable level before transfer is completed.

Parameters are adjustable. The length of time that the transfer switch is in the neutral position can be adjusted from 0 to 60 seconds in 1 second increments. The default value is 0 seconds. The proper adjustment is a function of the load. The values are set with InPower service tool or the digital display.


**Elevator Transfer Time Delay (TDEL):** Used in elevator applications, this delay sets a time to wait for an elevator pre-transfer signal. This signal allows the elevator to come to a complete stop before the switch transfers. The adjustable range is 0 to 60 seconds. The time delay begins when a transfer or retransfer signal signal has been sent to the relays. The default value is 0. The value can be set using the InPower service tool or the digital display.



## System Sensors

**Under-Voltage Sensing:** All controls include 3-phase under-voltage sensors for Source 1 and Source 2. When a sensor detects a low voltage condition over a specified time period, it initiates a transfer. When the source voltage returns to an acceptable value again, the sensor initiates a retransfer.

These parameters are adjustable. The under-voltage sensing range for a falling voltage (drop-out) is 75 to 98% of the pick-up voltage setting. The default value is 90%. The pick-up range for a rising voltage is 85 to 100% of the nominal voltage setpoint. The default value is 90%. The adjustable range for the time delay period is 0.1 to 1.0 seconds in 0.1 second increments. The default delay time is 0.5 second. These values are set with the InPower service tool or the digital display. See Figure 2-11 for an example using the default values.




**FIGURE 2-11. UNDER-VOLTAGE SENSING**

**Over-Voltage Sensing:** All controls include 3-phase over-voltage sensors for Source 1 and Source 2 that can be disabled and not used. When a sensor detects a high voltage condition over a specified time period (delay), it initiates a transfer. When the source voltage falls to an acceptable value again, the sensor initiates a retransfer.

These parameters are adjustable. The over-voltage sensing range (drop-out) for a rising voltage is 105 to 135% of the nominal voltage setpoint. The


default value is 110%. The pick-up range for a falling voltage is 95 to 100% of the drop-out setting. The default value is 95%. The adjustable range for the delay time period is 0.5 to 120.0 seconds in 1 second intervals. The default delay time is 3.0 seconds. The over-voltage sensing feature is enabled by default. These values are set with the InPower service tool or the digital display. See Figure 2-12 for an example using the default values. This feature can also be disabled.



**FIGURE 2-12. OVER-VOLTAGE SENSING**

**Frequency Sensing:** All controls include frequency sensors for Source 1 and Source 2 that can be disabled and not used. When a sensor detects a high or low frequency condition over a specified delay time period, it initiates a transfer. When the frequency returns to an acceptable value again, the sensor initiates a retransfer.

These parameters are adjustable. The nominal frequency can be set between 45.0 and 60.0 Hz in 0.1 Hz increments. The default frequency is 60 Hz. The acceptable frequency bandwidth (pick-up) is  $\pm 5$  to  $\pm 20\%$  of the nominal frequency setpoint. The default value is 10%. The drop-out frequency is 1 to 5% beyond the pick-up. The default value is 1%. The range for the delay time period is 0.1 to 15 seconds. The default delay time is 1.0 second. The frequency sensing feature is enabled by default. These values are set with the InPower service tool or the digital display. See Figure 2-13 for an example using the default values. This feature can also be disabled.



**FIGURE 2-13. FREQUENCY SETTING**

**Voltage Imbalance Sensor:** Three phase Level 2 controllers include a voltage imbalance sensor for both Source 1 and Source 2. This feature informs the operator when there is significant voltage imbalance between the phases of Source 1 or Source 2. This feature is used for equipment protection.

A voltage imbalance is typically caused by severe single phase loading. The sensor indicates a failure when the maximum deviation from the average voltage is greater than a user-specified value between 2 and 10 % (drop-out) of the average voltage in 1% increments. The pickup value is fixed at 10% of the drop-out. The time delay for the imbalance sensor drop-out is adjustable (2–20 seconds).

This sensor can be enabled using the InPower service tool or the digital display Setup sub-menus. This sensor is inactive for single phase systems and indicates no failures. To prevent nuisance faults, the setting can be increased up to 10 % of the nominal voltage.

**Phase Rotation Sensor:** Three phase Level 2 controllers include a phase rotation sensor. This feature monitors the phase rotation of the source opposite from the connected source. When the alternate source is out of phase rotation with the connected source, transfer is inhibited. This generally occurs on new installations or after storm damage or generator rewiring. This feature protects against equipment damage by preventing transfer to a source that is out of phase. This feature is required in fire pump applications.

**⚠ CAUTION** *Level 1 controls do not support three-phase sensing on Source 2. Do not select the three-phase option for the Source 2 Sensing adjustment with Level 1 controls, even if the system is three phase. This setting will prevent Source 2 from becoming available.*

Both voltage sources have to be applied in order to check phase rotation. Generally, a power source may become out of phase rotation in new installations, after a storm, or when there is generator re-wiring.

This feature is enabled by default. It can be disabled using the InPower service tool or the digital display Setup sub-menus.

**Loss of Single Phase Sensor:** Three phase Level 2 controllers include a loss of single phase sensor. This feature initiates a transfer from a source that has lost a single phase and prevents a transfer to a source that has lost a single phase. This is generally caused by a single phase to line ground or open. The controller indicates a fault when the relative phase angle between any line-to-line phase angle drops to less than 90°. This feature is mainly used to protect three phase devices, such as motors.

This sensor can be enabled using the InPower service tool or the digital display Setup sub-menus. This sensor is inactive for single phase systems and indicates no failures.

## Two-Wire Starting

The starting circuit is a basic supervisory function of the electronic control. Water-cooled generator sets use a two-wire start control.

Although the logic is more involved, the two-wire starting circuit can be thought of as a single pole, single throw switch. A closed switch starts the generator set. An open switch stops the generator.

**Three-wire starting is not available on BTPC transfer switches.**

## Transfer Times

The controller senses and records the time it takes for the transfer switch to break from one source and reconnect to the other source. (Transfer times are not recorded if Programmed Transition delay is in use.)

## Testing With or Without Load

The transfer switch, generator, and power system can be tested automatically. The operator can activate a test by pressing the Test pushbutton, using a remote switch, or via software commands (network input). See “Remote Test Transfer” on page 2-15.

The Test function can be programmed to test only the genset start command or test with a load transfer. By default, the genset will warm-up prior to a transfer. The load transfers to the genset when genset power becomes available (acceptable).

## Generator Exercise Programs

Controllers include eight programmable generator events and eight programmable exceptions. These events are generally programmed to be recurring. They can be programmed from the InPower service tool or the digital display. (Requires the InPower service tool to program exercise programs 3 through 8 and all exceptions.) See Figures 5-18 thru 5-24.

The Real-Time clock must be set before exercise programs are entered. See the Digital Display Menu System section (see page 5-36) for details on setting the clock.

For utility-to-genset configurations, the exercise clock initiates genset start and run cycles at specified intervals for specified durations. This feature is not used in utility-to-utility applications.

**NOTE: Exercise and Test routines are not used in Utility-to-Utility configurations. For Genset-to Genset configurations, Test and Exercise are not available from the ATS. These functions should be initiated by a master ATS or other device in the power system.**

## Real-Time Clock

All controllers have a real-time clock that keeps track of the time and date. The controller uses the real-time clock to time and date stamp all events.

**The clock is not set at the factory. To set the clock, use the digital display or InPower service tool.**

## CONTROL OPTIONS

### Relay (Signal) Module

The Relay Signal Module contains 11 Form-C relay contacts including the Elevator Pre-Transfer Delay. Additional signal relay contacts may be used with other applications. An illustration of all the contacts and functions can be seen in Figure 2-14.

The **Source 1 and Source 2 Connected** relays are energized when their respective power sources are available, ready to produce power, and connected to the load. These relays are latching relays and will retain their last state in case of a complete loss of power.

The **Source 1 and Source 2 Available** relays are energized when their respective power sources are producing power.

The **Test or Exercise Active** relay is energized when the system is in test or exercise mode.

The **Load Shed** relay is active when the transfer switch has been commanded to disconnect the load from power Source 2. The Fail to Disconnect relay is active when the transfer switch remains connected to both sources for more than 100 msec during a closed transition transfer. It should be wired to the shunt trip of the breaker feeding the ATS on either the normal or the emergency side. Refer to the section on closed transition ATS wiring considerations.

The **Fail to Transfer/Retransfer** relay is energized whenever the transfer switch does not *open* or *close* within a set time interval after the command to transfer or retransfer.

The **Fail to Synchronize** relay is energized when the two power sources did not come into synchronicity (frequency, voltage, phase) within a two-minute limit; during a transfer between two live sources.

The **Fail to Disconnect** fault is used only in closed transition modes. The relay is energized whenever the two sources remain parallel longer than a set time limit. It should be wired to the shunt trip of the breaker feeding the ATS on either the normal or the emergency side. Refer to the section on closed transition ATS wiring considerations.

The **Elevator Pre-Transfer Delay** Signal delays transfer (or retransfer) for a specified time to give warning to an elevator control that a transfer (or retransfer) is about to occur.

This time delay (TDEL) is adjustable over a range of 0 to 60 seconds. The default value is 0 seconds. The value is set with the InPower service tool or the digital display. See Figure 5-15 or 5-16 for information on how to adjust the TDEL value using the digital display.

The ATS **Not-In-Auto** relay is energized when any one of the following occurs:

- Motor Disconnect Switch is set to Off
- Fail-to-Disconnect event is active
- Control is locked out
- Wiring harness is disconnected from J12 on the Power Module
- Controller is set to Offline
- The Operator Release key switch is in the Unlocked (Manual) position – This only applies to models that include the optional external manual operation handle.

In 1200–3000 Amp switches, an additional 30 position terminal block is supplied with the module; TB3.

The *Source 1* or *Source 2 Connected* relays are energized when the respective power source is producing power and connected to the load.

The *Source 1* or *Source 2 Available* relays are energized when their respective power sources are available and within the acceptable limits of the voltage sensors.

The *Test/Exercise* relay is energized when the system is in a test or exercise routine.

The *Load Shed* relay (optional) is energized when the transfer switch is signaled to shed load from emergency. Connections at J15-15 and J15-16 are input from load shed to the control. This contact is used by the load shed circuit and is not available for customer use.

The *Elevator Pre-Transfer* signal delays transfer (or retransfer) gives warning to an elevator control that a transfer (or retransfer) is about to occur.




FIGURE 2-14. RELAY MODULE

## Load Monitoring

Controllers can include a load current and power sensor (Current Module) and current transformers installed on the load lines. The control senses the all the load currents (including the neutral current), three load voltages, and three power factor angles. The control calculates the real load power and the apparent load power (see Figure 2-15).

The load current sensing feature is active when the Current Module is installed and connected to the Digital Module.

The control issues a warning when the neutral current exceeds a user specified value between 100 and 150% of the rated current during a specified time period between 10 and 60 seconds.

The warning threshold (100 – 150%) and time delay (10 – 60 sec) are set only with the InPower service tool.




FIGURE 2-15. CURRENT MODULE

**CAUTION** To avoid system faults, false alarms and fault messages, do not remove P40 from the Current Module while the CTs are energized unless the secondaries are shorted. Refer to the Service Manual.

## Remote Test Transfer

The transfer switch may be wired with a remote test switch. Closure of a set of contacts across the remote test inputs causes the transfer switch to sense a (simulated) utility power failure and send a start/run signal to the generator set. The load is transferred to Source 2 when Source 2 becomes

available. (See Testing With or Without Load on page 2-13.)

## Auxiliary Relays

DC auxiliary relays provide contacts for energizing external alarms, remote indicators, and control equipment such as louver motors and water pumps. (Figure 2-16.) Relays are 4-pole, 12 or 24 VAC.




FIGURE 2-16. AUXILIARY RELAYS

## Battery Charger Options

Originally, either a 2-amp or a 10-amp battery charger was available for use with an BTPC transfer switch. Those battery chargers have now been replaced with new 2-amp and 15/12-amp battery chargers.

When present, the status of the battery charger can be viewed using the digital display (see Figure 2-17). The battery charger status submenu is included in the Statistics submenus (see Figure 5-5 or 5-6).





FIGURE 2-17. BATTERY CHARGER STATUS SUBMENU

## Original Float Battery Charger Option

A float-charge battery charger regulates its charge voltage to continuously charge without damage to the battery. As the battery approaches full charge, the charging current automatically tapers to zero amperes or to steady-state load on the battery.

Two chargers were available (Figure 2-18). One battery charger is rated for 10 amperes at 12 or 24 VDC. The other battery charger is rated for 2 amperes at 12 or 24 VDC.



**FIGURE 2-18. ORIGINAL FLOAT BATTERY CHARGERS**

The 2-ampere battery charger has an ammeter to indicate charging current and a fuse to protect the battery charger circuit.

The 10-ampere battery charger has three fuses (two on the AC input and one on the DC output), three fault display LEDs, and an ammeter for indication of charging current.


On the 10-ampere charger, three sets of (Form-C) alarm contacts (corresponding to the three fault LEDs) are also available. Using an optional alarm contact harness, these contacts can be wired by the installer to activate other audible or visual alarms.

Under normal operating conditions, the Low Bat and AC Fail relays are energized and the High Bat relay is de-energized. In response to a Low Bat or AC Fail condition, the appropriate normally ener-

gized relay (Low Bat or AC Fail) drops out. In response to a High Bat condition, the normally de-energized High Bat relay is energized.

## Current Float Battery Charger Option

A float-charge battery charger regulates its charge voltage to continuously charge without damage to the battery. As the battery approaches full charge, the charging current automatically tapers to zero amperes or to steady-state load on the battery.




**FIGURE 2-19. CURRENT BATTERY CHARGERS**

Two battery chargers are available (Figure 2-20). One battery charger is rated for 2 amperes at 12 or 24 VDC. The other battery charger is rated for 15 amperes at 12 VDC or 12 amperes at 24 VDC.

### 2-Amp Battery Charger

The 2-ampere battery charger (see Figure 2-20) has a 5 amp DC output circuit breaker switch on the front of the battery charger. The charger also includes a 5 amp AC fuse to protect the battery charger circuit.

Under normal operating conditions, the Low Bat and AC Fail relays are energized and the High Bat relay is de-energized. In response to a Low Bat or AC Fail condition, the appropriate normally energized relay (Low Bat or AC Fail) drops out. In response to a High Bat condition, the normally de-energized High Bat relay is energized.



**FIGURE 2-20. 2-AMP POWERCOMMAND BATTERY CHARGER**


#### *Control Panel*

The 2-amp charger control panel includes a digital display, a RESET button, and an LED status indicator (see Figure 2-21).

- The 2-line x 16-character digital display displays menus and faults.
- The RESET button is used to select menu options and to clear fault messages.
- The status LED displays the appropriate color for the following conditions.
  - **Green** – On solid indicates unit is charging
  - **Red** – On solid indicates a fault condition. The fault number is shown on the digital display.

#### *Battery Charger Configuration*

The **RESET** button on the control panel (see Figure 2-21) is used to configure the battery charger for the correct battery voltage. (More information on Setup menus is included in the Battery Charger Operator's Manual.)



**FIGURE 2-21. 2-AMP CHARGER CONTROL PANEL**


#### **15/12-Amp Battery Charger**

There are two types of 15/12-amp PowerCommand battery chargers (see Figure 2-22). All 15/12-amp battery chargers have a 20 amp DC circuit breaker switch on the front of the battery charger. The 120, 208, and 240 VAC battery chargers include two 10 amp AC circuit breaker switches and a circuit breaker guard, while the 277, 380, 416, and 600 VAC battery chargers include two AC fuse holders.


#### *Control Panel*

The 15/12-amp charger control panel includes a digital display, a Reset button, and an LED status indicator (see Figure 2-23).

- The 2-line x 16-character digital display displays menus and faults.
- The Reset button is used to select menu options and to clear fault messages.
- The status LED is displays the appropriate color for the following conditions.
  - **Green** – On solid indicates unit is charging
  - **Amber** – On solid indicates Equalizing
  - **Red** – On solid indicates a fault condition. The fault number is shown on the digital display.



**FIGURE 2-22. 15/12-AMP POWERCOMMAND BATTERY CHARGERS**



**FIGURE 2-23. 15/12-AMP CHARGER CONTROL PANEL**

#### *Optional Battery Temperature Sensor*

A connector for an optional battery temperature sensor is located on the front of the battery charger. When used to monitor battery temperature, the optional battery temperature sensor is connected from the battery charger to the positive terminal of the battery. A fault message (fault code 2263) is displayed if the battery temperature is too high (reaches 131 degrees F (55 degrees C)).

#### *Battery Charger Configuration*

The **RESET** button on the control panel (see Figure 2-23) is used to configure the battery charger. (More information on Setup menus is included in the Battery Charger Operator's Manual.)

- **Battery Voltage and Type** – The battery charger must be correctly configured, using the Setup menus, for the correct battery voltage and type before it is connected to the battery. The battery voltage can be set for 12 or 24 VDC (default = 12 VDC). The battery type can be set for Lead-Acid, Gel, or AGM batteries (default = Lead-Acid).

**NOTE:** A factory installed battery charger is set up for the proper DC battery voltage requested on the production order, with the Lead-Acid battery type selected as the default.

- **Battery Equalization** – Battery equalization is available for lead-acid batteries that are completely charged, using the Equalize Battery screen in the Setup menus. When battery equalization is in process, the LED status indicator turns amber.

#### **Load Shed**

The Load Shed module is used to disconnect the load from an available Power Source 2 in order to reduce the power consumed from that source. The load shed option can only be used with ATSs that have a neutral position. When the load shed function is initiated, the transfer switch is moved to the neutral position.

When the load shed feature is active and power on Source-1 returns, the control immediately retransfers to Source-1.

It should be wired to the shunt trip of the breaker feeding the ATS on either the normal or the emergency side. Refer to the section on closed transition ATS wiring considerations.

If the load shed signal is removed before Source-1 returns, the switch transfers back to Source-2.

Load Shed is enabled or disabled using the InPower service tool or the digital display. The relay module must be installed with a load shed module. Load shed includes power relay K4 on 150–1000 Amp switches and K6 with CR4 on 1200–4000 Amp switches, mounted to the control plate. Figure 2-10 shows the location of these relays.

## PowerCommand® Network Interface Module


This option interfaces the transfer switch to the PowerCommand network. It allows for remote monitoring of the transfer switch. Some commands can be sent from the remote location. Interfacing is accomplished through LONWORKS software. Refer to the *Network Installation and Operator's Manual* (900-0366 for TP-78 networks or 900-0529 for FT-10 networks) for network details.

The Network Interface Module is only enabled with the InPower service tool and is mounted to the digital board.


For installations that include an NCM, stranded twisted pair network cable is connected to the left side of terminals TB3-51 and TB3-52 (see Figure 2-25). The NCM is located on the left side of the digital module.

Early production NCMs included two Lithium batteries and a battery hold-down bracket. Current production NCMs no longer use batteries (see Figure 2-24).

**For information on battery maintenance, see Table 3-1.**




**FIGURE 2-24. NETWORK COMMUNICATIONS MODULE (NCM)**



**FIGURE 2-25. NETWORK COMMUNICATIONS MODULE CONNECTIONS**


The status of the NCM (OK, Not Installed, Not Enabled, or Not Available) can be viewed with the digital display (see Figure 2-26). This menu is included in the About submenus (see Figure 5-29 or 5-30, depending on software version).



**FIGURE 2-26. NETWORK MODULE STATUS SUBMENU**

## Security Key Switch

The optional security key switch is located on the front panel between the handle and the Control Panel (Figure 2-1). When in the Panel Lock position, it disables the front panel input switches, Test and Override. It also prevents changes being made to the setup menus using the Digital Display; however, values can be viewed, but not changed. Modifications can be made when the switch is in the Program position.



**FIGURE 2-27. KEY SWITCH**

# 3. Protective Relay


This section describes the solid state relays designed for use in single- or three-phase systems to protect equipment against overpower and/or underpower conditions. They may also be used in the supervisory control of circuits.

To increase the level of protection in our closed transition switches we have included a lock out relay (86) that trips of K32R directional relay or when it senses reverse power to utility 62PL paral-


lel timer senses that the normal and emergency side of the transfer switchswitch are connected together longer than the 62 PL timer settings.

The 86 lockout relay trips when its 24VDC relay coil is energized and requires a manual reset. NC and NO dry contacts are provided for customer wiring which are rated for 20A 600V.


Factory settings for the 62PL are 1 and 3 closed (ON), 2 and 4-10 open (OFF), for 500mS delay.




**FIGURE 3-1. CONTROLS AND INDICATORS**



**FIGURE 3-2. RELAY INSTALLATION M045**



**FIGURE 3-3. RELAY INSTALLATION M046**



**FIGURE 3-4. RELAY INSTALLATION M047**

# 4. Operation

## AUTOMATIC OPERATION

During normal automatic operation the transfer switch indicators and components will be in the following positions.

### 150–1000 Amp Switches

- **Drawout Position Indicator:** On Bypass switch panel in AUTOMATIC position (Figure 4-2).
- **Bypass Switch Handle:** Center position. Both bypass switch position indicators should read OPEN (Figure 4-2).
- **Source Selector Switch:** NORMAL for Source 1 power, EMERGENCY for Source 2 power (Figure 4-2).
- **Front Panel Indicator:** The Source 1 or Source 2 Connected indicator is lit (Figure 4-1).
- **Operation selector switch (engine control):** Remote position.

### 1200–4000 Amp Switches

- **Drawout Position Indicator:** On transfer switch – AUTO position.
- **Manual Bypass mechanism:** Lower position (OPEN). Neither the Bypass Normal nor the Bypass Emergency indicator lamps are illuminated.
- **Motor Disconnect toggle switch:** Place in AUTO position.
- **Bypass Selector Switch:** Place in OFF position.
- **Front Panel Indicator:** The Source 1 or Source 2 Connected indicator is lit.
- **Operation selector switch (engine control):** Remote position.




FIGURE 4-1. SWITCH PANEL




FIGURE 4-2. 150–1000 AMP BYPASS PANEL

## BYPASSING THE TRANSFER SWITCH

### Bypassing Load to Source 1

#### 150–1000 Amp Switches

The transfer switch should be in the Normal position and Source 1 power must be available.

1. Turn and hold the Bypass Source Select switch in the Normal position (Figure 4-2).
2. Move the bypass switch handle up to the Bypass to Normal position
3. Make sure the bypass switch position indicator reads CLOSED at the upper indicator.
4. Release the Bypass Source Select switch.

The transfer switch is bypassed. The digital display reads “Bypassed to S1”, and the Not In Auto LED is on.

#### 1200–4000 Amp Switches

**NOTE:** The load can only be bypassed to the same source that the automatic transfer switch is connected to. Interlocks prevent the operator from bypassing the load to the opposite source or to a dead source.

The transfer switch door must be opened if the cabinet is a NEMA 3, 4, or 12.

**⚠WARNING** Use extreme caution to avoid touching electrical contacts when the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.


Whenever bypassing the transfer switch, always make sure that both the transfer switch and the Bypass Source Select switch are in the same position.

The transfer switch should be in the Normal position and Source 1 power must be available.

1. Turn the Source Selector Switch to the Normal position (Figure 4-3).
2. Insert the manual Bypass Handle and move the mechanism up to the Bypass position.

The transfer switch is bypassed and the digital display reads “Bypassed to S1”. The Bypass/

Normal indicator and the ATS Inhibit indicator are lit.



**FIGURE 4-3. MANUAL BYPASS OPERATION  
1200–4000 AMP SWITCHES**

### Bypassing Load to Source 2

#### Transfer Load to Source 2

The software variable **Test-With/Test Without Load** must be set to the With Load value.

1. To activate the switch panel, turn the key switch on the front panel to PROGRAM.
2. To transfer to Source 2, first, start the genset by pressing and holding the *Test* button on the front switch panel for 2 seconds (Figure 4-1). The Test/Exercise LED is on.

After the Engine Start time delay, and Source 2 output is acceptable, the brief Normal to Emergency time delay begins. The Source 2 Available lamp is lit and the linear motor energizes and drives the transfer switch contact mechanism to Source 2.

The Source 2 Connected indicator on the switch panel will light.

**NOTE:** If the Program Transition feature is active, additional delays and sensor checks must occur before a transfer command is issued.

If the ATS is closed to Source 1, this operation will cause a brief power interruption while switching to Source 2.

### 150–1000 Amp Switches

1. Turn and hold the Bypass Source Select switch in the Emergency position.
2. Move the bypass switch handle down to the Bypass to Emergency indicator.
3. Make sure the bypass switch indicator reads CLOSED at the lower indicator.
4. Release the Bypass Source Select switch.

The transfer switch is bypassed to Source 2. The digital display reads “Bypassed to S2” and the Not In Auto LED is on.

### 1200–4000 Amp Switches

**NOTE:** The load can only be bypassed to the same source that the automatic transfer switch is connected to. Interlocks prevent the operator from bypassing the load to the opposite source or to a dead source.

The transfer switch door must be opened if the cabinet is a NEMA 3, 4, 4X, or 12.

**⚠WARNING** Use extreme caution to avoid touching electrical contacts when the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.

1. Turn the Source Selector Switch to the Emergency position.
2. Insert the Manual Bypass handle and move the mechanism up to the Bypass position.

The transfer switch is bypassed and the digital display reads “Bypassed to S2”. The Bypass/Emergency indicator and the ATS Inhibit indicator are lit.

## ISOLATING THE TRANSFER SWITCH


### 150–1000 Amp Switches

To isolate the automatic transfer switch for servicing, the operator must manually bypass the load to either the Normal source or to the Emergency source, and then crank the transfer switch out to the Isolated position.

1. Bypass the transfer switch to either available Source.
2. Extend the drawout cranking handle from the storage position (Figure 4-2).
3. Lift and hold the Drawout Release Lever up. Turn the cranking handle counterclockwise until the ATS travels past the TEST position, then release the Drawout Release Lever. (Push in on the cranking handle to deactivate the cranking interlocks.)
4. Continue cranking the handle until the Drawout Release drops and the cranking handle locks. The Drawout Position Indicator slot reads ISOLATED.

As the transfer switch is being drawn out, mechanical interlocks force the switch to the neutral position.

5. Return the handle to the stored position.



## 1200–4000 Amp Switches

To isolate the automatic transfer switch for servicing, the operator must manually bypass the load to either the Normal source or to the Emergency source, and then crank the transfer switch out to the Isolated position.

**The load can only be bypassed to the same source that the automatic transfer switch is connected to. Interlocks prevent the operator from bypassing the load to the opposite source or to a dead source.**

1. Bypass the transfer switch to either available Source.
2. To access the transfer switch and handle, open the cabinet door (Nema 3, 4, 4X, and 12 cabinets).

**⚠WARNING** AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.

3. Move the Motor Disconnect toggle switch (Figure 4-4) to the Off position to disable the linear actuator.

**NOTE:** The cranking handle operates only when power is available, and when the bypass switch is connected to one of the sources.

4. Locate the drawout cranking handle and insert it into cranking mechanism. While pressing in on the cranking handle, rotate the drawout handle (Figures 4-5 and 4-6) counterclockwise to move the transfer switch out.

Check that the transfer switch position pointer is aligned with the word ISOLATE (Figures 4-7 and 4-8). Check that the ATS Isolated and ATS Inhibit lamps are on.

5. Return the handle to its storage place.

6. Disconnect connector J12/P12 from the transfer switch before removing the switch from the enclosure.




FIGURE 4-4. MOTOR DISCONNECT SWITCH




FIGURE 4-5. 1200 AMP DRAWOUT MECHANISM






FIGURE 4-6. 1600–4000 DRAWOUT MECHANISM



**FIGURE 4-7. 1200 AMP DRAWOUT POSITION POINTER**



**FIGURE 4-8. 1600-4000 AMP DRAWOUT POSITION POINTER**

**⚠WARNING** *Improper removal of the automatic transfer switch can cause severe personal injury or death. Removal of the automatic transfer switch must only be performed by trained and experienced personnel, following the procedures provided in the Service manual.*

## RECONNECTING THE TRANSFER SWITCH

The manual bypass switch must be in the Normal or Emergency position in order to reconnect the transfer switch. If not done already, connect the bypass switch using one of the procedures described previously. If the bypass switch is connected to Normal there will not be a power interruption when reconnecting the transfer switch. If the bypass switch is connected to Emergency there will be a brief power interruption when reconnecting the transfer switch.

### 150–1000 Amp Switches

#### Load is Bypassed to the Normal Source

1. Make sure the transfer switch is on the rails and pushed all the way into the frame.
2. Lift the rail extensions and close the cabinet door.
3. Extend the drawout cranking handle from the stored position. Lift and hold the Drawout Lever.
4. Rotate the drawout cranking handle clockwise to move the transfer switch to the TEST position. Release the Drawout Lever after the transfer switch travels past the TEST position indicator.

As the transfer switch is being cranked back to the connected position, mechanical interlocks force the switch to the neutral position.

5. Keep turning the cranking handle clockwise until the Drawout Lever drops, locking the cranking handle.

The transfer switch will automatically return to the Normal position, provided the programmed transition time delay (TDPT) has expired, and normal power is available.

6. The Drawout Position Indicator should read CONNECTED.
7. Return the cranking handle to storage.

8. After the transfer switch has returned to the Normal source, move the bypass switch handle to the center position.
9. Check that the word OPEN is shown in both the Bypass to Normal and the Bypass to Emergency indicator slots.
10. Check the “Not in Auto” LED on the front panel is off.

#### Load is Bypassed to the Emergency Source (Source 2)

There will be a brief power interruption when reconnecting the transfer switch when the load is bypassed to Emergency. There are two methods to return the transfer switch to automatic operation depending if the Normal source is available.

##### *Method 1 (Normal Source Is Available)*

1. Make sure the transfer switch is on the rails and pushed all the way into the frame.
2. Lift the rail extensions and close the cabinet door.
3. Extend the drawout cranking handle from the stored position. Lift and hold the Drawout Lever.
4. Rotate the drawout cranking handle clockwise to move the transfer switch to the TEST position. Release the Drawout Lever after the transfer switch travels past the TEST position indicator.

As the transfer switch is being cranked back to the connected position, mechanical interlocks force the switch to the neutral position.

5. Keep turning the cranking handle clockwise until the Drawout Lever drops, locking the cranking handle.

Because normal power is available the control will try to transfer the transfer switch to Normal. Since the bypass switch is connected to Emergency, the automatic transfer switch will not automatically transfer. Relays K1 and K3 on the control plate will energize every 8 seconds. This is normal operation that protects the circuitry.

6. The Drawout Position Indicator should read CONNECTED.

7. Return the cranking handle to storage.

**⚠ CAUTION** *The next operation causes a brief power interruption. Move the bypass switch handle to the center position. After the programmed transition time delay (TDPT) the automatic transfer switch transfers to Normal.*

8. Check that the word OPEN is shown in both the Bypass to Normal and the Bypass to Emergency indicator slots.
9. Check the “Not in Auto” LED on the front panel is off.

### **Method 2 (Normal Source is Not Available)**

1. Make sure the transfer switch is on the rails and pushed all the way into the frame.
2. Lift the rail extensions and close the cabinet door.
3. Extend the drawout cranking handle from the stored position. Lift and hold the Drawout Lever.
4. Rotate the drawout cranking handle clockwise to move the transfer switch to the TEST position. Release the Drawout Lever after the transfer switch travels past the TEST position indicator.

As the transfer switch is being cranked back to the connected position, mechanical interlocks force the switch to the neutral position.

5. Keep turning the cranking handle clockwise until the Drawout Lever drops, locking the cranking handle.

The transfer switch will automatically return to the Emergency position, provided the programmed transition time delay (TDPT) has expired, and Emergency power is available.

6. The Drawout Position Indicator should read CONNECTED.
7. Return the cranking handle to storage.
8. After the transfer switch has returned to the Emergency source, move the bypass switch handle to the center position.

9. Check that the word OPEN is shown in both the Bypass to Normal and the Bypass to Emergency indicator slots.

10. Check the “Not in Auto” LED on the front panel is off.

**⚠ CAUTION** *When Normal power returns, the automatic transfer switch will follow standard operating procedures and transfer back to Normal after all the applicable time delays have expired. This operation will cause a brief power interruption.*

### **1200–4000 Amp Switches**

1. Position the transfer switch to the same power source as the bypass switch is connected to. See Manual Operation on the next page.
2. Reconnect harness P12/J12.
3. Locate the cranking handle and insert it into the cranking mechanism. Rotate the handle clockwise moving the switch to the Test position.
4. Check that the automatic transfer switch position pointer is aligned with the word TEST. Check that the **ATS in Test** lamp is lit and the **ATS Inhibit** lamp is not lit.
5. Keep turning the drawout cranking handle clockwise to move the automatic transfer switch back to the AUTO position.
6. Make sure the automatic transfer switch position pointer is aligned with the word AUTO. Return the drawout cranking handle to its stored position.
7. Move the Motor Disconnect toggle switch (located on the control plate) to the AUTO position to enable the linear actuators.
8. Move the Manual Bypass handle down to the OPEN position.
9. Make sure the **ATS Inhibit**, **Bypass Source 1** and **Bypass Source 2** indicator lamps are **not** lit. Return the manual bypass handle to its stored position.

After the automatic transfer switch is returned to the Auto position, the Motor Disconnect

toggle switch is moved to the Auto position, and the bypass switch is moved to the open (disconnected) position, the automatic transfer switch will respond to transfer/retransfer signals from the controller.

10. Close and lock the cabinet door.

## MANUAL OPERATION 1200–4000 Amp Switches

The transfer switch has operator handles that are intended for maintenance use only. Manual operation must be performed by qualified personnel under **NO-LOAD CONDITIONS ONLY**.

**⚠WARNING** *Manual operation of the transfer switch under load presents a shock hazard that can cause severe personal injury or death. Do not attempt to operate switch manually when it is under load. Follow the “Safety Related Work Practices” listed in NFPA 70E.*

On standard transfer switches, there are two manual operator slots—one for the Normal (Source 1) contacts and one for the Emergency (Source 2) contacts.

A manual operating handle is provided with the transfer switch. The handle is a straight steel rod or tube, with a knob or hand grip on one end.

The transfer switch and the bypass switch must be connected to the same source to isolate and reconnect the transfer switch.

### Manual Transfer to Source 2

Source 2 must be available to perform manual transfer. If you determine that Source 2 is available but the transfer switch does not automatically transfer (refer to the *Troubleshooting* section), perform this procedure to manually transfer to Source 2.

1. Bypass and isolate the automatic transfer switch to the available source as described in this section.

2. Make sure the Motor Disconnect switch is in the OFF position.

**⚠WARNING** *GAC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.*

3. Insert the transfer switch handle in the slot for the Normal contacts and open the Normal contacts by pulling the handle downward.

**⚠WARNING** *Manual operation of the transfer switch under load presents a shock hazard that can cause severe personal injury or death. Do not attempt to operate switch manually when it is under load.*

4. Then, insert the handle in the slot for the Emergency contacts and close the Emergency contacts by pulling the handle downward (Figure 4-9).

Be certain to push the handle all the way to the LOCK position. A distinct over-center locking action can be felt.


5. Return handle to the storage position.

**⚠WARNING** *Automatic transfer switch operation results in rapid movement of the manual operator mechanism and presents a hazard of severe personal injury if the operator handle is engaged in the mechanism. Remove the handle and place it in its storage position.*

6. Reconnect the transfer switch to the AUTO position.

7. Move the Motor Disconnect switch to the AUTO position, and close the cabinet door.

8. If the transfer switch is not functioning correctly, call your dealer or distributor immediately.



**FIGURE 4-9. MANUAL TRANSFER SWITCH SLOTS (1200–4000 AMPS)**

### Manual Transfer to Source 1

1. Bypass and isolate the automatic transfer switch as described in this section.
2. Make sure the Motor Disconnect switch is in the OFF position.

**⚠WARNING** AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.

3. Insert the handle in the slot for the Emergency contacts and open the Emergency contacts by pulling the handle upward.

4. Insert the handle in the slot for the Normal contacts and close the Normal contacts by pulling the handle upward.

Be certain to push the handle all the way to the LOCK position. A distinct over-center locking action can be felt. Return the handle to its storage position.

5. Return handle to the storage position.

**⚠WARNING** Automatic transfer switch operation results in rapid movement of the manual operator mechanism and presents a hazard of severe personal injury if the operator handle is engaged in the mechanism. Remove the handle and place it in its storage position.

6. Reconnect the transfer switch to the AUTO position.

7. Move the Motor Disconnect switch to the AUTO position, and close the cabinet door.

8. If the transfer switch is not functioning correctly, call your dealer or distributor immediately.

## SYSTEM TESTING

### Generator Set Start Test

This routine tests the start circuits of the Power-Command control and starts the generator set. The linear actuators and contact mechanisms are not tested and there is no transfer of load to the Emergency source (Source 2).

1. Place the key switch in the PROGRAM position.
2. Set the software **Test-With/Test Without Load** variable to the Without Load value.
3. Start the genset by pressing and holding the *Test* button on the front panel for 2 seconds (Figure 4-1).
4. After the Engine Start time delay, the generator starts and the Source 2 Available lamp is lit.
5. To end the test routine, press the Test button again to stop the generator.
6. Reset the **Test-With/Without Load** variable to the desired value for regularly scheduled exercise routines. Refer to *Generator Set Exercise* below.

### With Load Standby Test

The software variable **Test-With/Test Without Load** must be set to the With Load value. This operation may cause a brief power interruption while switching to Source 2, depending upon the transition type chosen.

1. Activate the switch panel by turning the key switch on the front panel to PROGRAM.
2. Start the genset by pressing and holding the *Test* button on the front panel for 2 seconds (Figure 4-1).
3. After the Engine Start time delay (TDES-A), and Source 2 output is acceptable, the brief Normal to Emergency time delay (TDNE) begins. The Source 2 Available lamp is lit and the linear actuator energizes and drives the transfer switch contact mechanism to neutral or Source 2.

**NOTE:** If the Programmed Transition feature is active, additional delays and sensor checks must occur before a transfer command is issued.

4. To end the test routine, press the Test button again. The controller issues a retransfer time delay (TDEN).

At the end of the TDEN time delay, the load retransfers from Source 2 to Source 1. The controller issues a engine cool-down time delay and turns off the generator. The Test/Exercise LED is turned off.

5. Reset the **Test-With/Without Load** variable to the desired value for regularly scheduled exercise routines.

**NOTE:** Time delays for Engine Start and Engine Cool-down are not used in Utility-to-Utility configurations.

### Non-Load Break Transfer Switch Test 150–1000 Amp Switches

When the transfer switch is in the Test position, the load-supplying contacts of the automatic transfer switch are out of service, but the PowerCommand control and the linear actuator are powered and fully operational. In this position, the control, the linear actuator, and the contact mechanisms can be tested while the load remains connected to Source 1.

1. Turn and hold the Bypass Source Select switch in the Normal position and move the bypass switch handle to the Normal position. Check that the word CLOSED is shown in the Bypass to Normal Indicator slot and release the Bypass Source Select switch (Figure 4-2).

**⚠WARNING** AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.

2. Lift the Drawout Release lever and turn the drawout cranking handle counterclockwise to

move the automatic transfer switch to the TEST position.

3. After three rotations of the cranking handle, release the Drawout Release lever. When the transfer switch reaches the TEST position, the Drawout Release lever engages, locking the transfer switch in the Test position.
4. As the automatic transfer switch is being drawn out, mechanical interlocks force the switch to the neutral position. Check that the word TEST appears in the Drawout Position Indicator slot. Return the drawout cranking handle to its stored position.
5. Select the software variable **Test-With/Test Without Load** to the With Load value.

**NOTE: With Load variable must be selected in order to test the linear actuator and the contact mechanisms. Because the automatic transfer switch is bypassed and isolated from the load, there will NOT be an actual transfer of load.**

6. Press and hold the TEST pushbutton on the front panel.

The generator set will start and run. After the transfer time delay, the linear actuator will drive the contact mechanism to the Emergency side. Because the automatic transfer switch is bypassed and isolated from the load, there is NO transfer of load to the Emergency source and NO interruption of power to the load.

7. Press the Test pushbutton to end the test routine. After the retransfer time delay, the linear actuator will drive the contact mechanism back to the Normal side.

To avoid the retransfer time delay, press the OVERRIDE pushbutton (the switch returns to Normal). The generator will stop after the cool-down time delay.

8. Lift the Drawout Release lever and turn the drawout cranking handle clockwise to move the automatic transfer switch back to the Automatic position.
9. After three rotations of the cranking handle, release the Drawout Lock. As the automatic transfer switch is being cranked back to the

Automatic position, mechanical interlocks force the switch to the neutral position.

10. Check that the word CONNECTED appears in the Drawout Position indicator slot and return the drawout cranking handle to its stored position.
11. After the automatic transfer switch has returned to the Normal position, move the bypass switch handle to the center position. Check that the word OPEN is shown in both the Bypass to Normal and the Bypass to Emergency indicator slots.
12. Reset the **Test-With/Without Load** variable to the desired value for regularly scheduled exercise routines. Refer to *Generator Set Exercise* below.

After the automatic transfer switch is returned to the Automatic position and the Drawout Release lever is released, the switch will respond to transfer/retransfer signals from the PowerCommand control. In this procedure, the switch returns to the Normal position, provided the retransfer time delay has expired.

Had the bypass switch been placed in the Emergency position, electrical and mechanical interlocks would prevent the automatic transfer switch from retransferring to the Normal source.

### **Non-Load Break Transfer Switch Test 1200–4000 Amp Switches**

**⚠WARNING** *GAC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open. Do not wear long hair, damp clothing, or jewelry. Use insulated tools, stand on a dry rubber mat or wood platform.*

The software variable **Test-With/Test Without Load** must be set to the With Load value in order to test the linear actuators and the contact mechanisms. Because the automatic transfer switch is bypassed and isolated from the load, there will NOT be an actual With Load test.

1. Insert the Manual Bypass handle into the bypass drive mechanism.

2. Turn the Bypass Selector switch to the Normal position and move the Manual Bypass handle up (Figure 4-3).

Check that the **Bypass Normal** and **ATS Inhibit** lamps are lit.

3. Push in and rotate the drawout cranking handle (Figures 4-5 and 4-6) counterclockwise to move the automatic transfer switch to the TEST position.

Check that the automatic transfer switch position pointer is aligned with the word Test (Figures 4-7 and 4-8).

Check that the **ATS in Test** lamp is lit, and that the **ATS Inhibit** lamp is not lit.

4. Return the drawout cranking handle to its stored position.

In the Test position, the load-supplying contacts of the automatic transfer switch are out of service, but the PowerCommand control and the linear actuators are powered and fully operational. In this position, the control, the linear actuators, and the contact mechanisms can be tested.

**NOTE:** The cranking handle operates only when power is available. The bypass switch must be connected to one of the sources.

5. Make sure the **Test-With/Without Load** variable is set to With Load.
6. Move the Motor Disconnect toggle switch (located on the control plate) to the AUTO position to enable the automatic transfer switch linear actuators. Close the cabinet door.
7. Press and hold the TEST button on the front panel.

The generator set will start and run. After the transfer time delay, the linear actuators will drive the contact mechanism to the Emergency side. Because the automatic transfer switch is bypassed and isolated from the load, there is NO transfer of load to the Emergency source and NO interruption of power to the load.

8. At the end of the test routine and time delays, the linear actuators will drive the contact mechanism back to the Normal side.

To avoid any retransfer time delays, press the Override button. The generator will stop after the stop time delay.

9. Move the Motor Disconnect toggle switch (located on the control plate) to the OFF position to disable the automatic transfer switch linear actuators.
10. Move the automatic transfer switch back to the Auto position by rotating the drawout cranking handle clockwise. The **ATS Inhibit** lamp will light.
11. Make sure the position pointer is aligned with the word AUTO. Return the drawout cranking handle to its stored position.
12. Move the Motor Disconnect toggle switch to the AUTO position. Close the cabinet door.
13. Move the Manual Bypass handle down. Check that the **ATS Inhibit**, **Bypass Normal** and the **Bypass Emergency** indicator lamps are **not** lit.
14. Return the Manual Bypass handle to its stored position.  
  
After the automatic transfer switch is returned to the Auto position, the Motor Disconnect toggle switch is moved to the Auto position, and the bypass switch is moved to the open (disconnected) position, the automatic transfer switch will respond to transfer/retransfer signals from the PowerCommand control.
15. Reset the **Test-With/Without Load** variable to the desired value for regularly scheduled exercise routines. Refer to *Generator Set Exercise* below.

## GENERATOR SET EXERCISE

Run the generator for at least 30 minutes once each week with at least 50 percent load (if possible). If exercise routines are not desired, use the switch, as described below, to test the generator set each week.

Exercise routines can be programmed for specified exercise periods and are used to exercise the generator set automatically with or without load. If Source 1 has an interruption while the generator set is exercising without load, the automatic trans-

fer switch transfers the load to the generator set. The Digital Display and the PC Service Tool can set parameters for up to eight exercise periods and eight exceptions.

All controllers have a switch to enable or disable pre-set exercise routines. The pushbutton is located on the Digital Module above the batteries next to the LED light bar display (see Figure NO TAG). This button is used by service personnel to disable unexpected transfers while servicing the switch.

If a power failure occurs during the exercise routine, the controller overrides the routine and transfers the load.

## **TRANSFER SWITCH MAINTENANCE**

Performing the annual planned maintenance procedures increases reliability of the transfer switch.

The following procedures must be performed only by trained and experienced personnel, according to procedures in the Service manual (150-1000 Amp Switches: 962-0518 and 1200-4000 Amp Switches: 962-0519). If repair or component replacement is necessary, call your dealer or distributor.

Transfer switches generally do not require maintenance, but they do require regular care and testing to make sure they operate properly upon a power failure; such as starting the generator set and reliably transferring power to the alternate power source.

### **Power System Functional Tests**

Emergency power systems are required to be tested on a regular basis, and the transfer switch is required to be tested at least once per month per NFPA 110: 6-4.5.

### **Weekly Inspection**

Inspect the entire emergency power system, including the transfer switch, to verify all indicating lamps are functional, the control switches are in the proper (automatic operation) position, and there are no obvious indications of overheating or faulty operation.

## **Monthly Testing**

In order to meet certain codes and standards, generator sets are required to be operated at 30% or more of rated load on a regular basis. Every month test the entire emergency power system using the transfer switch to initiate a exercise sequence.

In a standard exercise routine, the transfer switch should; signal the generator set to start, monitor the genset as it starts, and transfer load to the genset. After the genset test, the transfer switch should transfer the load back to normal service and shut-down the genset after a cool-down period. Methods to test the transfer switch can be: 1) manual operation of the Test switch on the transfer switch cabinet, 2) the automatic programmed Exercise routine, or 3) other building management systems.

The test verifies: 1) the generator set will start and carry the load, 2) the transfer switch is able to detect a power failure, 3) mechanically connect to the alternate power source, and 4) reconnect to the normal power source.

## **Annual Maintenance and Testing**

Because a transfer switch serves critical loads 24 hours a day both NFPA110 and NFPA 70B regulations require annual inspection and maintenance of automatic transfer switches. The inspection is intended to detect overheating contacts or connections that could be from overloads, wear in contact assemblies, or loose cable terminations. If these conditions remain uncorrected, the transfer switch can overheat and completely fail, resulting in total power loss to critical loads in a facility for extended periods of time. Replacement of the transfer switch is difficult when catastrophic failures occur because the transfer switch is always energized in the building's electrical system.

### ***Clean and Inspect the Switch***

Keeping the switch clean helps to prevent dangerous or damaging ground fault conditions. Disconnect power to the transfer switch from both the utility source and the generator source. The sources will be locked out and tagged for safety. Vacuum and clean the switch cabinet to remove all dirt and debris from the enclosure. Exterior surfaces of the switch can be cleaned as long as care is taken to

prevent liquid from entering external switches or the interior of the cabinet.

It is necessary to monitor the transfer switch condition because they are operated under load many more times than other distribution circuit devices. Inspect the transfer switch for carbon tracking, cracks, corrosion, or any other type of deterioration. Remove covers over the contact mechanisms and contacts and inspect for abnormal wear or degradation. Some contact wear is normal. Make corrections and repairs when required.

Most transfer switches require no lubrication, but if required, lubricate according to the Service manual.

After the transfer switch is cleaned and reassembled, check all the power and control connections for deterioration. Re-torque lug connections according to the Torque Table in the *Section 1* of the *Service Manual*. Particularly, check for wear on wires routed across doors, and wiring connected to moving parts.

### **Annual Testing**

After cleaning and inspecting the switch, a full power failure test is recommended. In the monthly test, a power failure is typically simulated by manipulation of the control circuits in the transfer switch or controller. Each year, physically open the normal power supply to the facility. Verify all critical support equipment is connected to generator power, and that the generator starts and runs critical loads. The generator set and power transfer system must function exactly as if an actual power failure has occurred.

### **Thermography**

A thermographic or infrared examination of transfer switches is a valuable resource to monitor transfer switch condition and loading. Thermal evaluations can detect overheating due to not only failure or deterioration of components, but also overloading or the effects of non-linear loads in the distribution system.

In general, thermographic evaluation is most useful when historical data is available for use in comparing current test data to samples of previous performance. Comparison of current performance to oth-

er contacts of identical or similar design, with similar load levels, or between contacts of a single device often identify contacts needing further inspection or repair.

If historical data is not available, then test data can be evaluated based on maximum allowable temperatures allowed by UL standards. On transfer switches rated 400 amps and lower, the contact and lug assembly should not exceed 50°C (122°F) over ambient with full load on the switch. On transfer switches 400 amps and over, the contact and lug assembly should not exceed 60°C (140°F) over ambient. The bus bar and connecting straps may operate at temperatures up to 60°C over ambient at full load.

Thermographic evaluation does not take the place of the required yearly inspection and maintenance, but can highlight problems between service intervals, or indicate the certain need for repairs such as contact replacement which are not commonly required. Advance notice of the need to repair these components can prevent wasted time and unnecessary down time.

### **Planned Maintenance Schedule**


**⚠️WARNING** *AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Incorrect installation, service, or parts replacement can result in severe personal injury, death, and/or equipment damage. All corrective service procedures must be done only by trained and experienced personnel, according to procedures in the Service manual (150-1000 Amp Switches: 962-0524 and 1200-4000 Amp Switches: 962-0525).*

**⚠️WARNING** *The transfer switch presents a shock hazard that can cause severe personal injury or death unless all AC power is removed. Be sure to set the genset operation selector switch to Stop, disconnect AC line power, disconnect the battery charger from its AC power source, and disconnect the starting battery (negative [-] lead first) before servicing.*


**⚠️WARNING** *Ignition of explosive battery gases can cause severe personal injury. Do not smoke or cause any spark, arc, or flame while servicing batteries.*

TABLE 3-1. PLANNED MAINTENANCE

<p><b>1. Disconnect All Sources of AC Power:</b></p> <ul style="list-style-type: none"><li>A. Disconnect both AC power sources from the transfer switch before continuing. Turn the generator set operation selector switch to Stop. (The selector switch is located on the generator set control panel.)</li><li>B. <b><i>If there is an external battery charger, disconnect it from its AC power source.</i></b> Then disconnect the set starting battery (negative [-] lead first).</li></ul>
<p><b>2. Clean</b></p> <ul style="list-style-type: none"><li>A. Thoroughly dust and vacuum all controls, meters, switching mechanism components, interior buswork, and connecting lugs.</li><li>B. Close the cabinet door and wash <b>exterior</b> surfaces with a damp sponge (mild detergent and water). <b><i>Do not allow water to enter the cabinet, especially at meters, lamps, and switches.</i></b></li></ul>
<p><b>3. Inspect</b></p> <ul style="list-style-type: none"><li>A. Check buswork and supporting hardware for carbon tracking, cracks, corrosion, or any other types of deterioration. If replacement is necessary, call your dealer or distributor.</li><li>B. Check stationary and movable contacts. If contact replacement is necessary, the procedures are described in the Service manual (for 150-1000 Amp switches: 962-0524 and for 1200-4000 Amp switches: 962-0525).</li><li>C. Check system hardware for loose connections. Tighten as indicated in step 4.</li><li>D. Check all control wiring and power cables (especially wiring between or near hinged door) for signs of wear or deterioration.</li><li>E. Check all control wiring and power cables for loose connections. Tighten as indicated in step 4.</li><li>F. Check the cabinet interior for loose hardware. Tighten as indicated in step 4.</li></ul>
<p><b>4. Perform Routine Maintenance</b></p> <ul style="list-style-type: none"><li>A. Tighten buswork, control wiring, power cables, and system hardware, as necessary. Hardware torque values are given in Section 4 of the Service manual (for 150-1000 Amp switches: 962-0518 and for 1200-4000 Amp switches: 962-0519). Retorque all cable lug connections. Lug torque requirements are listed in section 1 of the Service manual.</li><li>B. Replace the batteries (3V lithium) in the Digital Module and the Network Module (if applicable) every two years. See Figures 2-7 and 2-24.</li></ul>
<p><b>5. Connect AC Power and Check Operation</b></p> <ul style="list-style-type: none"><li>A. Connect the genset starting battery (negative [-] lead last). Connect the normal AC power source, enable the backup power source. If applicable, connect power to the battery charger.</li><li>B. Verify proper operation of the battery charger.</li><li>C. Test system operation as described in this section. Close and lock the cabinet door.</li></ul>



**THIS PAGE LEFT INTENTIONALLY BLANK**



# 5. Digital Display Menu System

---

This section describes the Digital Display Menu System and illustrates navigation through the menus. The menus display status information, events, and setup menus. Setup menus contain parameters with adjustable values. Descriptions in this section include ranges for the parameters and default values.

The system menus can also be accessed with the InPower Service Tool.

## DIGITAL DISPLAY

The Digital Display Menu System is a 2-line by 20-character graphical display screen and six pushbuttons. The screen or menu displays status information, parameters, events and messages. The buttons change screens and parameters. Two buttons have names: Home and Previous Menu. These buttons are used for navigation. Messages include navigational indicators for the other four buttons.

## MAIN MENUS

The main menu system consists of three top-level menus that list vertical menus (or submenus). The

submenu display status information. This information cannot be changed in the main menus. The main menus contain eight submenus including the Setup Menu.


## SETUP MENUS

Before you can navigate and change setup parameters, you must enter a password and unlock the key switch on the front panel. However, you can bypass the password and examine, but not change, any parameter. After parameters are changed in any setup menu, you are prompted to either save the changes or to restore the old value.

Setting and navigating through the password menu is described in Figures 5-8 and 5-9.


## NAVIGATION

Refer to Figures 5-34 through 5-39 at the end of this section for an overview of menu navigation. These illustrations can be used to locate a submenu and determine how to access it.




## MAIN MENU NAVIGATION

### USING THE MORE BUTTON



### USING THE HOME BUTTON



### USING THE PREVIOUS MENU BUTTON





FIGURE 5-1. NAVIGATION

## MAIN MENU DESCRIPTIONS

### FIRST MAIN MENU

These buttons move between submenus that monitor aspects of both power sources:  
Line-to-Line Voltage  
Source Connected  
Frequency  
Running Time

The HOME key returns to this display within any of the Source 1 or 2 or Load sub-menus



The LOAD key moves through submenus to display information on the Load connected source:

Voltage Output  
Power Factor and Output  
Amps and Frequency

The MORE button advances to the Second Main Menu (below)


The PREVIOUS MENU key is not active at this level

### SECOND MAIN MENU

The STATISTICS button displays information about either source  
Run Time  
Avg. Transfer time  
Total Number of transfers  
Total Number of failures  
Battery & (optional) Charger status  
Current ON time

The EVENTS button displays the last 50 events or fault codes recorded on the controller.

From this display, the HOME button returns to the First Main Menu



The SETUP button enters the Password protected adjustment program:

Adjust Sensors  
Set Time Delays  
Test and Exercise  
Transition Mode Trim  
Load Sequencer Enable

The MORE button advances to the Third Main Menu (below)


From this display, the PREVIOUS MENU button returns to the First Main Menu

### THIRD MAIN MENU

The ABOUT program displays general information about the transfer switch and controller.

The SYSTEM program provides access to data from surrounding devices communicating through a LonWorks network. If the optional network card is not included with the transfer switch, the SYSTEM program is not displayed.

From this display, the HOME button returns to the First Main Menu



The ACTIVE TD button displays all active time delays.


The MORE button returns the display to the First Main Menu

The PREVIOUS MENU button returns to the Second Main Menu (above)


**NOTE:** The Active TD feature was not available in early versions of software.

FIGURE 5-2. MAIN MENUS


## FIRST MAIN MENU – SOURCE 1 AND SOURCE 2 SUBMENUS




Use the ▲▼ buttons on left to navigate through these screens




This screen displays line-to-line voltages for either Source 1 or Source 2 for three phase, two phase or single phase configurations. If the voltage is measured at 10 volts or less, the display reads 0. If the Source is two phase, the display will read voltages at L12 and L31.




This screen displays Line to Neutral voltage measurements for three phase, two phase or single phase configurations. (Numbers do not display if system has no neutral)



This screen displays the sensed line frequency for Source 1 or 2.



This screen displays the position of contactors for either Source 1 or 2.




This screen displays the total time the transfer switch has been connected to either Source 1 or 2.

FIGURE 5-3. SOURCE 1 AND 2 SUBMENUS

# FIRST MAIN MENU – LOAD SUBMENUS

This subset is optional on Level 2 Controls



Use the ▲▼ buttons on left to navigate through these screens





FIGURE 5-4. LOAD SUBMENUS

## SECOND MAIN MENU – STATISTICS SUBMENUS – PRIOR TO SOFTWARE VERSION 1.12


The STATISTICS program displays read-only information about either source:

- Run Time
- Avg. Transfer time
- Total Number of transfers
- Total Number of failures
- Battery & (optional) Charger status
- Current ON time




From this display, the PREVIOUS MENU and HOME buttons return the program to the First Main Menu


Use the ▲▼ buttons on left to navigate through these screens




Total time the transfer switch has been connected to Source 1




Total time the transfer switch has been connected to Source 2




Average. transfer time over the last four transfers. Includes only time that both sources are disconnected. Sensing is disabled when Programmed Transition is active.




Total number of switch transfers in both directions




Total number of Source 1 failures




Total number of Source 2 failures (includes under-voltage, over-voltage, over/under frequency)



Status of lithium batteries on controller board



Status of optional generator battery charger




Displays the amount of time the controller board has been operating since initialization. Value is stored permanently.

FIGURE 5-5. STATISTICS SUBMENUS (PRIOR TO SOFTWARE VERSION 1.12)

## SECOND MAIN MENU – STATISTICS SUBMENUS – STARTING WITH SOFTWARE VERSION 1.12


The STATISTICS program displays read-only information about either source:

- Run Time
- Avg. Transfer time
- Total Number of transfers
- Total Number of failures
- Battery and (optional) Charger status
- Current ON time




From this display, the PREVIOUS MENU and HOME buttons return the program to the First Main Menu.


Use the ▲▼ buttons on left to navigate through these screens.




Total time the transfer switch has been connected to Source 1




Total time the transfer switch has been connected to Source 2




Average time over the last four transfers between the start of the command to move the switch from the old source (OT) and the position sensor sensing that the movement was completed.




Average time over the last four transfers between the start of the command to close the new switch (CT) and the position sensor sensing that the movement was completed.




Total number of switch transfers in both directions




Total number of Source 1 failures




Total number of Source 2 failures (includes under-voltage, over-voltage, over/under frequency)



Status of lithium batteries on controller board



Status of optional generator battery charger




Displays the amount of time the controller board has been operating since initialization. Value is stored permanently.

FIGURE 5-6. STATISTICS SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12)

## SECOND MAIN MENU – EVENTS SUBMENUS

The EVENTS program displays information about either source. The controller stores and records the last fifty "events" in chronological order, beginning with the most recent event. The date and time are listed with each event.

The Events program include Fault codes, active time delays or significant power system changes.



From this display, the PREVIOUS MENU button and HOME button returns program to the First Main Menu.

Within the submenus, press the PREVIOUS MENU button any-time to return to this menu.

Use the ▲▼ buttons on left to navigate through these screens.

### Sample Events

\* Indicates Event is currently active.









FIGURE 5-7. EVENTS SUBMENUS

## SECOND MAIN MENU – SETUP SUBMENUS

### PASSWORD



### Entering the Password Program

Press the Setup button to access the setup password menu.

The password is 574.

Use the + and – buttons to select numbers.

Use the → button to move the cursor to the next field.

**NOTE:** Except for the “View/Edit Exercise” and “View/Edit Exception” submenus available starting with software version 1.13.244, entering the password is required to change setup parameters. The remaining setup menus can be viewed (**read-only**) by pressing the button three times without pressing either the + or – buttons to select numbers.

When the password is set, press the ► button to enter the setup program.

The Setup program is now accessed.  
This is the first Setup Menu screen.





FIGURE 5-8. PASSWORD SUBMENUS

## SETUP MENU NAVIGATION AND DESCRIPTION



This group allows programming the operational parameters of the switch for Source 1 and Source 2.

The *Sensor Submenus* are used for setting the:

- Phase Type
- Nominal Voltage
- Undervoltage Settings
- Overvoltage Settings
- Time Delays
- Frequency Settings
- Imbalance Settings
- Phase Loss
- Phase Rotation

See Figures 5-12 or 5-13 for Sensor Submenus.

The *SynchChck* sensor submenus allow programming synchronous conditions for Source 1 and Source 2 that must be met before transferring from one to the other source. See Figure 5-14 for Sync Check submenus.

The *Time Delay* submenus allow programming time for the:

- Engine Start
- Power Source 1 to Source 2
- Power Source 2 to Source 1
- Engine Cooldown
- Programmed Transition
- Elevator Pre-Transfer
- Genset to Genset Engine Controls

Refer to Figure 5-15 or 5-16 for Time Delay submenus.

*Test* submenus allow programming the front panel test switch to test the source with or without a load. See Figure 5-17.

*Exerciser* submenus allows programming an exercise routine for Power Source 2 and are available only on utility-to-genset controls. The number of exercise programs that can be set is dependent upon the software version installed and the type of control. See Figures 5-18, 5-19, 5-21, or 5-23 for Exercise submenus. *Exercise* submenus also allow for adding and deleting exercise exceptions. See Figure 5-20, 5-22, or 5-24 for Exercise Exceptions submenus. Up to 8 routines and exceptions can be programmed using the PC service tool.

**NOTE:** Exercise Exceptions submenus were not available on early versions of software.


The *Mode* submenu allows programming the type of transition the switch uses. See Figure 5-25 or 5-26.

The *Clock* submenus program the time and date, as well as daylight savings time. See Figure 5-27.


*Load Sequencer* is a software feature, available only with LonWorks NetWork Communication Module. This program allows the user to send a predetermined sequence of event announcements in a timed, sequential order to turn the load off and on. See Figure 5-28.

FIGURE 5-9. SETUP DESCRIPTION

## CHANGING SETUP PARAMETERS – SOFTWARE VERSIONS PRIOR TO VERSION 1.12



When this button is pressed within any submenu, a cursor appears in the location of the editable field. In most cases, there is only one field to edit.



Use the + and – buttons to select numerical values or to toggle through a list of selections.

Default values are shown in parenthesis.

Use the → button to move the cursor to the next field.

When entering numerical values, the – button lowers the value to its lowest range, then begins again at the top end of the range. The + button increases the value to its highest range, then begins again at the low end of the range.

If changes are made, press the → button to enter the new value and return to the previous menu.

Changing any data within the setup submenus will invoke a SAVE/RESTORE screen when exiting the Setup Submenu Groups.

If the PREVIOUS MENU button is pressed during an editing session, the data will not be changed.

If the HOME button is pressed during an editing session, the SAVE/RESTORE screen is invoked.

## SAVING OR RESTORING SETUP PARAMETERS


Changing any parameters within the Setup submenus invokes this screen when exiting the Setup Submenu Groups.

Use the Restore button to delete any setup parameter changes that were made during the current session. The program reverts to data from the previous session and does not save any changes.



FIGURE 5-10. CHANGING SETUP PARAMETERS (SOFTWARE VERSIONS PRIOR TO 1.12)

## CHANGING SETUP PARAMETERS – STARTING WITH SOFTWARE VERSION 1.12



Use the + and – buttons to select numerical values or to toggle through a list of selections.

Default values are shown in parenthesis.

Use the > button to move the cursor to the next field.

When entering numerical values, the – button lowers the value to its lowest range, then begins again at the top end of the range. The + button increases the value to its highest range, then begins again at the low end of the range.

If changes are made, press the > button to enter the new value and return to the previous menu.

Changing any data within the setup submenus will invoke a SAVE CHANGES/CANCEL CHANGES screen when exiting the Setup Submenu Groups.

If the PREVIOUS MENU button is pressed during an editing session, the data will not be changed.

If the HOME button is pressed during an editing session, the SAVE CHANGES/CANCEL CHANGES screen is invoked.

### SAVING OR CANCELING SETUP PARAMETERS

Changing any data within the setup submenus invoke this screen when exiting the Setup Submenu Groups.

Use the “Cancel changes” button to delete any setup parameter changes that were made during the current session. The program will revert to its original data.





FIGURE 5-11. CHANGING SETUP PARAMETERS (STARTING WITH SOFTWARE VERSION 1.12)

## SETUP - GROUP 1

### SENSOR 1 & SENSOR 2 SUBMENUS - SOFTWARE VERSIONS PRIOR TO VERSION 1.12

Sensor 1 and Sensor 2 submenus are identical except:

S1 refers to Source 1  
S2 refers to Source 2




For 2-wire system, select:

1 phase-2 wire

For a single phase - 3 wire system, select: 1 phase-3 wire


For a 3 phase system, select: 3 phase



System Voltage for Source 1 or 2


Enter the system voltage between 110 and 600 VAC

**Note:** Level 1 Controls are Line-to-Line Voltages and Level 2 Controls are Line-to-Neutral Voltages.




Under-Voltage Sensor Pick-Up

Enter a number between 85 and 100% of the nominal voltage (90%)




Under-Voltage Sensor Drop-Out Voltage

Enter a number between 75 and 98% of the under-voltage pick-up percentage (90%)




Under-Voltage Drop-Out Time Delay

Enter a time between 0.0 and 1.0 seconds (0.5)



Over-Voltage Sensing Enable


Choose Enabled or Disabled (Enabled)




Over-Voltage Pick-Up

This adjusts the over-voltage pick-up as a percentage of the over-voltage drop-out

Enter a number between 95 and 99% (95%)



When this button is pressed in any submenu, a cursor appears in the location of the editable field. In most cases, there is only one field to edit.



Use the + and - buttons to select numerical values or to toggle through a list of selections.

Default values are shown in parenthesis)

When entering numerical values, the - button lowers the value to its lowest range, then begins again at the top end of the range. The + button increases the value to its highest range, then begins again at the low end of the range.

Use the → button to move the cursor to the next field.

If changes are made, press the → button to enter the new value and return to the previous menu.

Changing any data within the setup submenu will invoke a SAVE/RESTORE screen when exiting the Setup Submenu Groups.

If the PREVIOUS MENU button is pressed during an editing session, the data will not be changed.

If the HOME button is pressed during an editing session, the SAVE/RESTORE screen is invoked.

**Note:** Default values are in parenthesis.

Continued on next page


FIGURE 5-12. SETUP GROUP 1 - SENSOR SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.12)

## SETUP – GROUP 1


### Sensor 1 & Sensor 2 Submenus – Software Versions Prior to Version 1.12 (Continued)

Sensor 1 and Sensor 2 submenus are the same except:

S1 refers to Source 1  
S2 refers to Source 2




Continued from previous page




Over-Voltage Dropout

Enter a percentage between 105 and 135% of the nominal voltage (110%)




Over-Voltage Time Delay


Enter a range between 0.5 and 120 seconds (3 Seconds)




Monitors line frequency on A-Phases of both sources (Enabled)



Enter a frequency between 45 and 65 Hz (60 Hz)




Enter a percentage between 5 and 20% of the nominal frequency (10%)




Enter a percentage between 1 and 5% of the frequency pickup (1%)

**Note:** Default values are in parenthesis.




Enter a time between 0.1 and 15.0 seconds (5 Seconds)


*Level 2 Controllers Only*




Detects unbalanced voltages on 3-phase sources (Disabled)




Enter a percentage between 2 and 10% (5%)



Enter a time between 2 and 20 seconds (5 Seconds)



The loss of single phase sensing can be enabled or disabled (Disabled)



The phase rotation sensing can be enabled or disabled (Enabled)


**FIGURE 5-12. SETUP GROUP 1 – SENSOR SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.12) (Continued)**

## SETUP - GROUP 1

### SENSOR 1 & SENSOR 2 SUBMENUS - STARTING WITH SOFTWARE VERSION 1.12

Sensor 1 and Sensor 2 submenus are identical except:

S1 refers to Source 1  
S2 refers to Source 2




For 2-wire system, select:  
1 phase 2 wire.

For a single phase - 3 wire system, select: 1 phase 3 wire.


For a 3 phase system, select:  
3 phase.

See Note 2.



Delta or Wye Configuration. This menu is only displayed with Level 2 Controllers.


Chose Delta or Wye (Wye).



System Voltage for Source 1 or 2


Enter the system voltage between 110 and 600 VAC.

**Note:** Level 1 Controllers are Line-to-Line Voltages and Level 2 Controllers are Line-to-Neutral Voltages.




Under-Voltage Sensor Pick-Up

Enter a number between 85 and 100% of the nominal voltage (90%).




Under-Voltage Sensor Drop-Out Voltage

Enter a number between 75 and 98% of the under-voltage pick-up percentage (90%).




Under-Voltage Drop-Out Time Delay

Enter an time between 0.0 and 4.0 seconds (0.5 seconds).




Over-Voltage Sensing Enable  
Choose Enabled or Disabled (Enabled).




Over-Voltage Pick-Up

This adjusts the over-voltage pick-up as a percentage of the over-voltage drop-out.

Enter a number between 95 and 99% (95%).



When this button is pressed in any submenu, a cursor appears in the location of the editable field. In most cases, there is only one field to edit.



Use the + and - buttons to select numerical values or to toggle through a list of selections.

When entering numerical values, the - button lowers the value to its lowest range, then begins again at the top end of the range. The + button increases the value to its highest range, then begins again at the low end of the range.

Use the > button to move the cursor to the next field.

If changes are made, press the > button to enter the new value and return to the previous menu.

Changing any data within the setup submenus will invoke a SAVE CHANGES/CANCEL CHANGES screen when exiting the Setup Submenu Groups.

If the PREVIOUS MENU button is pressed during an editing session, the data will not be changed.

If the HOME button is pressed during an editing session, the SAVE CHANGES/CANCEL CHANGES screen is invoked.

**Note 1:** Default values are in parenthesis.

**Note 2:** Not all sensing choices are valid for all combinations of Level 1/Level 2 and Source 1/Source 2 transfer switches. Only the valid choices are displayed.

Continued on next page


FIGURE 5-13. SETUP GROUP 1 - SENSOR SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12)

## SETUP – GROUP 1


### SENSOR 1 & SENSOR 2 SUBMENUS – STARTING WITH SOFTWARE VERSION 1.12 (CONTINUED)

Sensor 1 and Sensor 2 submenus are the same except:

S1 refers to Source 1  
S2 refers to Source 2




Continued from previous page




Over-Voltage Dropout

Enter a percentage between 105 and 135% of the nominal voltage (110%).




Over-Voltage Time Delay


Enter a range between 0 and 120 seconds (3 seconds).




Monitors line frequency on A-Phases of both sources (Enabled).




Enter a frequency between 45 and 65 Hz (60 Hz).



Enter a percentage between 5 and 20% of the nominal frequency (10%).




Enter a percentage between 1 and 5% of the frequency pickup (1%).




Enter a time between 0.1 and 15.0 seconds (5.0 seconds).


#### Level 2 Controllers Only




Detects unbalanced voltages on 3-phase sources (Disabled).




Enter a percentage between 2 and 10% (4%).



Enter a time between 2 and 20 seconds (5 seconds).



The loss of single phase sensing can be enabled or disabled (Disabled).




The phase rotation sensing can be enabled or disabled (Enabled).

**Note:** Default values are in parenthesis.

**FIGURE 5-13. SETUP GROUP 1 – SENSOR SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12) (Continued)**

## SETUP – GROUP 1

### SYNC CHECK SUBMENUS – STARTING WITH SOFTWARE VERSION 1.20.250



**Note:** Default values are in parenthesis.

**FIGURE 5-14. SYNC CHECK SUBMENUS (STARTING WITH SOFTWARE VERSION 1.20.250)**


## SETUP - GROUP 2

### TIME DELAY SUBMENUS - SOFTWARE VERSIONS PRIOR TO VERSION 1.12



In a Normal to Emergency transfer this function allows Source 2 to stabilize before the load is applied.


Enter a time from 0 to 120 seconds (10 seconds). See Note 2.



When this button is pressed in any submenu, a cursor appears in the location of the editable field. In most cases, there is only one field to edit.


In a Emergency to Normal transfer this allows Source 1 to stabilize before re-transfer.

Enter a time from 0 to 30 minutes (10 minutes). See Note 2.



Sets the time delay for Engine Start on genset (a) used in a utility-generator and generator-generator mode. Prevents nuisance genset starting during brief power interruptions. This menu does not appear in utility-to-utility installations.

Enter a range from 0 to 120 seconds (3.0 seconds). See Note 2.




Use the + and - buttons to select numerical values or to toggle through a list of selections.

Default values are shown in parenthesis.

Use the → button to move the cursor to the next field.

Sets the time delay for Engine Cool-down following a re-transfer. This menu does not appear in utility-to-utility installations.


Enter a time from 0 to 30 minutes (10 minutes).



When entering numerical values, the - button lowers the value to its lowest range, then begins again at the top end of the range. The + button increases the value to its highest range, then begins again at the low end of the range.

Sets the time delay for Programmed Transition setting of 0.0 disables the program.

Enter a time from 0 to 60 seconds (0 seconds).




If changes are made, press the → button to enter the new value and return to the previous menu.

Changing any data within the setup submenus will invoke a SAVE/RESTORE screen when exiting the Setup Submenu Groups.

Sets the time delay to wait for an elevator pre-transfer signal.

Enter a time from 0 to 60 seconds (0 seconds).



If the PREVIOUS MENU button is pressed during an editing session, the data will not be changed.

If the HOME button is pressed during an editing session, the SAVE/RESTORE screen is invoked.

**Note:** Default values are in parenthesis.


*Continued on next page*

**Note 2:** On early versions of software, the sequence of the first three menus were as follows: TDESa, TDNE, and TDEN.

**FIGURE 5-15. SETUP GROUP 2 - TIME DELAY SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.12)**

## SETUP - GROUP 2

### TIME DELAY SUBMENUS - STARTING WITH SOFTWARE VERSION 1.12



In a Normal to Emergency transfer this function allows Source 2 to stabilize before the load is applied.


Enter a time from 0 to 120 seconds (10 seconds). See Note 2.



When this button is pressed in any submenu, a cursor appears in the location of the editable field. In most cases, there is only one field to edit.


In a Emergency to Normal transfer this allows Source 1 to stabilize before re-transfer.

Enter a time from 0 to 30 minutes (10 minutes).



Sets the time delay for Engine Start on genset (a) used in a utility-generator and generator-generator mode. Prevents nuisance genset starting during brief power interruptions. This menu does not appear in utility-to-utility installations.

Enter a range from 0 to 15 (Level 1 controls) or 0 to 120 (Level 2 controls) seconds (3.0 seconds). See Notes 2 and 3.




Use the + and - buttons to select numerical values or to toggle through a list of selections.

Default values are shown in parenthesis.

Use the → button to move the cursor to the next field.

Sets the time delay for Engine Cool-down following a re-transfer. This menu does not appear in utility-to-utility installations.

Enter a time from 0 to 30 minutes (10 minutes).




When entering numerical values, the - button lowers the value to its lowest range, then begins again at the top end of the range. The + button increases the value to its highest range, then begins again at the low end of the range.

If changes are made, press the → button to enter the new value and return to the previous menu.

Sets the time delay for Programmed Transition setting of 0.0 disables the program.


Enter a time from 0 to 60 seconds (0 seconds). See Note 2.



Changing any data within the setup submenus will invoke a SAVE CHANGES/CANCEL CHANGES screen when exiting the Setup Submenu Groups.

Sets the time delay to wait for an elevator pre-transfer signal.

Enter a time from 0 to 60 seconds (0 seconds). See Note 2.



If the PREVIOUS MENU button is pressed during an editing session, the data will not be changed.

If the HOME button is pressed during an editing session, the SAVE CHANGES/CANCEL CHANGES screen is invoked.

**Note 1:** Default values are in parenthesis.

*Continued on next page*

**Note 2:** TDNE, TDESa, TDESa, TDEsb, TDEL, and TDPT values up to 20 seconds are adjustable in 1 second increments. Values over 20 seconds are adjustable in 5 second increments.

**Note 3:** For long engine start time delays (over 15 seconds) a remote battery source should be used.



**FIGURE 5-16. SETUP GROUP 2 - TIME DELAY SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12)**

## SETUP - GROUP 2 TEST SUBMENUS



*This menu is used only in Utility-to-Genset applications*

*This menu is used only in Utility-to-Utility applications*




Allows an operator to automatically test the transfer switch, generator and power system.

Sets the function of the Test Switch on the front panel (Default = Test With Load).


Allows for the selection of the Preferred Source (Default = Source 1)

**Note:** Default values are in parenthesis.


**FIGURE 5-17. SETUP GROUP 2 - TEST SUBMENUS**




**SETUP – GROUP 2**  
**EXERCISER SUBMENUS – SOFTWARE VERSIONS PRIOR TO 1.5.190**  
*These submenus are available only in Utility-to-Genset applications.*




Enables or disables all the functions of exercising the generator(s)




Displays the Time remaining until the next exercise cycle. This display is readable only when the exerciser is Enabled (May not be displayed in Software Version 1.0)




This screen allows disabling Exercise Program 1 only




The first of four programming submenus for the Exerciser cycle. Sets the day an Exercise cycle will occur  
 Select a day between Sunday=0 and Saturday=6




Sets a Time for the exercise cycle to begin  
 Enter a time within a 24 hour period:  
 hh = 0 – 23, mm = 0 – 59.



Sets the length of Time the exercise cycle will run  
 Enter a time within a 24 hour period:  
 hh = 0 – 23, mm = 0 – 59.



Sets an Interval the exercise cycle will repeat  
 Enter a cycle between 0 and 52 weeks  
 Typical values are 1 or 2




*Only one program is available for Level 1 Controllers*

*Continued on next page*


**FIGURE 5-18. SETUP GROUP 2 – EXERCISER SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.5.190)**

**SETUP – GROUP 2**  
**EXERCISER SUBMENUS – SOFTWARE VERSIONS PRIOR TO**  
**1.5.190 (CONTINUED)**




Level 2 Controllers allow for two exercise programs to be setup from the Setup menu screen. Six additional programs and eight exceptions can be setup using the PC service tool.

Enables or disables exercising the generator(s) with or without a load



This screen allows disabling Exercise Program 2 only



Sets the day of the second exercise cycle.  
 Enter a day between Sunday = 0 and Saturday = 6.

Sets the time the second exercise cycle will begin  
 Enter a time within a 24 hour period: hh = 0 – 23, mm = 0 – 59.


Sets a time limit the second exercise cycle will run  
 Enter a time within a 24 hour period: hh = 0 – 23, mm = 0 – 59.

Sets an Interval the second exercise cycle will repeat  
 Enter a range from 0 to 52 weeks. Typical values are 1 or 2.


Enables or disables the second exercise program to run the generator(s) with or without a load

**FIGURE 5-18. SETUP GROUP 2 – EXERCISER SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.5.190) (Continued)**

**SETUP – GROUP 2**  
**EXERCISER SUBMENUS – STARTING WITH SOFTWARE VERSION 1.5.190**  
*These submenus are available only in Utility-to-Genset applications.*




Enables or disables all the functions of exercising the generator(s). (Default = Disabled)




**Note:** Instead of “Exercise Feature,” this menu is titled “Exercise Enable” in some early versions of software. This menu is no longer included with current software.


Displays the Time remaining until the next exercise cycle. If no exercises are enabled, the message “No Next Exercise” is displayed.



This screen allows disabling Exercise 1 only. (Default = Disabled)




The first of four programming submenus for the Exercise cycle. Sets the day an Exercise cycle will occur  
 Select a day between Sunday and Saturday. (Default = Sunday)




Sets a Time for the exercise cycle to begin.

Enter a time within a 24 hour period:  
 hr = 0–23, mn = 0–59. (Default = 00:00)




Sets the length of Time the exercise cycle will run.

Enter a time within a 24 hour period:  
 hr = 0–23, mn = 0–59. (Default = 00:00)



Sets an Interval the exercise cycle will repeat.

Enter a cycle between 0 and 52 weeks.  
 Typical values are 1 or 2. (Default = 0 weeks)




**Note:** Only one exercise is available for Level 1 Controllers

*Continued on next page*

**FIGURE 5-19. SETUP GROUP 2 – EXERCISE SUBMENUS (STARTING WITH SOFTWARE VERSION 1.5.190)**

**SETUP – GROUP 2**

**EXERCISE SUBMENUS – STARTING WITH SOFTWARE VERSION 1.5.190 (CONTINUED)**



Level 2 Controllers allow for two exercise programs to be setup from the Setup menu screen. Six additional programs and eight exceptions can be setup using the PC service tool.

Enables or disables the first exercise program to run the generator(s) with or without a load. (Default = Without Load)

This screen allows disabling Exercise 2 only. (Default = Disabled)

Sets the day of the second exercise cycle.  
Enter a day between Sunday and Saturday.  
(Default = Sunday)



Sets the time the second exercise cycle will begin.  
Enter a time within a 24 hour period: hr = 0–23, mn = 0–59. (Default = 00:00)

Sets a time limit the second exercise cycle will run.  
Enter a time within a 24 hour period: hr = 0–23, mn = 0–59. (Default = 00:00)

Sets an Interval the second exercise cycle will repeat.  
Enter a range from 0 to 52 weeks. Typical values are 1 or 2. (Default = 0 weeks)

Enables or disables the second exercise program to run the generator(s) with or without a load. (Default = Without Load)


*Continued from previous page*



*Add and Delete Exceptions  
(continued on next page)*

**FIGURE 5-19. SETUP GROUP 2 – EXERCISE SUBMENUS  
(STARTING WITH SOFTWARE VERSION 1.5.190) (Continued)**


**SETUP - GROUP 2**  
**EXERCISE EXCEPTIONS SUBMENUS - STARTING WITH SOFTWARE VERSION**  
**1.5.190**




Level 2 Controllers allow for adding and deleting exceptions to the two exercise programs setup from the Setup menu screen.

*Continued from previous page*


Indicates the number of active exercise exceptions. If there are no active exceptions, the message "No Exceptions Active" is displayed.




This screen allows canceling all exceptions. (Default = Normal)




This screen allows enabling/disabling Exception 1 only. (Default = Disabled)




Sets the month and day for Exception 1.  
 Enter a starting date that the exercise will not run: mo = 1-12, dy = 1-31.



Sets a time of day for Exception 1.  
 Enter a starting time of day that the exercise will not run: hr = 0-23, mn = 0-59.




Sets the Time period that Exception 1 will override an Exercise.  
 Enter a time: dy = 1-31, hr = 0-23, mn = 0-59.



*Continued on next page*


**FIGURE 5-20. SETUP GROUP 2 - EXERCISE EXCEPTIONS SUBMENUS**  
**(STARTING WITH SOFTWARE VERSION 1.5.190)**

**SETUP – GROUP 2**  
**EXERCISE EXCEPTIONS SUBMENUS**  
**(CONTINUED)**




*Continued from previous page*


This screen allows enabling/disabling Exception 1 repeating. (Default = Disabled)




This screen allows enabling/disabling Exception 2 only. (Default = Disabled)




Sets the month and day for Exception 2.  
 Enter a starting date that the exercise will not run: mo = 1-12, dy = 1-31.




Sets a time of day for Exception 2.  
 Enter a starting time of day that the exercise will not run: hr = 0-23, mn = 0-59.



Sets the Time period that Exception 2 will override an Exercise.  
 Enter a time: dy = 1-31, hr = 0-23, mn = 0-59.



This screen allows enabling/disabling Exception 2 repeating. (Default = Disabled)




**FIGURE 5-20. SETUP GROUP 2 – EXERCISE EXCEPTIONS SUBMENUS**  
**(STARTING WITH SOFTWARE VERSION 1.5.190) (Continued)**

## SETUP – GROUP 2


### EXERCISE SUBMENUS – STARTING WITH SOFTWARE VERSION 1.12 THESE SUBMENUS ARE ONLY AVAILABLE IN UTILITY-TO-GENSET APPLICATIONS.



Displays the Time remaining until the next exercise cycle. If no exercises are enabled, the message “No Next Exercise” is displayed.




This screen allows disabling Exercise 1 only. (Default = Disabled)




The first of four programming submenus for the Exercise cycle. Sets the day an Exercise cycle will occur

Select a day between Sunday and Saturday. (Default = Sunday)




Sets a Time for the exercise cycle to begin.

Enter a time within a 24 hour period:  
hr = 0–23, mn = 0–59. (Default = 00:00)



Sets the length of Time the exercise cycle will run.


Enter a time within a 24 hour period:  
hr = 0–23, mn = 0–59. (Default = 00:00)



Sets an interval the exercise cycle will repeat.

Enter a cycle between 0 and 52 weeks. (Default = 0 weeks). Typical values are 1 or 2.

Set the value to 0 to exercise one time only.  
Set the value to 1 to exercise once a week.  
Set the value to 2 to exercise every other week.




Continued on next page

**Note:** Only one exercise is available for Level 1 Controllers

FIGURE 5-21. SETUP GROUP 2 – EXERCISE SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12)

**SETUP – GROUP 2**

**EXERCISE SUBMENUS – STARTING WITH SOFTWARE VERSION 1.12 (CONTINUED)**



Level 2 Controllers allow for two exercise programs to be setup from the Setup menu screen. Six additional programs and eight exceptions can be setup using the PC service tool.

Enables or disables the first exercise program to run the generator(s) with or without a load. (Default = Without Load)

This screen allows disabling Exercise 2 only. (Default = Disabled)

Sets the day of the second exercise cycle. Enter a day between Sunday and Saturday. (Default = Sunday)



Sets the time the second exercise cycle will begin. Enter a time within a 24 hour period: hr = 0–23, mn = 0–59. (Default = 00:00)

Sets a time limit the second exercise cycle will run. Enter a time within a 24 hour period: hr = 0–23, mn = 0–59. (Default = 00:00)

Sets an interval the second exercise cycle will repeat. Enter a range from 0 to 52 weeks. (Default = 0 weeks) Typical values are 1 or 2. Set the value to 0 to exercise one time only. Set the value to 1 to exercise once a week. Set the value to 2 to exercise every other week.

Enables or disables the second exercise program to run the generator(s) with or without a load. (Default = Without Load)

*Continued from previous page*




*Add and Delete Exceptions  
(continued on next page)*

**FIGURE 5-21. SETUP GROUP 2 – EXERCISE SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12) (Continued)**

## SETUP – GROUP 2


### EXERCISE EXCEPTIONS SUBMENU – STARTING WITH SOFTWARE VERSION 1.12




Level 1 Controllers allow for setting one exception.  
Level 2 Controllers allow for adding and deleting exceptions to the two exercise programs setup from the Setup menu screen.

Indicates the time remaining for the exception of the longest duration. If there are no active exceptions, the message "No Excepts Active" is displayed on the first line.


*Continued from previous page*




This screen allows canceling all exceptions. (Default = Normal)




This screen allows enabling/disabling Exception 1 only. (Default = Disabled)




Sets the month and day for Exception 1.  
Enter a starting date that the exercise will not run: mo = 1–12, dy = 1–31.



Sets a time of day for Exception 1.  
Enter a starting time of day that the exercise will not run: hr = 0–23, mn = 0–59.




Sets the Time period that Exception 1 will override an Exercise.  
Enter a time: days = 1–31, hr = 0–23, mn = 0–59.



*Continued on next page*


**FIGURE 5-22. SETUP GROUP 2 – EXERCISE EXCEPTIONS SUBMENU (STARTING WITH SOFTWARE VERSION 1.12)**

**SETUP – GROUP 2**  
**EXERCISE EXCEPTIONS SUBMENUS – STARTING WITH SOFTWARE VERSION 1.12**  
**(CONTINUED)**




*Continued from previous page*


This screen allows enabling/disabling Exception 1 repeating. (Default = Disabled)




This screen allows enabling/disabling Exception 2 only. (Default = Disabled)




Sets the month and day for Exception 2.  
 Enter a starting date that the exercise will not run: mo = 1-12, dy = 1-31.





Sets a time of day for Exception 2.  
 Enter a starting time of day that the exercise will not run: hr = 0-23, mn = 0-59.



Sets the Time period that Exception 2 will override an Exercise.  
 Enter a time: days = 1-31, hr = 0-23, mn = 0-59.




This screen allows enabling/disabling Exception 2 repeating. (Default = Disabled)



**FIGURE 5-22. SETUP GROUP 2 – EXERCISE EXCEPTIONS SUBMENUS**  
**(STARTING WITH SOFTWARE VERSION 1.12) (Continued)**


## SETUP – GROUP 2

### EXERCISE SUBMENUS – STARTING WITH SOFTWARE VERSION 1.13.244 THESE SUBMENUS ARE ONLY AVAILABLE IN UTILITY-TO-GENSET APPLICATIONS.



Level 1 Controllers allow for setting two exercise periods and Level 2 Controllers allow for setting eight exercise periods from the digital display screen.


Displays the Time remaining until the next exercise cycle. If no exercises are enabled, the message "No Next Exercise" is displayed.




This screen allows for selecting one of the available exercises and displays its status. \*

Enter a number between 1 and 8 (Default = 1).

**NOTE:** Only Exercises 1 and 2 are available with Level 1 controllers. Exercises 1 through 8 are available with Level 2 controllers.



This menu is used to enable/disable the Exercise selected in the previous menu. (Default = Disabled)




The first of four programming submenus for the Exercise cycle. Sets the day an Exercise cycle will occur

Select a day between Sunday and Saturday. (Default = Sunday)



Sets a Time for the exercise cycle to begin.

Enter a time within a 24 hour period:  
hr = 0–23, mn = 0–59. (Default = 00:00)



Continued on next page


\* If a password (see the Setup Password Submenu in Figure 5-8) is not entered:

- Only the View/Edit Exercise and View/Edit Exception menus can be modified.
- When the View/Edit Exercise or View/Edit Exception menus are modified, the Save Changes/Cancel Changes submenu is displayed upon exiting the Exercise submenus.

**FIGURE 5-23. SETUP GROUP 2 – EXERCISE SUBMENUS  
(STARTING WITH SOFTWARE VERSION 1.13.244)**

## SETUP – GROUP 2


### EXERCISE SUBMENUS – STARTING WITH SOFTWARE VERSION 1.13.244 (CONTINUED)



Continued from previous page

Sets the length of Time the exercise cycle will run.


Enter a time within a 24 hour period:  
hr = 0–23, mn = 0–59. (Default = 00:00)



Sets an interval the exercise cycle will repeat.

Enter a cycle between 0 and 100 weeks. (Default = 0 weeks). Typical values are 1 or 2.

Set the value to 0 to exercise one time only.  
Set the value to 1 to exercise once a week.  
Set the value to 2 to exercise every other week.  
Set the value to 52 to exercise once every 52 weeks.




OR

Enter a cycle for a specific day of the month (1st, 2nd, 3rd, 4th, or 5th \_\_\_ day of the month).


For example, set the value to 1st Monday to exercise only on the first Monday of each month.

**NOTE:** After selecting the ► button, press the down or up button (▼ or ▲) until the desired 1st thru 5th \_\_\_ day value is displayed. The menus required to set a specific day of the month to exercise are displayed when you use the ▼ button to go below “0” or the ▲ button to go above “100.”

**NOTE:** The day of the week displayed in this menu matches the day selected on the first “Exercise # Start” menu.



Enables or disables the first exercise program to run the generator(s) with or without a load. (Default = Without Load)




Continued on next page

FIGURE 5-23. SETUP GROUP 2 – EXERCISE SUBMENUS (STARTING WITH SOFTWARE VERSION 1.13.244) (Continued)

## SETUP - GROUP 2


### EXERCISE EXCEPTIONS SUBMENUS - STARTING WITH SOFTWARE VERSION 1.13.244




Level 1 Controllers allow for setting two exceptions and Level 2 Controllers allow for setting exceptions to the eight exercise programs setup from the digital display screen.

*Continued from previous page*

Indicates the time remaining for the exception of the longest duration. If there are no active exceptions, the message "No Excepts Active" is displayed on the first line.




This screen allows canceling all exceptions. (Default = Normal)




This screen allows for selecting an Exception and displaying its status. \*

Enter a number between 1 and 8 (Default = 1).

**NOTE:** The number selected here must match the Exercise number selected in the "View/Edit Exercise" menu.




This menu is used to enable/disable the Exception selected in the previous menu. (Default = Disabled)



Sets the month and day for Exception 1.

Enter a starting date that the exercise will not run: mo = 1-12, dy = 1-31.




*Continued on next page*

\* If a password (see the Setup Password Submenu in Figure 5-8) is not entered:

- Only the View/Edit Exercise and View/Edit Exception menus can be modified.
- When the View/Edit Exercise or View/Edit Exception menus are modified, the Save Changes/Cancel Changes submenu is displayed upon exiting the Exercise submenus.


**FIGURE 5-24. SETUP GROUP 2 - EXERCISE EXCEPTIONS SUBMENUS (STARTING WITH SOFTWARE VERSION 1.13.244)**

**SETUP - GROUP 2**  
**EXERCISE EXCEPTIONS SUBMENUS - STARTING WITH SOFTWARE VERSION**  
**1.13.244 (CONTINUED)**




*Continued from previous page*


Sets a time of day for Exception 1.  
 Enter a starting time of day that the exercise will not run: hr = 0-23, mn = 0-59.




Sets the Time period that the Exception will override the same numbered Exercise.  
 Enter a time: days = 1-31, hr = 0-23, mn = 0-59.




This menu allows for enabling/disabling repeating the Exception. (Default = Disabled)



**FIGURE 5-24. SETUP GROUP 2 - EXERCISE EXCEPTIONS SUBMENUS**  
**(STARTING WITH SOFTWARE VERSION 1.13.244) (Continued)**




**FIGURE 5-25. SETUP GROUP 3 - MODE SUBMENU (PRIOR TO SOFTWARE VERSION 1.20.250)**



**FIGURE 5-26. SETUP GROUP 3 - MODE SUBMENU (STARTING WITH SOFTWARE VERSION 1.20.250)**


## SETUP – GROUP 3 CLOCK SUBMENUS

The Clock submenus allow the user to set the actual date and time, as well as select the Daylight Saving Time option.




Sets the actual day and date.

Enter a month between Jan = 1 and Dec = 12, date between 1 and 31, and year between 1 and 9999.




Sets the actual time of day.

Enter the actual time within a 24 hour period  
Enter a time within a 24 hour period: hh = 0 – 23, mm = 0 – 59, ss = 0 – 59.




Activates the Daylight Savings time option.  
Selecting Enabled automatically updates the clock +/- one hour on the appropriate days.  
(Default = Disabled)




**Note:** The Daylight Savings Time program is set for North America. If you are anywhere outside of North America, the time should be changed manually.

- The first Sunday in April – moves the time forward one hour.
- The last Sunday in October – moves the time back one hour.

**FIGURE 5-27. SETUP GROUP 3 – CLOCK SUBMENUS**




## SETUP - GROUP 3 SEQUENCER SUBMENUS



The Sequencer submenus are a software only feature allowing the user to send a predetermined sequence of network event announcements. The announcements are sent in a timed, sequential order and are used to turn ATS loads off and on. When used, a few seconds should be allowed between load steps to allow the generator voltage and frequency to stabilize.


Sequencer is available only with the optional Network Communication Module. The module must be installed and enabled with the PC service tool before these screens are displayed.

When Enabled, allows event announcements to be sent to the transfer switch.




Sets activation for certain operational modes.

Choose Transfer, Re-transfer, or All




The control can activate a maximum of 8 relay output signals.

Enter the number of relay output signals desired to activate: 1 thru 8.




When Load Sequencer is triggered, the controller deactivates all remote relay output signals. Starting with Relay 1, the controller counts down the specified time delay, then activates Relay 1.

Enter a time from 0 to 60 seconds.



If the Sequence Length is greater than 1, the control counts down the specified Relay 2 time delay, then activates the Relay 2 signal.

Enter a time from 0 to 60 seconds.




The process repeats until all relay signals have been sequenced. The maximum time delay for all 8 signals is 8 minutes.

*Menus continue through Output 8, depending on the number of Sequence Lengths specified.*


**FIGURE 5-28. SETUP GROUP 3 - SEQUENCER SUBMENUS**

### THIRD MAIN MENU – ABOUT SUBMENUS – PRIOR TO SOFTWARE VERSION 1.20.250

The About submenus contain read-only information about the transfer switch and controller.




Displays the name of the switch as defined in the Event Handling Requirement.




Displays the current firmware version of the controller.



Displays the manufacturing date of the controller.




Displays the configuration of the controller. Changes are made by service personnel using the PC service tool.



Data
Test Mode
Util-Gen
Utility-Utility
Genset-Genset
Unknown


Displays the mode of operation the control is using. Adjustments can be made by service personnel using the PC service tool.



Data
OT = Open Transition
BT = Bypass Transition
Unknown

Displays the ATS board level (1 or 2).


**NOTE:** This menu was not included in early versions of software.



Continued on next page


FIGURE 5-29. THIRD MAIN MENU – ABOUT SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.20.250)

**THIRD MAIN MENU – ABOUT SUBMENUS – PRIOR TO SOFTWARE VERSION 1.20.250 (CONTINUED)**




Continued from previous page

This screen indicates if a Network Communications Module is installed and enabled.




Hardware Detected	Software Enabled	Data
True	True	OK
False	True	Not Installed
True	False	Not Enabled
False	False	Not Available

This screen indicates if the Relay Module hardware is installed.




Data
OK
Not Installed

This screen indicates if the Load Current Module hardware is installed.  
This feature is not available on Level 1 controllers




**FIGURE 5-29. THIRD MAIN MENU – ABOUT SUBMENUS (SOFTWARE VERSIONS PRIOR TO 1.20.250) (Continued)**



### THIRD MAIN MENU – ABOUT SUBMENUS – STARTING WITH SOFTWARE VERSION 1.20.250

The About submenus contain read-only information about the transfer switch and controller.



Displays the name of the switch as defined in the Event Handling Requirement.




Displays the current firmware version of the controller.




Displays the current bootcode version of the controller.



Displays the manufacturing date of the controller.




Displays the switch mechanism of the controller.



Data
OHPC/CHPC
OTPC2
OTPC3
Dual Linear Motor
OTPC/BTPC
PLT

Displays the configuration of the controller. Changes are made by service personnel using the PC service tool.




Data
Offline
Util-Gen
Util-Util
Gen-Gen

Continued on next page


FIGURE 5-30. THIRD MAIN MENU – ABOUT SUBMENUS (STARTING WITH SOFTWARE VERSION 1.20.250)

**THIRD MAIN MENU – ABOUT SUBMENUS– STARTING WITH SOFTWARE VERSION 1.20.250 (CONTINUED)**




Continued from previous page

Displays the mode of operation the control is using. Adjustments can be made by service personnel using the PC service tool.




Data
OT = Open Transition
BT = Bypass Transition
CT = Closed Transition

Displays the ATS board level (1 or 2).




This screen indicates if a Network Communications Module is installed and enabled.




Hardware Detected	Software Enabled	Data
True	True	OK
False	True	Not Installed
True	False	Not Enabled
False	False	Not Available

This screen indicates if the Relay Module hardware is installed.



Data
OK
Not Installed



This screen indicates if the Load Current Module hardware is installed. This feature is not available on Level 1 controllers.




**FIGURE 5-30. THIRD MAIN MENU – ABOUT SUBMENUS (STARTING WITH SOFTWARE VERSION 1.20.250) (Continued)**

## THIRD MAIN MENU – SYSTEM SUBMENUS

These submenus are available only with the optional Network Communication Module.  
The status of up to 32 devices can be viewed at the ATS.



If no Generator Sets are connected to the system, the message "No GenSets Found" is displayed.



The Master Control menu displays information on:

1. Power (kW)
2. Master Control Status (Non Auto, Ready, Norm Fail, Test)
3. Voltage Source Status ([N=Source1, E=Source2], On, OK, or NA).


If a Master Control is not connected to the system, the message "No Master Control" is displayed.

**NOTE:** The Master Control menu is not available in early versions of software.

**FIGURE 5-31. THIRD MAIN MENU – SYSTEM SUBMENUS**




### THIRD MAIN MENU – ACTIVE TD SUBMENUS – STARTING WITH SOFTWARE VERSION 1.12




#### EXAMPLES


Shows name of Time Delay



Shows the remaining time, in seconds




This menu shows a Preferred Source Changeover Timer and remaining time (Utility-to-Utility and Genset-to-Genset applications only)



This message is displayed only if there are no active time delays.

FIGURE 5-33. THIRD MAIN MENU – ACTIVE TD SUBMENUS (STARTING WITH SOFTWARE VERSION 1.12)






FIGURE 5-34. MENU SYSTEM MAP – PRIOR TO SOFTWARE VERSION 1.5.190






FIGURE 5-36. MENU SYSTEM MAP – STARTING WITH SOFTWARE VERSION 1.8.204





FIGURE 5-37. MENU SYSTEM MAP - STARTING WITH SOFTWARE VERSION 1.12

NOTE 1 - THIS MENU IS AVAILABLE WITH UTILITY-TO-UTILITY AND GENSET-TO-GENSET APPLICATIONS ONLY.  
 NOTE 2 - THIS MENU IS AVAILABLE WITH UTILITY-TO-GENSET APPLICATIONS ONLY.



**FIGURE 5-38. MENU SYSTEM MAP – STARTING WITH SOFTWARE VERSION 1.13.244**



# 6. Events

---

This section describes the Events feature and contains a list of all non-fault events. Events can be displayed on the InPower service tool and on transfer switches that are equipped with the digital display.

## INTRODUCTION

The controller displays the last event that occurred on the digital display. Up to 50 events can be viewed in the event history file.

Active events consist of a text message, a date/time stamp, and an asterisk. The asterisk indicator is part of an active event message until the event becomes inactive. Some events require pressing the Reset/Lamp Test button on the control panel to make the event inactive.

## Event History

The controller records up to 50 events in the event history file. When the history file is full and a new event occurs, the control adds it to the history file and deletes the oldest event in the history file. The PC Service tool and the digital display can be used to view the events. See the Digital Display Menu System section for how to view previous events.

**NOTE:** The controller automatically saves a record of events twice a day. If power is lost for more than 20 seconds, the controller attempts to save a record of current events. If the controller batteries and power are removed, data not saved is lost.

## EVENTS

The following is an alphabetical listing of transfer switch events. The code number is listed with each event. Only the codes that include an asterisk (\*) are flashed out with the LED indicators on the Digital Module. All codes can be viewed using the PC Service tool. A numerical listing of these events is included in Table 6-1.

### **ATS Common Alarm** **Code 1125**

This network event is active whenever any of the following events are active.

- Control Battery Low

- Charger Error
- Fail to Transfer
- Fail to Retransfer
- Fail to Disconnect (this event is only available in transfer switches with closed transition)
- Network Battery Low\*
- Network Error\*
- S1 Failed to Open
- S1 Failed to Close
- S2 Failed to Open
- S2 Failed to Close

\* Events “Network Battery Low” and “Network Error” are no longer available, starting with software version 1.13.

For this event to become inactive, all of the above events must become inactive and the Reset button on the front panel must be pressed. This event momentarily becomes inactive when the Rest button is pressed but will again become active if any of the above events persist after the reset.

### **Battery Charger Fault** **Code 597\***

For transfer switches that include a genset battery charger, this event signals the controller that the genset battery charger is malfunctioning and may need to be replaced.

This is not a standard factory connection. For more information, contact your dealer or distributor.

The event remains active until the Reset button on the front panel is pressed.

### **Common Alarm A** **Code 156**

When this event is active, Generator A (Source 1) is not available. This input is usually only used in genset-to-genset applications.

### **Common Alarm B** **Code 157**

When this event is active, Generator B (Source 2) is not available. This input is usually only used in genset-to-genset applications.

**Control Battery Low****Code 441\***

This event is active when the actual voltage of the lithium batteries drops to 5 VDC.

The controller monitors the voltage of the lithium batteries that backup power to the controller. If the battery voltage drops to 5 VDC, the controller sets the fault status to active.

The controller Fault Flash-out subsystem flashes this fault until the Reset button on the front panel is pressed. If the battery voltage is still low, the event stays active.

**Controller Pwr Off****Code 158**

If this event is displayed on the front panel, the controller will shut itself down within 5 seconds of the message being displayed.

If this event is listed in the Event History log, it indicates that the control went to sleep after not receiving AC power from either source for 30 seconds.

The controller signals the Network Communications Module (NCM) and other devices that the ATS controller is going to shutdown due to a lack of power. This signal triggers a time-delay start or other sequences. After the sequences are complete, the controller shuts itself down in order to conserve the back-up batteries. The NCM responds by not communicating to the controller.

**CT Enabled****Code 142**

This event is only available in transfer switches with closed transition. This event is active whenever a closed transition transfer or retransfer is pending.

If the spring is not wound after a fixed period of time, the event "Fail to Charge Sprg" is displayed.

**Emergency Start A****Code 105**

This event is active whenever the controller requires the Source 2 genset to start and reach rated speed — otherwise known as an emergency start. There is also a discrete output called Emergency Start A.

**Emergency Start B****Code 107**

This event is active whenever the controller requires the Source 1 genset to start and reach rated speed. This event is only used in genset-to-genset control modes. There is also a discrete output called Emergency Start B.

**Exercise Active****Code 118**

This event is active whenever an exercise sequence is active. There is an associated LED output on the front panel and a relay output on the Relay Module. When this event is active, the Test/Exercise Active LED on the front panel is lit and the Test/Exercise relay on the relay module is activated.

**Fail to Disconnect****Code 1121\***

This event is only available in transfer switches with closed transition. This event is active when both sources have paralleled, there is a failure to open either power source, and all attempts to automatically separate them within a set period of time have failed. This event applies to only closed transition modes and is needed to trip an external circuit breaker.

The event remains active until the Reset button on the front panel is pressed.

**Fail to Sync****Code 145**

This event is only available if there is an active sync check. This event indicates the two power sources have failed to synchronize either voltage, phase, or frequency within the time limit of 120 seconds.

The event stays active until the Reset/Lamp Test button on the front panel is pressed. The Fail to Sync relay output stays closed until the Reset button is pressed.

After a Fail to Sync event occurs, another Fail to Sync event may occur or, if set up to do so, the transfer switch may go to open transition. If not set up to go to open transition, a series of Fail to Sync events may repeat until the system synchronizer is adjusted or repaired.

## **Fail to Retransfer**

**Code 1114**

For utility-to-genset applications, this event is active if the transfer switch failed to move from Source 2 to Neutral or Neutral to Source 1 within a preset time limit.

For utility-to-utility and genset-to-genset applications, this event is active if the transfer switch failed to move from the backup source to the preferred source within a preset time limit.

For open transition transfer switches, the controller first verifies that the transfer switch moved from Source 1 to Neutral within the time limit defined in the Fail to Open Time Delay. The controller also verifies that the transfer switch moved from Neutral to Source 2 within the time limit defined in the Fail to Close Time Delay.

For closed transition transfer switches, the controller verifies that the ATS transferred from Source 1 to Source 2 within the time limits.

If the time limits are exceeded, the controller changes the fault status to active. The fault remains active until the Reset button is pressed.

## **Fail to Transfer**

**Code 1113**

For utility-to-genset applications, this event is active if the transfer switch failed to move from Source 1 to Neutral or Neutral to Source 2 within a preset time limit.

For utility-to-utility and genset-to-genset applications, this event is active if the transfer switch failed to move from the preferred source to the backup source within a preset time limit.

For open transition transfer switches, the controller first verifies that the transfer switch moved from Source 2 to Neutral within the time limit defined in the Fail to Open Time Delay. The controller also verifies that the transfer switch moved from Neutral to Source 1 within the time limit defined in the Fail to Close Time Delay.

For closed transition transfer switches, the controller verifies that the ATS retransferred from Source 2 to Source 1 within the time limits.

If the time limits are exceeded, the controller changes the fault status to active. The fault remains active until the Reset button is pressed.

## **High Neutral Amps**

**Code 161**

This event is detected only on switches equipped with the Load Monitoring bargraph. This event is active when the neutral current (amps) exceeds the threshold for neutral current.

## **Load Shed**

**Code 134**

This event is active whenever the Load Shed input is active.

## **Motor Disconnect**

**Code 133**

This event is active whenever the Motor Disconnect input is active and when the Drawout Release Lever is lifted. This input causes the controller to enter a non-automatic mode; it does not try to move the transfer switch mechanism.

## **Network Battery Low**

**Code 477\***

This event is detected by the optional Network Communications Module (NCM) and is active when the network lithium battery voltage is less than 5.0 VDC.

The event remains active until the Reset button on the front panel is pressed.

This event is no longer available, starting with software version 1.13.

## **Network Error**

**Code 1468\***

This event is detected by the optional Network Communications Module (NCM) and is active when a network communications error is detected. This indicates that the device is no longer communicating with other devices on the network.

The event remains active until the Reset button on the front panel is pressed.

This event is no longer available, starting with software version 1.13.

## **Network Wink**

**Code 155**

Network wink events are used by network service technicians to identify a particular network device.

**Not in Auto****Code 139**

This event is active whenever the Not In Auto LED output is activated. This event is used to support the multiple Not In Auto conditions. This output has the same value (or status) as the hardware LED output located on the ATS front panel and the Relay Module output.

Whenever any of the Not In Auto events are true — including, Motor Disconnect Switch set to Off, Fail to Charge Spring, Controller is Offline, Control Lockout Active, and Fail to Disconnect—the control makes this event active.

**Panel Lock Switch****Code 168**

This event will only occur on transfer switches equipped with the optional security key switch (see Figure 2-27). This event is active when the key switch is in the Panel Lock position. When the key switch is in the Panel Lock position, the front panel Test and Override pushbuttons are disabled and no changes to the setup menus can be made.

**Phase Rotation Fail****Code 132**

This event is active whenever Source 1 and Source 2 voltages have difference phase sequences.

This feature is used to protect against equipment damage. It is only available on Level 2 controls. This feature is required in fire pump applications and is enabled by default. This feature monitors the phase rotation of the non-connected source in relation to the connected source. When the non-connected source is out of phase rotation with the connected source, transfer is inhibited. This generally occurs on new installations or after storm damage or generator rewiring.

**Retransfer Inhibit****Code 136**

This event is active whenever the Retransfer Inhibit input is activated via any available input.

In systems that have multiple closed transition transfer switches the retransfer inhibit function should be used to make sure that multiple switches don't transfer at the same time. Refer to the section on closed transition ATS considerations.

**S1 Failed to Close****Code 2396\***

While attempting to transfer the load to Source 1, this event is detected if the control is not able to close the Source 1 contacts.

**S1 Failed to Open****Code 2397\***

While attempting to transfer the load to Source 2, this event is active if the control is not able to open the Source 1 contacts. This event is followed by a "Control Locked Out" event.

**S1 Frequency Fail****Code 123**

This event is active whenever Source 1 frequency is outside acceptable limits.

**S1 Imbalance Fail****Code 125**

This event is active whenever Source 1 phase-to-phase voltage is outside acceptable limits.

This feature is used for equipment protection. It is used in three-phase applications and informs the operator when there is a significant voltage imbalance between the phases of Source 1 or Source 2. The imbalance is typically caused by severe single phase loading. To prevent nuisance faults, the setting can be increased up to ten percent of nominal voltage.

**S1 Loss Phase****Code 124**

This event is active whenever Source 1 is missing one or more of its (three-phase) voltage sources.

This feature is mainly used to protect three-phase devices, like motors. It is only available on Level 2 controls, in a three-phase application. This feature initiates a transfer away from a source that has lost a single phase and it prevents transfer to a source that has lost a single phase. This is generally caused by a single phase to line ground or open.

**S1 Over Voltage****Code 122**

This event is active whenever Source 1 voltage is greater than the acceptable limits.

**S1 Stopped****Code 164**

This event indicates that Source 1 is not needed and is commanded by the ATS to stop. This event is used only in genset-to-genset applications.

**S1 Under Voltage** **Code 121**

This event is active when ever Source 1 voltage is less than the acceptable limits.

**S2 Failed to Close** **Code 1452\***

While attempting to transfer the load to Source 2, this event is detected if the control is not able to close the Source 2 contacts.

**S2 Failed to Open** **Code 1453\***

While attempting to transfer the load to Source 1, this event is active if the control is not able to open the Source 2 contacts.

**S2 Frequency Fail** **Code 128**

This event is activate whenever Source 2 frequency is outside acceptable limits.

**S2 Imbalance Fail** **Code 131**

This event is active whenever Source 2 phase-to-phase voltage is outside acceptable limits.

This feature is used for equipment protection. It is used in three-phase applications and informs the operator when there is a significant voltage imbalance between the phases of Source 1 or Source 2. The imbalance is typically caused by severe single phase loading. To prevent nuisance faults, the setting can be increased up to ten percent of nominal voltage.

**S2 Loss Phase** **Code 129**

This event is active whenever Source 2 is missing one or more of its (three-phase) voltage sources.

This feature is mainly used to protect three-phase devices, like motors. It is only available on Level 2 controls, in a three-phase application. This feature initiates a transfer away from a source that has lost a single phase and it prevents transfer to a source

that has lost a single phase. This is generally caused by a single phase to line ground or open.

**S2 Over Voltage** **Code 127**

This event is active whenever Source 2 voltage is greater than the acceptable limits.

**S2 Stopped** **Code 165**

This event indicates that Source 2 is not needed and is commanded by the ATS to stop. This event is used in utility-to-genset and genset-to-genset applications.

**S2 Under Voltage** **Code 126**

This event is active whenever Source 2 voltage is less than the acceptable limits.

**Sequencer Output 1 thru Sequencer Output 8** **Codes 146 thru 149 and 151 thru 154**

This event is active whenever the Load Sequencer outputs (1-8) change state.

The Load Sequencer feature consists of eight programmable timers which can control eight different network devices in a timed sequence. Each Load Sequencer output is an independent Event Announcement. This is necessary for the Network Communications Module (NCM) to receive and transmit event changes.

When these outputs are active, the transfer switch is typically inhibiting another transfer switch from loading the active source. This allows a gentle loading of a transfer switch when performing a transfer or retransfer sequence.

This event is used only in the utility-to-genset control mode.

**Service Tool** **Code 141**

This event is active whenever there is a PC Service tool connected to the controller.

**Source-1 Available****Code 102**

This event is active whenever the Source 1 sensors (over/under voltage, over/under frequency, phase rotation, loss of phase, voltage imbalance) indicate that Source 1 is within acceptable limits. There is an associated LED output on the front panel and a relay output on the Relay Module.

**Source-1 Connected****Code 101**

This event is active whenever the Source 1 position input is active. There is an associated LED output on the front panel, a relay output on the Relay Module, and a Digital Display screen that also indicate Source 1 is connected.

**Source-2 Available****Code 104**

This event is active whenever the Source 2 sensors (over/under voltage, over/under frequency, phase rotation, loss of phase, voltage imbalance) indicate that Source 2 is within acceptable limits. There is an associated LED output on the front panel and a relay output on the Relay Module.

**Source-2 Connected****Code 103**

This event is active whenever the Source 2 position input is active. There is an associated LED output on the front panel, a relay output on the Relay Module, and a Digital Display screen that also indicate Source 2 is connected.

**Speed Adjust****Code 144**

This event is used to send a *Speed Adjust* message to a network generator control. The controller sends the message and logs the event.

This signal causes the genset to increase speed (1/2 Hz) to sync with the utility. This signal ends when the transfer is complete.

**Sync Check Active****Code 119**

This event is active whenever an in-phase transfer (using the Sync Check Sensor) is pending.

**Sync Enable****Code 143**

This event is only displayed if active synchronicity is enabled. This event becomes active when the control sends a *Sync Enable* message to a network generator control.

**TDECa (Time Delay Engine Cool-Down (A))****Code 114**

This event is active whenever the Time Delay Engine Cool-Down (A) timer is active—also called the time delay stop. This event is inactive whenever the timer expires or is not active. The control activates this output whenever the control is cooling down the genset.

The digital display shows this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

**TDEL (Transfer Pending)****Code 116**

This event is active whenever the Elevator Pretransfer output is active. The control activates this event whenever a transfer pending signal is needed in the power system—this is typically used as an early warning signal for elevator systems. When the timer expires, the event becomes inactive.

The digital display shows this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

**TDEN (Time Delay Source 2 (E) to Source 1 (N))****Code 113**

This event is active whenever the Time Delay Source 2 to Source 1 timer is active—also called the time delay retransfer. This event is inactive whenever the timer expires or is not active. The control activates this output when the control is counting down to transfer the switch from Source 2 to Source 1.

The digital display shows this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

**TDESa (Time Delay Engine Start A)**

**Code 109**

This event is active whenever the Time Delay Start A timer is active. This event is inactive whenever the timer expires or is not active. The control activates this output whenever the control requires generator set (A) to start.

The digital display shows this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

The digital display shows this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

**TDNE (Time Delay Source 1 (N) to Source 2 (E))**

**Code 112**

This event is active whenever the Time Delay Source 1 to Source 2 timer is active — also called the time delay transfer. This event is inactive whenever the timer expires or is not active. The control activates this output when the control is counting down to transfer the switch from Source 1 to Source 2.

The digital display displays this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

**TDPT (Time Delay Programmed Transition)**

**Code 115**

This event is active whenever the programmed transition timer is active (whenever the control is delaying the transfer switch in the neutral position). This event is inactive whenever the timer expires or is not active.

The digital display shows this event when it becomes active. In addition, it displays an active countdown, in seconds, of the time delay.

**Test In Progress**

**Code 117**

This event is active whenever a test sequence is active. There is an associated LED output on the front panel and a relay output on the Relay Module. When this event is active, the Test/Exercise Active LED on the front panel is lit and the Test/Exercise relay on the relay module is activated.

**Test Start A**

**Code 106**

This event is active whenever the controller performs a Test sequence. The controller also activates the Emergency Start A output in order for the generator to interpret that a Test/Exercise start is called for. The genset will not start if only the Test Start A event is active.

**Test Start B**

**Code 108**


This event is active whenever the controller performs a Test sequence on Source 2. This is only used in genset-to-genset applications. The controller activates the Emergency Start B output in order for the generator to interpret that a Test/Exercise start is called for. The genset will not start if only the Test Start B event is active.

**Transfer Inhibit**

**Code 135**

This event is active whenever the Transfer Inhibit input is activated via any available input.

In systems that have multiple closed transition transfer switches the transfer inhibit function should be used to make sure that multiple switches don't transfer at the same time. Refer to the section on closed transition ATS considerations.



**TABLE 6-1. EVENT CODES AND DISPLAY MESSAGES**

Code	Event	Page Ref.
101	Source-1 Connected	2-1, 6-6
102	Source-1 Available	2-1, 6-6
103	Source-2 Connected	2-1, 6-6
104	Source-2 Available	2-1, 6-6
105	Emergency Start A	6-2
106	Test Start A	6-7
107	Emergency Start B	6-2
108	Test Start B	6-7
109	TDESa	2-10, 6-7
112	TDNE	2-10, 6-7
113	TDEN	2-10, 6-6
114	TDECa	2-10, 6-6
115	TDPT	2-10, 6-7
116	TDEL	2-10, 6-6
117	Test in Progress	6-7
118	Exercise Active	6-2
119	Sync Check Active	6-6
121	S1 Under Voltage	2-11, 6-5
122	S1 Over Voltage	2-11, 6-4
123	S1 Frequency Fail	2-11, 6-4
124	S1 Loss Phase	2-12, 6-4
125	S1 Imbalance Fail	2-12, 6-4
126	S2 Under Voltage	2-11, 6-5
127	S2 Over Voltage	2-11, 6-5
128	S2 Frequency Fail	2-11, 6-5
129	S2 Loss Phase	2-12, 6-5
131	S2 Imbalance Fail	2-12, 6-5
132	Phase Rotation Fail	2-12, 6-4
133	Motor Disconnect	2-7, 6-3
134	Load Shed	2-19, 6-3
135	Transfer Inhibit	6-7
136	Retransfer Inhibit	6-4
139	Not in Auto	2-1, 6-4
141	Service Tool	6-5
142	CT Enabled	6-2
143	Sync Enable	6-6

Code	Event	Page Ref.
144	Speed Adjust	6-6
145•	Fail to Sync	6-2
146	Sequencer Output 1	6-5
147	Sequencer Output 2	6-5
148	Sequencer Output 3	6-5
149	Sequencer Output 4	6-5
151	Sequencer Output 5	6-5
152	Sequencer Output 6	6-5
153	Sequencer Output 7	6-5
154	Sequencer Output 8	6-5
155	Network Wink	6-3
156	Common Alarm A	6-1
157	Common Alarm B	6-1
158	Controller Pwr Off	6-2
161	High Neutral Amps	6-3
164	S1 Stopped	6-4
165	S2 Stopped	6-5
168	Panel Lock Switch	6-4
441•*	Control Battery Low	6-2
477•*	Network Battery Low	6-3
597•*	Battery Charger Fault	6-1
1113•	Fail to Transfer	2-13, 6-3
1114•	Fail to Retransfer	2-13, 6-3
1121•*	Fail to Disconnect	6-2
1125•	ATS Common Alarm	6-1
1452•*	S2 Failed to Close	6-5
1453•*	S2 Failed to Open	6-5
1468•*	Network Error	6-3
2396•*	S1 Failed to Close	6-4
2397•*	S1 Failed to Open	6-4
<ul style="list-style-type: none"> <li>• Events requiring the front panel Reset button be pressed.</li> <li>* Events that are flashed out with the LED indicators on the Digital Module.</li> </ul>		

# 7. Troubleshooting

The following procedures describe preliminary troubleshooting checks. If the problem persists, call your dealer or distributor.

Fault messages appear on the digital display, and by LED indicators. Ten LED indicators and a small push-button switch located on the Digital Module may help in troubleshooting the transfer switch (Figure NO TAG).

## CONTROL MODULE LED INDICATORS AND SWITCH

The digital module located on the inside of the switch enclosure door contains ten LED indicators. The indicators provide some information about the current control status. These indicators may be

helpful in troubleshooting the transfer switch when the cabinet door is open. See Figure NO TAG.

## Fault Flash-Out

The control flashes an active fault code on the Status LED indicator until it is acknowledged with the Reset switch on the front panel. See Figure NO TAG and Table NO TAG. The control flashes each digit of the fault code with a pause between digits and a longer pause between repetitions.

The control moves and stores acknowledged events to an event history file. This file can hold a maximum of 50 fault and non-fault events. Contents of the events history file can be viewed using the digital display or the PC service tool.




FIGURE . LED LOCATION ON DIGITAL MODULE (SHOWN ON THE 600-1000 AMP SPEC A SWITCH)

**TABLE 6-1 DIGITAL MODULE LED INDICATORS**

<b>Indicator</b>	<b>Definition</b>
Status	Blinks at 1/2 Hz rate when the controller has power and the program is running without error. This indicator flashes the event code of an active event until the event is acknowledged with the Reset switch on the front panel. This indicator is sometimes referred to as the heart beat because it blinks constantly when the controller does not have an active event. (Refer to Table 4-2.)
S1 Available	Lights when Power Source 1 has acceptable voltage and frequency limits. This indicator lights when the Source 1 Available indicator on the control panel lights.
S2 Available	Lights when Power Source 2 has acceptable voltage and frequency limits. This indicator lights when the Source 2 Available indicator on the control panel lights.
Start A/TDES-A	<ol style="list-style-type: none"> <li>1. Lights constantly when the control has commanded Source 2 to start</li> <li>2. Blinks at 1/2 Hz rate during the time delay to engine start (TDESa)</li> </ol>
Start B/TDES-B	<p>This indicator is only used for genset-to-genset applications when Source 1 is a generator not a utility.</p> <ol style="list-style-type: none"> <li>1. Lights constantly when the control has commanded Source 1 to start</li> <li>2. Blinks at 1/2 Hz rate during the time delay to engine start (TDESb)</li> </ol>
Retransfer/TDEN	<ol style="list-style-type: none"> <li>1. Lights when the control energizes the Retransfer relay</li> <li>2. Blinks at 1/2 Hz rate during the time delay to retransfer (TDEN)</li> </ol>
Transfer/TDNE	<ol style="list-style-type: none"> <li>1. Lights when the control energizes the Transfer relay</li> <li>2. Blinks at 1/2 Hz rate during the time delay to transfer (TDNE)</li> </ol>
TDPT	<p>Time Delay Programmed Transition</p> <p>Blinks at 1/2 Hz rate during the programmed transition time delay</p>
Exerciser Enabled	Lights when an Exerciser routine is enabled and blinks during an exercise period. The small switch next to the indicator enables and disables the exerciser. The operator can also enable and disable the exercise routine from the Digital Display when it is available.

**Exerciser Enable/Disable Switch**

All controllers have a switch to enable or disable pre-set exercise routines. The pushbutton is located on the Digital Module above the batteries next to the LED light bar display. This button is used by service personnel to disable unexpected transfers while servicing the switch.

**Override Pushbutton**

To override transfer time delays and transfer inhibits, press the Override pushbutton. The controller will not override time delays for Programmed Transition, Elevator Pre-Transfer signals and Engine Cool-down. The Override pushbutton is located on the front of the cabinet. See *Section 2, Description*.

## TROUBLESHOOTING TRANSFER SWITCH WITHOUT A DIGITAL DISPLAY

**⚠WARNING** *Some ATS service procedures present hazards that can result in severe personal injury or death. Only qualified service personnel with knowledge of electricity and machinery hazards should perform service. See Safety Precautions.*

When the digital display is not available, diagnosis of problems involves observing system operation.

The “Status” LED indicator shown in Figure NO TAG will continuously flash a fault code when a fault occurs. Table NO TAG lists the fault codes. You should be able to visually count the intermittent pulses on the LED and determine the corresponding numerical code.

If the transfer switch is equipped with a network module, events and fault codes can be viewed using InPower software.

To acknowledge or clear the event or fault, press the Override pushbutton. If you cannot determine the problem, contact Cummins Power Generation Service.

## GENERAL TROUBLESHOOTING

### Power Outage Occurs, But Generator Set Does Not Start

**⚠WARNING** *AC power within the cabinet and the rear side of the cabinet door present a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open.*

1. The operation selector switch on the generator set control panel should be set at Remote. Check for fault indicators on the generator set control.
2. Start the generator set using its start-stop controls. If it does not crank, check the starting batteries. If it cranks but does not start, check the fuel supply. If the problem persists, call your dealer or distributor.

3. The controller doesn't sense Source 1 has failed. Press the Reset Pushbutton or the Test Pushbutton.
4. Check the Engine Start Time Delay in the Setup menus. It should not be set over 120 seconds.

**⚠WARNING** *Ignition of explosive battery gases can cause severe personal injury. Do not smoke or cause any spark or flame while servicing batteries.*

**⚠WARNING** *Ignition of fuel can cause severe personal injury or death by fire or explosion. Do not permit any flame, cigarette, spark, pilot light, arcing equipment, or other possible source of ignition near the fuel system.*

### Generator Set Starts During Normal Power Service

1. The operation selector switch on the generator set control panel should be set at Remote.

**⚠WARNING** *AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. Use extreme caution to avoid touching electrical contacts whenever the cabinet door is open.*

2. Check the Test/Exerciser Active indicator to see whether it is in an exercise period.

If the exercise period occurs at unexpected times or for excessive duration, check the Exercise Routines in the Setup Menus. Reprogram if necessary.

3. Momentary voltage dips might cause voltage sensors to initiate generator set starting. Check the parameter settings in the Setup Menus.
4. The switch is sensing an Over- or -Under Voltage condition on Source 1.
5. If the problem persists, call your dealer or distributor.

### Generator Set Does Not Exercise

1. The operation selector switch on the generator set control panel should be set at Remote.

2. Check wiring between transfer switch and genset for correct configuration and opens. (Refer to the Interconnection Diagram supplied with the switch.)

**⚠WARNING** *AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. When the cabinet door is open, use extreme caution to avoid touching electrical contacts with body, tools, jewelry, clothes, hair, etc.*

3. Check the Test/Exerciser Active indicator to see whether it is in an exercise period.
4. Start the generator set using its start-stop controls. If it does not crank, check the starting batteries. If it cranks but does not start, check the fuel supply. If the problem persists, call your dealer or distributor.

**⚠WARNING** *Ignition of explosive battery gases can cause severe personal injury. Do not smoke or cause any spark or flame while servicing batteries.*

**⚠WARNING** *Ignition of fuel can cause severe personal injury or death by fire or explosion. Do not permit any flame, cigarette, spark, pilot light, arcing switch or equipment, or other possible source of ignition near the fuel system.*

### After a Power Failure, Generator Set Starts But Does Not Assume Load

1. Check the Not In Auto lamp on front panel. In this instance, the indicator will be lit if :

The Transfer Inhibit option is active – press the Override pushbutton.

The Motor Disconnect switch is in the OFF position (1200–3000 amp units) – open cabinet door and move switch to AUTO.

The switch is bypassed to Source 1 – manually transfer the bypass switch to Source 2 (see *Operation*).

The Load Shed option is enabled and will not allow the switch to move. – Disable Load Shed.

**⚠WARNING** *AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. When the cabinet door is open, use extreme caution to avoid touching electrical contacts with body, tools, jewelry, clothes, hair, etc.*

2. Check the output voltage of the power source by observing the voltmeter on the generator set or the optional meters on the transfer switch door.
3. Check the Source 2 Available lamp on the ATS Control Panel. Check the parameter settings in the Setup menus.
4. The Drawout Release lever should be fully locked. Lift the lever and turn the Drawout Crank handle clockwise or counterclockwise to allow the lever to fully drop.

### After Power Returns, Transfer Switch Does Not Return to Normal Position

1. The retransfer time delay period may not have expired. Check the Retransfer Timing lamp on the Digital Module.
2. The transfer switch is bypassed to Source 2 – manually transfer the bypass switch to Source 1.
3. The Retransfer Inhibit option is active – press the Override pushbutton.
4. The Load Shed option is active and is moving the load to neutral. Switch should transfer.
5. Open the cabinet door and check the Motor Disconnect switch position. For automatic operation, it must be in the AUTO position.

**⚠WARNING** *AC power within the cabinet and the rear side of the cabinet door presents a shock hazard that can cause severe personal injury or death. When the cabinet door is open, use extreme caution to avoid touching electrical contacts with body, tools, jewelry, clothes, hair, etc.*

6. Stop the generator set with the Start/Stop switch. When the generator set stops, the transfer switch transfers the load to Power Source 1, if power ratings are acceptable.

- If the switch still does not retransfer, manually return the switch to the Source 1 position (see *Operation*). Call your dealer or distributor.

### Generator Set Continues to Run After Retransfer of Load to Normal Power

The Engine Cool-Down Time Delay is active. Genset should stop when time delay expires (30 minutes maximum).

If genset continues to run, stop the genset with its Start/Stop switch, and call your dealer or distributor.

### Battery Charger Fails To Charge (If Equipped)

Check the battery charger fuse(s). Replace, if necessary, with fuses of the correct rating. Fuse ampere ratings are shown on the charger faceplate.

**⚠WARNING** *Ignition of explosive battery gases can cause severe personal injury. Do not smoke or cause any spark or flame while servicing batteries.*

If the fuse is OK, call your dealer or distributor.

### Battery Loses Water

The battery charger float voltage could be too high (if equipped with battery charger). Adjust the float setting. Refer to the *Installation Manual*. If the problem continues, call your dealer or distributor.

### Battery Loses Charge

Battery charger float voltage could be too low (if equipped with battery charger). Adjust the float setting. Refer to the *Installation Manual*. If the problem continues, call your dealer or distributor.

## TROUBLESHOOTING TRANSFER SWITCH WITH THE DIGITAL DISPLAY

The Digital Display shows two types of events: fault events and non-fault events. The last 50 events, both fault and non-fault events, can be viewed with the Digital Display. You can also read all events in the event history file by using the PC Service Tool.

### Fault Events

Fault events should be considered alarms for the transfer switch operator. They indicate that the transfer switch is not operating correctly. Table NO TAG lists the fault codes and fault message and Table NO TAG gives corrective actions for each fault code.

**TABLE 6-2 FAULT CODES AND MESSAGES**

343	Controller Checksum Error
441	Low Controller Battery
1113	ATS Fail to Close: Transfer
1114	ATS Fail to Close: Retransfer
597	Battery Charger Malfunction
477*	Network Battery Low
1468	Network Communications Error
* This fault code only applies to older transfer switches that included an Network Communications Module (NCM) with batteries.	

The controller displays the fault message on the Digital Display. The flashing asterisk indicates the event or fault code is currently active. Pressing the Reset button on the control panel acknowledges a fault and clears the display.

The LED indicator on the Digital Module will flash out the numerical code on the status LED .

TABLE 6-3 TROUBLESHOOTING

**⚠ WARNING** *Some ATS service procedures present hazards that can result in severe personal injury or death. Only qualified service personnel with knowledge of electricity and machinery hazards should perform service. See Safety Precautions.*

**CONTROLLER CHECKSUM ERROR (343)**

The checksum of the Flash EPROM does not match the checksum stored in the controller

**Corrective Action:**

1. Reset the control by removing power.
2. Remove and re-install Digital Module batteries (see Figures 2-5 and 2-6).
3. Contact Cummins Power Generation Service if checksum error is repeated on power up.
4. Reset real-time clock (see Figure 4-18).

**LOW CONTROLLER BATTERY (441)**

Low Lithium battery voltage

**Corrective Action:**

1. Replace Digital Module batteries. (See Figures 2-5 and 2-6.)
2. Press the Reset button on the front panel.
3. Reset real-time clock (see Figure 4-18).

**ATS FAIL TO CLOSE: TRANSFER (1113)**

A transfer between Source 1 and Neutral failed or the allotted transfer time was exceeded.

**Corrective Action:**

1. Press the Reset button on the front panel.
2. Refer to the fault definitions following this table.
3. Contact Cummins Power Generation Service.

**ATS FAILED TO CLOSE: RETRANSFER (1114)**

A transfer between Source 2 and Neutral failed or the allotted transfer time was exceeded.

**Corrective Action:**

1. Press the Reset button on the front panel.
2. Refer to the fault definitions following this table.
3. Contact Cummins/Onan Service.




TABLE 6-3 TROUBLESHOOTING (CONTINUED)

**⚠ WARNING** *Some ATS service procedures present hazards that can result in severe personal injury or death. Only qualified service personnel with knowledge of electricity and machinery hazards should perform service. See Safety Precautions.*

**BATTERY CHARGER MALFUNCTION (597)**

The battery charger status signal indicates a fault condition.

**Corrective Action:**

1. Press the Reset button on the front panel.
2. Check the battery charger fuse(s). Replace, if necessary, with fuses of the correct rating. Fuse current ratings are shown on the charger faceplate.
3. Refer to the fault definitions following this table.
4. Contact Cummins/Onan Service.

**NETWORK BATTERY LOW (477)**

The Network Control Module (NCM) indicates that the network battery voltage is low.

**Corrective Action:**


1. Press the Reset button on the front panel.
2. Replace the Network Module batteries.
3. Contact Cummins/Onan Service.

**NETWORK COMMUNICATIONS ERROR (1468)**

The Network Control Module (NCM) indicates that a network communications error has occurred.

**Corrective Action:**

1. Press the Reset button on the front panel.
2. Contact Cummins/Onan Service.



## FAULT CODE DEFINITIONS

### Controller Checksum Error

The control checks the Flash EPROM checksum after each microprocessor reset. The checksum is stored in nonvolatile EPROM. If a checksum error fault occurs, the controller still attempts a normal boot-up sequence.

The control Fault Flash-out system flashes this fault on the Status LED Indicator until the fault is acknowledged (reset). Reset the control by removing power (including the batteries). If checksum error is repeated on power up, replace the Digital Module.

### Low Controller Battery

The control monitors the voltage of the Lithium batteries that supply power to the controller. If the battery voltage drops to 5.2 VDC, the controller sets the fault status to active.

The control Fault Flash-out system flashes this fault on the Status LED Indicator until the fault is acknowledged (reset).

### ATS Fail to Close: Re-Transfer

The control first verifies that the transfer switch moved from Source 2 to Neutral within the time limit defined in the Fail to Close Time Delay. The control also verifies that the transfer switch moved from Neutral to Source 1 within the time limit defined in the Fail to Close Time Delay.

If the Fail to Close time limit is exceeded, the control changes the fault status to active. The fault remains active until the Reset button is pressed.

### ATS Fail to Close: Transfer

The control first verifies that the transfer switch moved from Source 1 to Neutral within the time limit

defined in the Fail to Close Time Delay. The control also verifies that the transfer switch moved from Neutral to Source 1 within the time limit defined in the Fail to Close Time Delay.

If the Fail to Close time limit is exceeded, the control changes the fault status to active. The fault remains active until the Reset button is pressed.

### Battery Charger Malfunction

The control monitors the status of the optional battery charger. If the Battery Charger Fault input is active, this event is active.

The control Fault Flash-out system flashes this fault until the fault is acknowledged (reset).

### Network Battery Low


This event is detected by the optional Network Communications Module (NCM) and is communicated to the control. If the battery voltage drops, the control sets the fault status to active.

The control Fault Flash-out system flashes this fault on the Status LED Indicator until the fault is acknowledged (reset).

### Network Communications Error


This event is detected by the Network Communications Module (NCM) and is communicated to the transfer switch control. This indicates that the device is no longer communicating with other devices on the network.

The control Fault Flash-out system flashes this fault on the Status LED Indicator until the fault is acknowledged (reset).



## 8. Time Delay Glossary

TIME DELAY	ABBREVIATION	DEFINITION
Start Time Delay	TDES	This delay is adjustable from 0 to 15 seconds in 1 second increments on Level-1 controls and from 0 to 120 seconds in 1 second increments on Level-2 controls. The default value is 3 seconds for both. This brief time delay prevents the generator set from starting during short power interruptions. Timing starts at the Source 1 power interruption. If the duration of interruption exceeds the delay time, the control system signals the generator set to start. The value is set with the PC service tool or the digital display when it is available.
Stop Time Delay (Cool-down)	TDEC	This delay is adjustable from 0 to 30 minutes in 1 minute increments. The default value is 10 minutes. It begins timing when the load is retransferred to Source 1. At the end of the delay, the stop signal is sent to the generator set. During this time delay, the generator set cools down at no load before stopping. The value is set with the PC service tool or the digital display when it is available.
Transfer Time Delay	TDNE	This delay begins when Source 2 (typically the generator) voltage and frequency reach the settings of the control. After the delay, the transfer switch transfers the load to Source 2. This brief time delay allows the generator set to stabilize before the load is applied. It has an adjustable range of 0 to 120 seconds in 1 second increments. The default value is 10 seconds. The value is set with the PC service tool or the digital display when it is available.  TDNE is the delay from preferred source to backup source in utility-to-utility applications.
Retransfer Time Delay	TDEN	This delay begins the moment Source 1 line voltage and frequency return to specified values. After the delay, the transfer switch can retransfer the load to Source 1. The delay allows the Power Source 1 to stabilize before retransfer. It has an adjustable range of 0 to 30 minutes in 1 minute increments. The default value is 10 minutes. The value is set with PC service tool or the digital display when it is available.  TDEN is the delay from backup source to preferred source in utility-to-utility applications.
Programmed Transition Time Delay	TDPT	This delay is the time that the switch spends in the neutral position, when neither source is connected to the load, during a transfer or a retransfer. It begins when the switch moves to the neutral position and opens the contacts of the switch connected to the load. After the delay the control transfers the load. This time delay allows residual voltage of inductive loads to decay sufficiently before connecting it to another source. It is adjustable from 0 to 60 seconds in 1 second increments. The default value is 0 seconds. The proper adjustment is a function of the load. This feature is enabled by default. The value is set with the PC service tool or the digital display when it is available.
Elevator Pre-transfer Time Delay	TDEL	The Elevator Pre-Transfer Delay Signal delays transfer (or retransfer) for a specified time to give warning to an elevator control that a transfer (or retransfer) is about to occur. It is adjustable from 0 to 60 seconds in 1 second increments. The default value is 0 seconds. This feature is enabled by default. The value is set with the PC service tool or the digital display when it is available.



**THIS PAGE LEFT INTENTIONALLY BLANK**



## 9. Application Considerations for Closed Transition Transfer Switches

---

In Closed transition power transfer introduces risk to the power system because two live sources are momentarily connected together. The following simple installation practices can minimize these risks:

- Prevent multiple transfer switches from transferring at the same time. Multiple transfer switches transferring simultaneously can result in the genset voltage being unstable during transfer. Two methods for preventing simultaneous transfer are:
  - Staggering time delays between switches and
  - Interconnecting aux contacts with inhibit functions.
- Prevent the two sources from remaining connected indefinitely by connecting the ATS fail to disconnect output to the shunt trip input of one of the breakers feeding the ATS. This function is actually required by many utilities.


### Staggering Time Delays


Setting time delays on different transfer switches to different values will prevent the switches from transferring at the same time. For example setting the Emergency to Normal Time Delays (TDEN) to different values on each switch will prevent the switches from re-transferring to the normal source at the same time after the source has returned after a failure or at the end of a test. When using this method care should be taken to make sure that all of the sensing settings are the same on each of the switches to make sure that the switches recognize the source as being available at the same time.

Note that it is only necessary to stagger the time delays when transferring between live sources. After a utility failure it is not necessary to stagger time delays for switching loads on to the genset unless the genset needs time to recover after taking on the individual loads as is often the case when starting large motors.


### Re-transfer and Transfer Inhibit Functions

The transfer and re-transfer inhibit functions can be used to prevent multiple transfer switches from transferring at the same time. For example to prevent two switches from re-transferring from the genset to the utility at the same time wire the normally closed contact that indicates the first ATS is connected to the normal source into the retransfer inhibit input of the transfer switch that is intended to transfer second. Ground the common aux contact on the first switch so that the re-transfer inhibit input on the second switch is grounded when the first transfer switch is not connected to the normal source. This will inhibit the second switch from beginning its retransfer sequence (including all time delays) until after the first transfer switch has transferred back to the normal source. A similar wiring scheme can be used when transferring to the emergency source so that only one switch transfers at a time. Switch position outputs are available on the relay signal module which is included with all Cummins closed transition ATS models. Figures 1 and 2 illustrate how this can be accomplished with all of Cummins' closed transition transfer switch models.





**FIGURE 9-1. USING SOURCE CONNECTED CONTACTS TO INHIBIT TRANSFERS SUCH THAT ONLY ONE  
ATS WILL TRANSFER AT A TIME FOR  
CHPC AND BTPC 1600-3000 AMP TRANSFER SWITCHES**




**FIGURE 9-2. USING SOURCE CONNECTED CONTACTS TO INHIBIT TRANSFERS SUCH THAT ONLY ONE ATS WILL TRANSFER AT A TIME FOR OTPC 1000-4000 AND BTPC 125-1200 AND 4000 AMP TRANSFER SWITCHES**

**Fail to disconnect**

The Fail to Disconnect relay is active when the transfer switch remains connected to both sources for

more than 100 msec during a closed transition transfer. It should be wired to the shunt trip of the breaker feeding the ATS on either the normal or the emergency side. The fail to disconnect relay is located on the relay signal module. See figure 3.



**FIGURE 9-3. USING THE FAIL TO DISCONNECT OUTPUT TO SHUNT TRIP A BREAKER**





[www.power.cummins.com](http://www.power.cummins.com)

Copyright © 2015 Cummins Power Generation Inc. All rights reserved.

Cummins Power Generation, the "C" logo, and Cummins are registered trademarks of Cummins Inc. PowerCommand, AmpSentry, InPower and "Our energy working for you." are trademarks of Cummins Power Generation. Other company, product, or service names may be trademarks or service marks of others. Specifications are subject to change without notice.

