

# Eaton® 93PM-L UPS

20 – 60 kW (208V) UPS  
Installation and Operation Manual



p/n: P-164000711  
Revision 05

---

**IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS**

---

This manual contains important instructions that you should follow during installation and maintenance of the UPS and batteries. Please read all instructions before operating the equipment and save this manual for future reference.

---

---

**CONSIGNES DE SÉCURITÉ IMPORTANTES – CONSERVER CES INSTRUCTIONS**

---

Ce manuel comporte des instructions importantes que vous êtes invité à suivre lors de toute procédure d'installation et de maintenance des batteries et de l'onduleur. Veuillez consulter entièrement ces instructions avant de faire fonctionner l'équipement et conserver ce manuel afin de pouvoir vous y reporter ultérieurement.

---

**IMPORTANT**

---

To ensure you have the most up-to-date content and information for this product, please review the latest manual revision on our website, [www.eaton.com/93PM](http://www.eaton.com/93PM).

---

Eaton reserves the right to change specifications without prior notice. Eaton is a registered trademark of Eaton. National Electrical Code and NEC are registered trademarks of National Fire Protection Association, Inc. ERIFLEX and FLEXIBAR are registered trademark of Erico International Corporation. All other trademarks are property of their respective companies.

©Copyright 2017-2020 Eaton, Raleigh, NC, USA. All rights reserved. No part of this document may be reproduced in any way without the express written approval of Eaton.

## EATON END-USER LICENSE AGREEMENT

IMPORTANT, READ CAREFULLY. THIS END USER LICENSE AGREEMENT (THE "AGREEMENT") IS A BINDING CONTRACT BETWEEN YOU, THE END-USER (THE "LICENSEE") AND EATON INTELLIGENT POWER LIMITED, IRELAND, OR ONE OF ITS AFFILIATES ("EATON" OR "LICENSOR"), BY OPERATING THIS UNINTERRUPTIBLE POWER SUPPLY (UPS) PRODUCT INCLUDING SOFTWARE EMBEDDED IN IT (FIRMWARE), YOU, THE LICENSEE, ARE AGREEING TO BE BOUND BY THE TERMS, CONDITIONS, AND LIMITATIONS OF THIS AGREEMENT. READ THE TERMS AND CONDITIONS OF THIS AGREEMENT CAREFULLY BEFORE, INSTALLING OR OPERATING THE PRODUCT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, PROMPTLY RETURN THE UNUSED PRODUCT TO EATON.

### 1.0 DEFINITIONS

**1.1 Documentation.** "Documentation" means the user guides and manuals for the installation and use of the UPS, whether made available over the internet, provided in CD-ROM, DVD, hard copy or other form.

**1.2 Firmware.** "Firmware" means software programs that are embedded in the product for which Licensee is granted a license hereunder, the Documentation therefore and, to the extent available, Updates thereto. The Firmware is licensed hereunder in object code (machine-readable) form only except that certain software programs may include limited portions in source code (human-readable) form.

**1.3 Update.** "Update" means a subsequent release of the Firmware, if and when developed by Eaton. An Update does not include any release, new version, option, or future product, which Eaton licenses separately.

### 2.0 FIRMWARE LICENSE

**2.1 Ownership.** Eaton or its third party licensors retains all title, copyright and other proprietary rights in, and ownership of the Firmware regardless of the media upon which the original or any copy may be recorded or fixed.

**2.2 License Grant.** Eaton grants to Licensee a limited, revocable, non-exclusive, non-assignable license to use the Firmware in conjunction with the operation of the product to which the Firmware pertains or other products as described by Eaton in the Documentation. Licensee does not acquire any rights, express or implied, other than those expressly granted in this Agreement.

**2.3 Restrictions and Requirements.** Licensee will not, nor will it permit others to, modify, adapt, translate, reverse engineer, decompile, or disassemble the Firmware or any component thereof (including the Documentation), or create derivative works based on the Firmware (including the Documentation), except to the extent such foregoing restriction is prohibited by applicable law or applicable open source license to, and only to, any open source software component that is incorporated into the Firmware (if any). Copyright laws and international treaties protect the Firmware, including the Documentation. Unauthorized copying of the Firmware, the Documentation or any part thereof, is expressly prohibited. For avoidance of doubt, Eaton does not grant Licensee a license to any of Eaton's brands, logos, designs, trade dress, service marks, trademarks, domain names or trade names, in whole or in part. Licensee agrees to install or allow installation of all corrections of substantial defects, security patches, minor bug fixes and updates, including any enhancements, for the Firmware in accordance with the instructions and as directed by Eaton.

**2.4 Transfer and Assignment Restrictions.** Licensee will not sell, resell, assign, lease, sublicense, encumber, or otherwise transfer its interest in this Agreement or in the Firmware, or the Documentation in whole or in part, or allow any other person or entity, including any parent or subsidiary of Licensee or other subsidiary of Licensee's parent, to copy, distribute, or otherwise transfer the Firmware without the prior written consent of Eaton. Licensee may transfer the Firmware directly to a third party only in connection with the sale of the Eaton product in which it is installed.

### 3.0 TERMINATION

**3.1 Termination.** This Agreement and the license granted hereunder automatically terminates if Licensee breaches any provision of this Agreement. Eaton may terminate this license at any time with or without cause.

**3.2 Effect of Termination.** Immediately upon termination of this Agreement or the license granted hereunder, Licensee will cease using the product. The parties' rights and obligations under the following sections of this Agreement will survive termination of this Agreement: Article 1.0, Section 2.1, Section 2.3, Section 2.4, Article 3.0, Article 4.0 and Article 5.0.

### 4.0 INFRINGEMENT AND WARRANTIES

**4.1 Infringement.** If Licensee learns of a threat, demand, allegation, or indication that the UPS with its firmware infringes or misappropriates any third party intellectual property rights (including but not limited to any patent, copyright, trademark, trade dress, or trade secret) ("Intellectual Property Claim"), Licensee will notify Eaton promptly of such claim. Eaton may, in its sole discretion, elect to assume sole control of the defense and settlement of said Intellectual Property Claim and Licensee will provide reasonable information and assistance to Eaton for the defense of such claim.

**4.2 Disclaimer of Warranties.** THE FIRMWARE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EATON DOES NOT WARRANT THAT THE FIRMWARE WILL BE ERROR-FREE OR SECURE FROM UNAUTHORIZED ACCESS. THE LICENSEE EXPRESSLY ACKNOWLEDGES THAT TO THE EXTENT PERMITTED BY APPLICABLE LAW, THE USE OF THE PRODUCT IS AT LICENSEE'S SOLE RISK.

### 5.0 GENERAL PROVISIONS

**5.1 Update Policy.** Eaton may from time to time, but has no obligation to, create Updates of the Firmware or components thereof.

**5.2 Limitation on Liability.** NOTWITHSTANDING ANY PROVISION OF THIS AGREEMENT TO THE CONTRARY, LICENSEE EXPRESSLY UNDERSTANDS AND AGREES THAT EATON, ITS AFFILIATES, AND ITS LICENSORS, WILL NOT BE LIABLE FOR: (A) ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES WHICH MAY BE INCURRED BY LICENSEE OR ANY THIRD PARTY, HOWEVER CAUSED AND UNDER ANY THEORY OF LIABILITY THIS WILL INCLUDE, BUT NOT BE LIMITED TO, ANY LOSS OF PROFIT (WHETHER INCURRED DIRECTLY OR INDIRECTLY), ANY LOSS OF GOODWILL OR BUSINESS REPUTATION, ANY LOSS OF DATA SUFFERED, COST OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, OR OTHER INTANGIBLE LOSS; (B) ANY LOSS OR DAMAGE WHICH MAY BE INCURRED BY LICENSEE OR ANY THIRD PARTY. THESE LIMITATIONS ON EATON'S LIABILITY WILL APPLY WHETHER OR NOT EATON HAS BEEN ADVISED OF OR SHOULD HAVE BEEN AWARE OF THE POSSIBILITY OF ANY SUCH LOSSES ARISING.

TO THE EXTENT PERMITTED BY LAW, THE TOTAL LIABILITY OF EATON, ITS AFFILIATES, AND ITS LICENSORS, FOR ANY CLAIMS UNDER THESE TERMS, INCLUDING FOR ANY IMPLIED WARRANTIES, IS LIMITED TO THE AMOUNT PAID FOR THE UPS.

THIS SECTION 5.2 STATES EATON'S ENTIRE LIABILITY AND LICENSEE'S SOLE AND EXCLUSIVE REMEDY UNDER THIS AGREEMENT, AND IS SUBJECT TO ALL LIMITATIONS STATED IN SECTION 4.2.

**5.3 Notices.** All notices required to be sent hereunder will be in writing and will be deemed to

have been given when mailed by first class mail to the address shown below:

LICENSE NOTICES:  
Eaton Intelligent Power Limited  
Eaton House,  
30 Pembroke Road,  
Dublin 4,  
D04 Y0C2,  
Ireland

**5.4 Severability.** If any provision of this Agreement is held to be invalid or unenforceable, the remaining provisions of this Agreement will remain in full force.

**5.5 Waiver.** The waiver by either party of any default or breach of this Agreement will not constitute a waiver of any other or subsequent default or breach. Failure to enforce or delay in enforcing any provision of this Agreement will not constitute a waiver of any rights under any provisions of this Agreement.

**5.6 Entire Agreement.** This Agreement constitutes the complete agreement between the parties and supersedes all prior or contemporaneous agreements or representations, written or oral, concerning the subject matter of this Agreement. This Agreement may not be modified or amended except in a writing specifically referencing this Agreement and signed by a duly authorized representative of each party. No other act, document, usage or custom will be deemed to amend or modify this Agreement. The Firmware, or portions thereof, may also be subject to additional paper or electronic license agreements. In such cases, the terms of this Agreement will be supplemental to those in the additional agreements, to the extent not inconsistent with the additional agreements. If a copy of this Agreement in a language other than English is included with the Firmware or Documentation, it is included for convenience and the English language version of this Agreement will control.

**5.7 Heirs, Successors, and Assigns.** Each and all of the covenants, terms, provisions and agreements herein contained will be binding upon and inure to the benefit of the parties hereto and, to the extent expressly permitted by this Agreement, their respective heirs, legal representatives, successors and assigns.

**5.8 Export Restrictions.** Licensee agrees to comply fully with all relevant export laws and regulations of the United States and all other countries in the world (the "Export Laws") to assure that neither the Firmware nor any direct product thereof are (i) exported, directly or indirectly, in violation of Export Laws; or (ii) are intended to be used for any purposes prohibited by the Export Laws. Without limiting the foregoing, Licensee will not export or re-export the Firmware: (i) to any country to which the U.S. has embargoed or restricted the export of goods or services (see <http://www.treasury.gov/resource-center/sanctions/Programs/Pages/Programs.aspx>), or to any national of any such country, wherever located, who intends to transmit or transport the Firmware back to such country; (ii) to any end user who Licensee knows or has reason to know will utilize the Firmware in the design, development or production of nuclear, chemical or biological weapons; or (iii) to any end-user who has been prohibited from participating in U.S. export transactions by any federal agency of the U.S. government.

**5.9 U.S. Government Restricted Rights.** The Firmware is a "commercial item" as that term is defined at 48 C.F.R. § 2.101, consisting of "commercial computer software" and "commercial computer software documentation", as such terms are used in 48 C.F.R. § 12.212, and is provided to the U.S. Government only as a commercial end item. Consistent with 48 C.F.R. § 12.212 and 48 C.F.R. §§ 227.7202-1 through 227.7202-4, all U.S. Government End Users acquire the Firmware with only those rights set forth herein. Contractor/manufacturer is Eaton Corporation, 1000 Eaton Boulevard, Cleveland, Ohio 44122.

**5.10 Third Party Intellectual Property Rights.** The Firmware may contain components (including open source software components) that are owned by third parties ("Third Party Licensors") and are provided with, incorporated into, or embedded in, the Firmware pursuant to license arrangements between Eaton and such third parties. Third Party Licensor components in the Firmware are not licensed or warranted under the terms of this document, but are instead subject to the Third Party Licensors' license agreements. Licensee will not modify, delete, or obfuscate any copyright or other proprietary rights notices of Third Party Licensors contained in the Firmware.

**5.11 Indemnity.** Licensee shall defend, indemnify and hold Eaton and its officers, directors, employees, and agents harmless from and against all losses, damages, liabilities, claims, actions, and associated costs and expenses (including reasonable attorneys' fees and expenses) by reason of injury or death to any person or damage to any tangible or intangible property arising or resulting from the negligence or willful misconduct of the Licensee, its employees, contractors, or agents, in connection with Licensee's use of Firmware and Documentation.

Licensee shall be responsible for any breach of this Agreement by its officers, directors, employees, contractors, or agents. Licensee shall defend, indemnify, and hold Eaton and its officers, directors, employees, and agents harmless from and against any and all losses, damages, liabilities, claims, actions, and associated costs and expenses (including reasonable attorneys' fees and expenses) arising out of or in connection with any breach of this Agreement.

**5.12 Open Source Software.** The Firmware may contain certain components owned by Eaton that are provided with, incorporated into, linked to, or embedded in the Firmware that are subject to third party open source licenses ("Eaton Open Source Components"). Eaton Open Source Components are subject to the open source licenses corresponding to the particular software component. To the extent there are any conflicts between the terms of this Agreement and any open source license corresponding to Eaton Open Source Components or additional obligations by such open sources license that are not set forth in this Agreement, the terms of the open source license will control.

**5.13 Confidentiality.** Licensee acknowledges that confidential aspects of the Firmware (including any proprietary source code) are a trade secret of Eaton, the disclosure of which would cause substantial harm to Eaton that could not be remedied by the payment of damages alone and such confidential aspects of the Firmware shall not be disclosed to third parties without the prior written consent of Eaton. Accordingly, Eaton will be entitled to preliminary and permanent injunctive and other equitable relief for any breach of this Section 5.13.

**5.14 Note on JAVA Support.** The Firmware may contain support for programs written in JAVA. JAVA technology is not fault tolerant and is not designed, manufactured, or intended for use or resale as online control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communications systems, air traffic control, direct life support machines, or weapons systems, in which the failure of JAVA technology could lead directly to death, personal injury, or severe physical or environmental damage. EATON DISCLAIMS ALL DAMAGES INCLUDING DIRECT, INDIRECT AND CONSEQUENTIAL DAMAGES RELATING TO THE FAILURE OF ANY SOFTWARE INCLUDING JAVA PROGRAMS AND/OR JAVA TECHNOLOGY.

**5.15 Governing Law.** This Agreement will be interpreted and enforced in accordance with the laws of Ireland, without regard to choice of law principles. Any claim or suit with respect to this Agreement shall be brought in the Courts of Ireland, unless mandatory law imposes otherwise.

Eaton EULA



# Table of Contents

<b>1 Introduction</b>	<b>1</b>
1.1 UPS Standard Features	1
1.1.1 Installation Features	1
1.1.2 Control Panel	3
1.1.3 Customer Interface	3
1.1.4 Energy Saver System Mode	3
1.1.5 Internal Redundancy	4
1.1.6 Advanced Battery Management	4
1.2 Options and Accessories	4
1.2.1 Integrated Battery Cabinet	4
1.2.2 Sidecar Integrated Accessory Cabinet-Bypass	5
1.2.3 Top Entry Wiring Sidecar	5
1.2.4 Integrated Accessory Cabinet-Power Distribution	5
1.2.5 Parallel System	5
1.2.6 Monitoring and Communication	5
1.2.7 Additional Output Surge Protection	6
1.3 Battery System	6
1.3.1 Battery Configurations	6
1.3.2 Optional Thermal Sensor	6
1.4 Basic System Configurations	6
1.5 Using This Manual	7
1.6 Conventions Used in This Manual	7
1.7 Symbols, Controls, and Indicators	8
1.8 For More Information	8
1.9 Getting Help	9
1.10 Equipment Registration	9
<b>2 Safety Warnings</b>	<b>11</b>
<b>3 UPS Installation Plan and Unpacking</b>	<b>13</b>
3.1 Creating an Installation Plan	13
3.2 Preparing the Site	13
3.2.1 Environmental and Installation Considerations	13
3.3 UPS System Power Wiring Preparation	33
3.4 External Parallel UPS System Power Wiring Preparation	35
3.5 UPS System Interface Wiring Preparation	50
3.6 Inspecting and Unpacking the UPS Cabinet	51
<b>4 UPS System Installation</b>	<b>55</b>
4.1 Preliminary Installation Information	55
4.2 Unloading the UPS Cabinet from the Pallet	55

# Table of Contents

4.3 Integrated Battery Cabinet Installation .....	60
4.4 External AC Power Wiring Installation .....	60
4.4.1 Standalone UPS or UPS with Top Entry Sidecar (No Breakers) .....	61
4.4.2 UPS with 2-Breaker Sidecar (MBP and MIS) .....	67
4.4.3 UPS with 3-Breaker Sidecar (BIB, MBP and MIS) .....	70
4.4.4 UPS with 4 -Breaker Sidecar (RIB, BIB, MBP and MIS) .....	72
4.5 Battery Power Wiring .....	74
4.6 Installing Interface Connections .....	75
4.6.1 Installing Building Alarm and Relay Contact Connections .....	75
4.6.2 Sidecar MIS and RIB Breaker Monitoring Connections .....	81
4.6.3 Installing Battery Detect Interface Connections .....	83
4.6.4 Installing Battery Shunt Trip and Battery Aux Interface Connections .....	84
4.6.5 Bypass Shunt Trip Connections .....	86
4.6.6 Generator Interface Connections .....	86
4.6.7 External Parallel CAN Control Wiring and Connections .....	87
4.6.8 External Parallel Pull Chain Control Wiring and Connections .....	90
4.6.9 Installing Minislot Interface Connections .....	93
4.7 Installing a REPO Switch .....	94
4.8 Initial Startup .....	97
4.9 Completing the Installation Checklist .....	97
4.10 Installation Checklist .....	98
<b>5 Understanding UPS Operation .....</b>	<b>101</b>
5.1 UPS System Overview .....	101
5.2 Single UPS .....	102
5.2.1 Modes .....	102
5.2.2 Energy Saver System Mode .....	102
5.2.3 Normal Mode .....	103
5.2.4 Bypass Mode .....	104
5.2.5 Battery Mode .....	105
5.3 Single UPS Unit System Online Configurations .....	107
<b>6 UPS Operating Instructions .....</b>	<b>111</b>
6.1 UPS Controls and Indicators .....	111
6.2 Using the Control Panel .....	112
6.2.1 Status Indicators .....	112
6.2.2 System Events .....	113
6.2.3 Using the LCD Touch Screen .....	113
6.2.4 Using the Menu .....	114
6.2.5 Mimic Screen .....	115
6.2.6 Display Menu Operation .....	116
6.2.7 Sign In .....	121

6.2.8 System Controls .....	123
6.3 Single UPS Operation .....	127
6.3.1 Starting the UPS in Double Conversion Mode .....	127
6.3.2 Starting the UPS in Bypass Mode .....	127
6.3.3 Starting the UPS via DC Start Button .....	128
6.3.4 Starting the UPMs .....	129
6.3.5 Starting a Single UPM .....	129
6.3.6 Transfer from Double Conversion to Bypass Mode .....	129
6.3.7 Transfer from Bypass to Double Conversion Mode .....	130
6.3.8 Transfer from ESS Mode to Double Conversion Mode .....	130
6.3.9 Transfer from Double Conversion Mode to ESS Mode .....	130
6.3.10 Transfer from Double Conversion to Bypass Mode and Shut Down UPMs .....	130
6.3.11 Single UPM Shutdown .....	131
6.3.12 Single UPM Restart .....	131
6.3.13 UPS and Critical Load Shutdown .....	131
6.3.14 Charger Control .....	132
6.3.15 Battery Test .....	132
6.3.16 Using the UPS LOAD OFF Command .....	132
6.3.17 Using the Remote Emergency Power-off Switch .....	133
6.4 Multiple External Parallel System Operation .....	134
6.4.1 Starting the Parallel System in Double Conversion Mode .....	134
6.4.2 Starting the Parallel System in Bypass Mode .....	135
6.4.3 Starting the Parallel System UPMs .....	135
6.4.4 Starting a Single UPM .....	136
6.4.5 Transfer from Double Conversion to Bypass Mode .....	136
6.4.6 Transfer from Bypass to Double Conversion Mode .....	136
6.4.7 Transfer from ESS Mode to Double Conversion Mode .....	137
6.4.8 Transfer from Double Conversion Mode to ESS Mode .....	137
6.4.9 Transfer from Double Conversion to Bypass Mode and Shutdown all UPMs .....	137
6.4.10 Single UPM Shutdown .....	138
6.4.11 Single UPM Restart .....	138
6.4.12 Single UPS Shutdown .....	138
6.4.13 Single UPS Restart .....	138
6.4.14 Parallel System and Critical Load Shutdown .....	139
6.4.15 Charger Control .....	139
6.4.16 Battery Test .....	140
6.4.17 Using the LOAD OFF Command .....	140
6.4.18 Using the Remote Emergency Power-off Switch .....	141
<b>7 Communication .....</b>	<b>143</b>
7.1 Minislot Cards .....	143
7.2 Building Alarm Monitoring .....	143

# Table of Contents

7.3 General Purpose Relay Contact .....	144
7.4 PredictPulse Remote Monitoring and Management Service.....	144
7.4.1 PredictPulse Service Features .....	144
7.4.2 Installing PredictPulse.....	145
<b>8 UPS Maintenance.....</b>	<b>147</b>
8.1 Important Safety Instructions .....	147
8.2 Performing Preventive Maintenance .....	147
8.2.1 DAILY Maintenance .....	148
8.2.2 MONTHLY Maintenance .....	148
8.2.3 PERIODIC Maintenance .....	149
8.2.4 ANNUAL Maintenance.....	149
8.2.5 BATTERY Maintenance.....	149
8.3 Installing Batteries .....	149
8.4 Recycling the Used Battery or UPS.....	150
8.5 Maintenance Training .....	150
<b>9 Product Specifications .....</b>	<b>151</b>
9.1 Models.....	151
9.2 Specifications .....	151
9.2.1 UPS Input .....	151
9.2.2 UPS Output .....	151
9.2.3 UPS Environmental .....	152
<b>10 Warranty.....</b>	<b>153</b>



## List of Figures

Figure 1.	Eaton 93PM-L UPS (60 kW, Four-Wire) .....	2
Figure 2.	Eaton 93PM-L UPS (60 kW, Four-Wire) with Top Entry Wiring Sidecar .....	2
Figure 3.	Eaton 93PM-L UPS (60 kW, Four-Wire) with Bypass Sidecar (2, 3 or 4 Breaker SIAC-B) .....	3
Figure 4.	UPS Cabinet Dimensions (Front and Right Side Views).....	18
Figure 5.	UPS Cabinet Dimensions (Top and Bottom Views) .....	19
Figure 6.	UPS Cabinet Rear Floor Mounting Bracket Mounting Dimensions .....	20
Figure 7.	UPS Cabinet Floor Mounting Bracket Dimensions (Top Views).....	21
Figure 8.	UPS with Left or Right-Mounted Top Entry Sidecar Dimensions (Front Views).....	22
Figure 9.	UPS with Left or Right-Mounted Top Entry Sidecar Dimensions (Top and Bottom Views) .....	23
Figure 10.	UPS with Left or Right-Mounted Bypass Sidecar (SIAC-B) Dimensions (Front Views).....	24
Figure 11.	UPS with Left or Right-Mounted Bypass Sidecar (SIAC-B) Dimensions (Top and Bottom Views) .....	25
Figure 12.	UPS Cabinet Center of Gravity .....	26
Figure 13.	UPS with Left or Right-Mounted Top Entry Wiring Sidecar Center of Gravity .....	27
Figure 14.	UPS with Left or Right-Mounted SIAC-B Center of Gravity .....	29
Figure 15.	Remote EPO Switch Dimensions .....	33
Figure 16.	93PM-L External Parallel Wire Length.....	35
Figure 17.	UPS Cabinet as Shipped on Pallet .....	52
Figure 18.	UPS Cabinet with Left or Right-Mounted Top Entry Wiring Sidecar as Shipped on Pallet.....	52
Figure 19.	UPS Cabinet with Left or Right-Mounted Sidecar as Shipped on Pallet.....	53
Figure 20.	Removing the UPS Pallet Skids and Supports .....	56
Figure 21.	Removing the Top Entry Sidecar Pallet Skids and Supports .....	57
Figure 22.	Removing the Bypass Sidecar (SIAC-B) Pallet Skids and Supports .....	57
Figure 23.	Removing the Sidecar Rear Shipping Bracket – UPS with Right-Mounted Sidecar .....	59
Figure 24.	UPS Conduit and Wire Entry Locations .....	62
Figure 25.	UPS with Top Entry Sidecar Conduit and Wire Entry Locations.....	63
Figure 26.	UPS Inter-Cabinet Wiring Access Location.....	64
Figure 27.	Power Terminal Locations.....	65
Figure 28.	Eaton 93PM-L UPS Power Terminal Detail.....	66
Figure 29.	UPS with Bypass Sidecar (SIAC-B) Conduit and Wire Entry Locations.....	68
Figure 30.	Eaton 93PM-L with SIAC-B (2-Breaker) Power Terminal Locations .....	69
Figure 31.	Eaton 93PM-L with SIAC-B (3-Breaker) Power Terminal Locations .....	71
Figure 32.	Eaton 93PM-L with SIAC-B (4-Breaker) Power Terminal Locations .....	73
Figure 33.	93PM-L SIAC-B RIB Terminal Detail .....	74
Figure 34.	Interface Terminal Locations.....	77
Figure 35.	Interface Terminal Detail.....	78
Figure 36.	Bottom Access Interface Wiring Location.....	78
Figure 37.	Wire Tie Anchors .....	79
Figure 38.	Building Alarm Terminal Block Connector Assignments.....	80
Figure 39.	Relay Contact Terminal Block Connector Assignments.....	80

## List of Figures

Figure 40.	Sidecar TB1 and TB2 Terminal Locations .....	82
Figure 41.	Bypass Shunt Trip, Battery Shunt Trip and Detect Terminal Detail .....	85
Figure 42.	External Parallel CAN Connections Between UPSs .....	89
Figure 43.	External Parallel Terminal Block .....	90
Figure 44.	External Parallel Pull Chain Wiring .....	92
Figure 45.	REPO Switch .....	95
Figure 46.	REPO Terminal Block Connector Assignments .....	96
Figure 47.	Normally-Open REPO Switch Wiring .....	96
Figure 48.	Normally-Closed REPO Switch Wiring .....	97
Figure 49.	Main Elements of the UPS System .....	101
Figure 50.	Path of Current Through the UPS in Energy Saver System Mode .....	103
Figure 51.	Path of Current Through the UPS in Normal Mode .....	104
Figure 52.	Path of Current Through the UPS in Bypass Mode .....	105
Figure 53.	Path of Current Through the UPS in Battery Mode .....	106
Figure 54.	Eaton 93PM-L 60 UPS System Oneline .....	108
Figure 55.	Eaton 93PM-L 60 UPS with Top Entry Sidecar System Oneline .....	109
Figure 56.	Eaton 93PM-L 60 UPS with Bypass Sidecar (SIAC-B) System Oneline .....	110
Figure 57.	UPS Controls and Indicators .....	111
Figure 58.	UPS Control Panel .....	112
Figure 59.	Parts of the LCD .....	114
Figure 60.	Main Menu and Mimic Screen .....	115
Figure 61.	Typical Meters Summary Screen .....	117
Figure 62.	Typical Active Events Screen .....	118
Figure 63.	Typical System Log Screen .....	118
Figure 64.	Typical Settings User Screen .....	119
Figure 65.	Typical Information Screen .....	119
Figure 66.	Typical About Screen .....	120
Figure 67.	Typical Settings Configuration 1 Screen .....	120
Figure 68.	Typical Settings Configuration 2 Screen .....	121
Figure 69.	Typical Statistics Screen .....	121
Figure 70.	Sign In Password Screen .....	122
Figure 71.	Sign In Keypad .....	123
Figure 72.	Typical System Control Screen .....	124
Figure 73.	Typical UPS Control Screen .....	125
Figure 74.	Typical UPM Select Screen .....	125
Figure 75.	Typical UPM Control Screen .....	126
Figure 76.	Typical EAA Control Screen .....	126
Figure 77.	DC Start Button Location .....	128
Figure 78.	REPO Operation .....	134
Figure 79.	Optional Minislot Cards .....	143
Figure 80.	Air Filter Location .....	149

## List of Tables

Table 1.	Air Conditioning or Ventilation Requirements During Full Load Operation.....	15
Table 2.	93PM-L 60 kW UPS Cabinet Weights .....	15
Table 3.	93PM-L 60 kW UPS with Top Entry Sidecar Cabinet Weights.....	16
Table 4.	93PM-L 60 kW UPS with SIAC-B Cabinet Weights.....	16
Table 5.	UPS Cabinet Clearances .....	18
Table 6.	UPS – Center of Gravity Dimensions.....	26
Table 7.	UPS with Top Entry Wiring Sidecar - Center of Gravity dimensions.....	28
Table 8.	UPS with Bypass Sidecar (SIAC-B) - Center of Gravity dimensions .....	30
Table 9.	Input/Output Ratings and Wiring Recommendations: 10– 30 kW (208/208).....	36
Table 10.	Input/Output Ratings and Wiring Recommendations: 40–60 kW (208/208).....	38
Table 11.	Input/Output Ratings and Wiring Recommendations: 10–30 kW (220/220).....	40
Table 12.	Input/Output Ratings and Wiring Recommendations: 40–60 kW (220/220).....	42
Table 13.	UPS External Power Cable Terminations .....	44
Table 14.	Supplied External Wiring Terminal Hardware Kit.....	45
Table 15.	Recommended Installation Parts and Tools (Not Supplied by Eaton) .....	45
Table 16.	Power Cable Conduit Recommendations.....	46
Table 17.	Recommended Input and Bypass Circuit Breaker Ratings .....	48
Table 18.	Recommended Output Circuit Breaker Ratings .....	49
Table 19.	Recommended DC Input Battery Disconnect Circuit Breaker Ratings .....	49
Table 20.	List of Interface and Control Wiring Connection Topics .....	75
Table 21.	Building Alarm Connections and Wire Terminations .....	79
Table 22.	Relay Contact Connections and Wire Terminations .....	80
Table 23.	Sidecar MIS and RIB Breaker Monitoring Connection and Wire Terminations .....	81
Table 24.	Shunt Trip and Battery Detect Connections and Wire Terminations .....	85
Table 25.	External Parallel CAN and Pull Chain Connections.....	88
Table 26.	External Parallel CAN and Pull Chain Terminal Block Terminations.....	89
Table 27.	Normally-Open REPO Connections and Wire Terminations.....	96
Table 28.	Normally-Closed REPO Connections and Wire Terminations.....	97
Table 29.	Status Indicators .....	113
Table 30.	Display Function Menu Map .....	115
Table 31.	Display Menu Operation .....	116
Table 32.	Controls Menu Operation .....	123
Table 33.	Typical System Status Messages.....	124
Table 34.	IRC-MS Default Triggers .....	143

List of Tables

# Chapter 1 Introduction

The Eaton® 93PM-L 60 kW, Four-Wire uninterruptible power supply (UPS) is a true online, continuous-duty, transformerless, double-conversion, solid-state, three-phase system, providing conditioned and uninterruptible AC power to protect the customer's load from power failures.


The Eaton 93PM-L UPS online power protection system is used to prevent loss of valuable electronic information, minimize equipment downtime, and minimize the adverse effect on production equipment due to unexpected power problems.

The Eaton 93PM-L UPS continually monitors incoming electrical power and removes the surges, spikes, sags, and other irregularities that are inherent in commercial utility power. Working with a building's electrical system, the UPS system supplies clean, consistent power that sensitive electronic equipment requires for reliable operation. During brownouts, blackouts, and other power interruptions, batteries provide emergency power to safeguard operation.

The Eaton 93PM-L UPS is available with up to three Uninterruptible Power Modules (UPMs) integrated in one cabinet. Each UPM is rated for a maximum of 20 kW. The system maximum rating is 60 kW. To deliver greater reliability, a UPS with two or more UPMs can provide N+1 redundancy up to a maximum of 40 kW. Should one UPM become unavailable or require servicing, the remaining UPMs supply the load instead of transferring to bypass.

The UPS is housed in a single free-standing cabinet, with safety shields behind the door for hazardous voltage protection. Power wiring is installed through the bottom of the cabinet with an optional sidecar available for top entry wiring. [Figure 1](#) shows the Eaton 93PM-L UPS, [Figure 2](#) shows the Eaton 93PM-L UPS with a left or right-mounted Top Entry Wiring Sidecar, and [Figure 3](#) shows the Eaton 93PM-L UPS with a left or right-mounted Bypass Sidecar (SIAC-B).

---

**NOTE**  Startup and operational checks must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on the product's resources page become void. See [Chapter 10 Warranty](#) for details. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (a minimum two-week notice is required) to reserve a preferred startup date.

---


## 1.1 UPS Standard Features

The UPS has many standard features that provide cost-effective and consistently reliable power protection. The descriptions in this section provide a brief overview of the UPS standard features.


### 1.1.1 Installation Features

- Line-up-and-match or standalone configurations
- Power wiring can be routed through the bottom of the cabinet in standalone configurations or alternately through the top when configured with an optional accessory sidecar
- Battery wiring can be run internally through the left or right sides of the UPS cabinet in line-up-and-match configurations
- Easily accessible mechanical terminals located at the bottom front of the cabinet reduce installation time
- Control wiring can be routed through the top or bottom of the UPS cabinet, or through the left or right sides of the UPS cabinet in line-up-and-match configurations
- Built-in casters for easy cabinet placement
- Cabinet bolt holes are provided for permanently mounting the UPS using optional front and back or left and right side floor mounting bracket kits


**Figure 1. Eaton 93PM-L UPS (60 kW, Four-Wire)**



**Figure 2. Eaton 93PM-L UPS (60 kW, Four-Wire) with Top Entry Wiring Sidecar**



**Figure 3. Eaton 93PM-L UPS (60 kW, Four-Wire) with Bypass Sidecar (2, 3 or 4 Breaker SIAC-B)**



### 1.1.2 Control Panel

The control panel, located on the front of the UPS, contains a color liquid crystal touch screen display (LCD) and a horizontal row of LED indicators to control the operation of the UPS and to display the status of the UPS system. See **Chapter 6 UPS Operating Instructions**, for additional information.

### 1.1.3 Customer Interface

- **Building Alarm Monitoring** – Up to five inputs in the UPS are available to connect the facility's alarm system contacts. Some system configurations may limit the number of inputs available. The UPS uses these inputs to monitor the building alarms in addition to the UPS status.
- **Alarm Contact** – One alarm contact is provided for connection to equipment at the facility, such as a light, an audible alarm, or a computer terminal. The equipment connected to this contact alerts you to a UPS alarm.
- **Minislot Communication Bays** – Four communication bays are standard equipment. One to four optional Minislot® connectivity cards can be installed in the UPS at any time. Minislot cards are quickly installed at the front of the UPS and are hot-pluggable.

For additional information on these topics, see [Chapter 7 Communication](#).

### 1.1.4 Energy Saver System Mode

The 93PM-L Series UPS offers an Energy Saver System (ESS) mode that maximizes efficiency by eliminating unnecessary power conversion when the commercial power source is within acceptable voltage and frequency limits. In this mode, the UPS is actively monitoring the critical bus and instantly and seamlessly transitions to double-conversion mode (inverter online) if a commercial electrical power brownout, blackout, overvoltage, undervoltage, or out-of-tolerance frequency condition occurs. See **Chapter 6 UPS Operating Instructions**, for additional information.

## 1.1.5 Internal Redundancy

To deliver greater reliability, the Eaton 93PM-L UPS can be configured for internal redundancy. When configured, the UPS automatically becomes redundant if the load is at or below the capacity of the UPMs minus the capacity of one UPM. Under normal conditions the UPMs in the UPS share the load equally. If one or more UPMs becomes unavailable and the load is at or below the capacity of remaining UPMs, the remaining UPMs supply the load instead of transferring to bypass.

## 1.1.6 Advanced Battery Management

Advanced Battery Management (ABM) technology uses sophisticated sensing circuitry and a three-stage charger. The charger is a high-frequency, IGBT-based power conversion stage that extends the useful service life of UPS batteries by isolating the battery from the electrical environment, except for periodic charging or reserve mode operation. ABM also protects batteries from damage due to high current charging and inverter ripple currents. Charging at high currents can overheat and damage batteries.

ABM extends battery life by keeping the batteries charged and performing periodic battery testing. The battery test checks the batteries by transferring to battery mode. During the test the battery voltage is constantly monitored to determine Battery Health. ABM is intended for VRLA style batteries.

An ABM charging cycle starts with the charger driving the battery voltage at maximum current limit, to a battery charge level of 2.30volts/cell. The time it takes for the voltage to reach the battery charge level is saved as the battery charge time. If the battery charge time exceeds 24 hours, an alarm sounds.

When the battery reaches the float level, the battery is charged at the float level for 48 hours. Due to charger capability, some battery cabinet configurations extend float level to 72 hours. Twenty-four hours into the float period, a series of battery tests are performed to check the battery health. The float level charge continues after a successful test.

After initial startup, the battery run time on the front panel display indicates two minutes. After the 24-hour float charging period and automated battery testing, the actual battery run time is determined and the actual battery run time is displayed.

After the float period is completed, the charger is disconnected and the batteries are allowed to rest for up to 672 hours (28 days) maximum rest time. If the battery voltage falls below the opportunity charge level of 2.1V/cell during the first 240 hours (10 days) of the rest period, an alarm sounds.

An ABM charge cycle is initiated whenever one of these four conditions occurs since the last charge cycle:

- The batteries have rested over the maximum rest time of 672 hours.
- Accumulated discharge time is over a maximum battery discharge time of 20 seconds.
- Battery voltage is under the opportunity charge level of 2.1 volts/cell and the cabinet has been in rest mode for longer than 240 hours.
- A Battery Test command has been initiated.

## 1.2 Options and Accessories

Contact an Eaton sales representative for information about the following options.

### 1.2.1 Integrated Battery Cabinet

Battery backup protection with additional runtime can be provided by equipping the UPS system with up to four Integrated Battery Cabinets (IBCs) containing sealed lead-acid, maintenance-free batteries. The IBCs are housed in single, free-standing cabinets designed for line-up-and-match installation, but may be installed separate from the UPS cabinet. An external battery disconnect switch or tie point must be used when three or four IBCs are located separate from the UPS cabinet. The IBCs may be installed on either the right or left side of the UPS cabinet. The recommended installation location for adjacent battery cabinets is on the right side of the UPS cabinet.



### 1.2.2 Sidecar Integrated Accessory Cabinet-Bypass

A Sidecar Integrated Accessory Cabinet-Bypass (SIAC-B) provides maintenance bypass functions. The SIAC-B is available in two, three, or four breaker configurations enabling power to completely bypass the UPS. The UPS can then be safely serviced or replaced without interrupting power to critical systems. Our manufacturing facility installs the SIAC-B on either the right or left side of the UPS cabinet based on the order requirements. The SIAC-B can also be used for top entry wiring access.

### 1.2.3 Top Entry Wiring Sidecar

If required, a sidecar is available for top entry power wiring. The sidecar performs the function of a wireway routing the wires to the terminals mounted at the bottom of the UPS cabinet. The sidecar can be installed on the left or right side of the UPS cabinet.

### 1.2.4 Integrated Accessory Cabinet-Power Distribution

The Integrated Accessory Cabinet-Power Distribution (IAC-PD) provides power distribution options for servers, racks, and other equipment via distribution panelboards, or distributes power to larger loads via distribution subfeed circuit breakers. The distribution options are customer configurable, enabling adaptation and expansion without costly electrical rework. The IAC-PD may be installed in a line-and-match or standalone configuration.

The IAC-PD may be installed on either the right or left side of the UPS cabinet.

### 1.2.5 Parallel System



#### NOTE

All UPSs in a parallel system must have the same battery configuration. Each UPS requires a separate battery cabinet.

---

A parallel UPS system with multiple UPSs with a maximum combined wattage of 400 kW can be installed to provide a parallel capacity and/or redundant system. This load sharing system provides more capacity than a single UPS, and can provide redundancy, depending on the load and configuration. In addition, when one UPS is taken out of service for maintenance or is not operating properly, a redundant UPS continues to supply uninterrupted power to the critical load. A built-in Controller Area Network (CAN) provides connectivity for system metering and operational mode control. The parallel system consists of two to four UPSs, and a Wall Mounted Panelboard acting as a tie point and to control the output.

### 1.2.6 Monitoring and Communication

**Minislot Cards** – Optional Minislot cards support several protocols, such as SNMP, SMTP, HTTP, Modbus®, and TCP/IP. See [Chapter 7 Communication](#), for additional information on monitoring and communication features.

**Remote Monitoring Device (RMD)** – An optional RMD contains a touch screen status display and a local audible alarm, allowing monitoring of the operational status and alarm condition of the UPS from virtually any location within the facility, up to 300 feet from the UPS.

Refer to the ***Eaton Remote Monitoring Device (RMD) Installation and Operation Manual***, listed in paragraph [1.8 For More Information](#), for additional information.

**PredictPulse™ Remote Monitoring and Management Service** – PredictPulse is a subscription monitoring and management service from Eaton that collects and analyzes data from connected power infrastructure devices, providing us with the insight needed to make recommendations and take action on your behalf. It's also powered by CA Technologies, bringing together the best in hardware and software. Like a second set of eyes on your power infrastructure, PredictPulse provides 24/7 remote monitoring of alarms and system performance (load, temperature/humidity, battery health, energy savings and service level) to reduce downtime risk and expedite repairs. PredictPulse also shares real-time status and trend information via an online dashboard and smartphone mobile app (Apple and Android), giving subscribers insights about past and current performance, a list of all active alarms, and asset management data (i.e., battery date codes, last and next scheduled service dates, firmware versions). The service notifies customers of critical alarms, supports remote diagnostics, and facilitates smart dispatch of technicians. PredictPulse requires a Power Xpert® Gateway

Minislot (PXGMS) connectivity card in an Minislot communication bay and an Environmental Monitoring Probe (EMP) for battery temperature/humidity monitoring. See [Chapter 7 Communication](#), for additional information.

### 1.2.7 Additional Output Surge Protection

The Eaton 93PM-L UPS complies with ANSI 62.41 for line surges. However, if added security is required an additional Surge Protection Device (SPD) can be installed. For this application, a 208V Delta Style SPD Type 1 or Type 2 installed on the load side is recommended. The SPD must meet the Maximum Continuous Operating Voltage (MCOV) for a 208V Delta Style SPD. Eaton offers a variety of SPD solutions including the Eaton SPD Series with various kA ratings options.

## 1.3 Battery System

The battery system provides emergency short-term backup power to safeguard operation during brownouts, blackouts, and other power interruptions.

### 1.3.1 Battery Configurations

The 93PM-L (60 kW) UPS battery system can be internal to the UPS cabinet, an external Integrated Battery Cabinet/s (IBC), or a combination of both. The external IBCs are connected in parallel with the internal batteries to provide extended run time. The battery system is equipped with sealed lead-acid, maintenance-free batteries.

An external battery disconnect switch or tie point must be used when battery systems are located separate from the UPS cabinet and wiring exceeds the number of battery terminals available.

A supplemental 48 Vdc shunt trip signal for the battery disconnect device is provided by the UPS, but is not required for normal operation.

### 1.3.2 Optional Thermal Sensor

Thermal runaway protection for VRLA batteries can be provided by adding an optional thermal sensor to the internal battery section or external battery cabinet.

The sensor is wired to the thermal sensor terminal and programmed to turn the charger off when a trip signal is received.

The thermal sensor will maintain the trip state until it is reset by service. Service should be called to inspect the batteries and reset the sensor in case of such an event.

## 1.4 Basic System Configurations

The following basic UPS system configurations are possible:

- Single UPS (20–60 kW) with one to four external battery cabinets
- Single UPS (20–60 kW) with one to four external battery cabinets and accessory cabinets
- Multiple UPSs (20–60 kW to a maximum combined rating of 400 kW) with one to four standard external battery cabinets for each UPS
- Multiple UPSs (20–60 kW to a maximum combined rating of 400 kW) with one to four standard external battery cabinets for each UPS and accessory cabinets

The UPS system configuration can be enhanced by adding optional accessories such as a Remote Emergency Power-off (REPO) control or Minislot communication cards.

## 1.5 Using This Manual

This manual describes how to install and operate the Eaton 93PM-L UPS. Read and understand the procedures described in this manual to ensure trouble-free installation and operation. In particular, be thoroughly familiar with the REPO procedure or the LOAD OFF procedure, see **Chapter 6 UPS Operating Instructions**.

The information in this manual is divided into sections and chapters. The system, options, and accessories being installed dictate which parts of this manual should be read. At a minimum, **Chapter 1 Introduction** through **Chapter 4 UPS System Installation** and **Chapter 6 UPS Operating Instructions** should be examined.

Read through each procedure before beginning the procedure. Perform only those procedures that apply to the UPS system being installed or operated.

## 1.6 Conventions Used in This Manual

This manual uses these type conventions:

- **Bold type** highlights important concepts in discussions, key terms in procedures, and menu options, or represents a command or option that you type or enter at a prompt.
- *Italic type* highlights notes and new terms where they are defined.
- `Screen type` represents information that appears on the screen or LCD.

Icon	Description
Note	Information notes call attention to important features or instructions.
[Keys]	Brackets are used when referring to a specific key, such as [Enter] or [Ctrl].

In this manual, the term UPS refers only to the UPS cabinet and its internal elements. The term UPS system refers to the entire power protection system – the UPS cabinet, an external battery system, and options or accessories installed.

The term line-up-and-match refers to accessory cabinets that are physically located adjacent to the UPS. The term standalone refers to accessory cabinets that are located separate from the UPS.

Left and right side notations are referenced standing in front of the cabinet.

## 1.7 Symbols, Controls, and Indicators

The following are examples of symbols used on the UPS or accessories to alert you to important information:



**RISK OF ELECTRIC SHOCK** - Observe the warning associated with the risk of electric shock symbol.



**CAUTION: REFER TO OPERATOR'S MANUAL** - Refer to your operator's manual for additional information, such as important operating and maintenance instructions.



This symbol indicates that you should not discard the UPS or the UPS batteries in the trash. This product contains sealed, lead-acid batteries and must be disposed of properly. For more information, contact your local recycling/reuse or hazardous waste center.



This symbol indicates that you should not discard waste electrical or electronic equipment (WEEE) in the trash. For proper disposal, contact your local recycling/reuse or hazardous waste center.

## 1.8 For More Information

Refer to the ***Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded***, or the ***Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate*** for the following additional information:

- Installation instructions, including site preparation, planning for installation, wiring and safety information, and detailed illustrations of cabinets with dimensional and connection point drawings

Refer to the ***Eaton 93PM-L Sidecar Integrated Accessory Cabinet (60 kW Top Entry Wiring Sidecar, 60 kW SIAC-B, 120 kW Top Entry Wiring Sidecar, and 120 kW SIAC-B) Installation and Operation Manual*** for the following additional information:

- Installation instructions, including site preparation, planning for installation, wiring and safety information, and detailed illustrations of cabinets with dimensional and connection point drawings
- Operation, including breakers, standard features and optional accessories, procedures for using the bypass functions, and information about maintenance

Refer to the ***Eaton 93PM Integrated Accessory Cabinet-Power Distribution (208V 4-Wire IAC-PD, 480V 3-Wire IAC-PD, 480V 4-Wire IAC-PD) Installation and Operation Manual*** for the following additional information:

- Installation instructions, including site preparation, planning for installation, wiring and safety information, and detailed illustrations of cabinets with dimensional and connection point drawings
- Operation, including breakers, standard features and optional accessories, procedures for using the bypass functions, and information about maintenance

Refer to the ***Eaton Remote Monitoring Device (RMD) Installation and Operation Manual*** for additional installation and operating instructions.

- Visit [www.eaton.com/powerquality](http://www.eaton.com/powerquality) or contact an Eaton service representative for information on how to obtain copies of these manuals.

## 1.9 Getting Help

If help is needed with any of the following:

- Scheduling initial startup
- Regional locations and telephone numbers
- A question about any of the information in this manual
- A question this manual does not answer

Please call the Customer Reliability Center at:

United States: **1-800-843-9433**  
Canada: **1-800-461-9166 ext 260**  
All other countries: **Call your local service representative**

Please use the following e-mail address for manual comments, suggestions, or to report an error in this manual:

**E-ESSDocumentation@eaton.com**

## 1.10 Equipment Registration

Please visit [www.eaton.com/pq/register](http://www.eaton.com/pq/register) to register your new Eaton UPS / Eaton UPS Accessory.

**Model Number:**

---

**Serial Number:**

---



## Chapter 2 Safety Warnings

---

### IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

---

This manual contains important instructions that should be followed during installation and maintenance of the UPS and batteries. Read all instructions before operating the equipment and save this manual for future reference.

The UPS is designed for industrial or computer room applications, and contains safety shields behind the door and front panels. However, the UPS is a sophisticated power system and should be handled with appropriate care.



#### DANGER

This UPS contains LETHAL VOLTAGES. All repairs and service should be performed by AUTHORIZED SERVICE PERSONNEL ONLY. There are NO USER SERVICEABLE PARTS inside the UPS.



#### WARNING

- The UPS is powered by its own energy source (batteries). The output terminals may carry live voltage even when the UPS is disconnected from an AC source.
  - To reduce the risk of fire or electric shock, install this UPS in a temperature and humidity controlled, indoor environment, free of conductive contaminants. Ambient temperature must not exceed 40°C (104°F). Do not operate near water or excessive humidity (95% maximum). The system is not intended for outdoor use.
  - As a result of the connected loads high leakage current is possible. Connection to earth ground is required for safety and proper product operation. Do not check UPS operation by any action that includes removal of the earth (ground) connection with loads attached.
  - Emergency Power Off (EPO) and Remote Emergency Power Off (REPO) functionality is disabled for UPS systems configured for UL 924 auxiliary lighting. To remove power from the system a LOAD OFF command must be given using the front panel controls and all breakers opened. Review **Chapter 6 UPS Operating Instructions**, for details.
  - Ensure all power is disconnected before performing installation or service.
  - Batteries can present a risk of electrical shock or burn from high short-circuit current. The following precautions should be observed: 1) Remove watches, rings, or other metal objects; 2) Use tools with insulated handles; 3) Do not lay tools or metal parts on top of batteries; 4) Wear voltage rated gloves and electrical hazard footwear.
  - ELECTRIC ENERGY HAZARD. Do not attempt to alter any UPS or battery wiring or connectors. Attempting to alter wiring can cause injury.
  - Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.
-

---

 **CAUTION**

---

- Installation or servicing should be performed by qualified service personnel knowledgeable of UPS and battery systems, and required precautions. Keep unauthorized personnel away from equipment. Consider all warnings, cautions, and notes before installing or servicing equipment. **DO NOT DISCONNECT** the batteries while the UPS is in Battery mode.
- Replace batteries with the same number and type of batteries as originally installed with the UPS.
- Disconnect the charging source prior to connecting or disconnecting terminals.
- Determine if the battery is inadvertently grounded. If it is, remove the source of the ground. Contacting any part of a grounded battery can cause a risk of electric shock. An electric shock is less likely if you disconnect the grounding connection before you work on the batteries.
- Proper disposal of batteries is required. Refer to local codes for disposal requirements.
- Do not dispose of batteries in a fire. Batteries may explode when exposed to flame.
- Keep the UPS door closed and front panels installed to ensure proper cooling airflow and to protect personnel from dangerous voltages inside the unit.
- Do not install or operate the UPS system close to gas or electric heat sources.
- Lead-acid batteries can present a risk of fire because they generate hydrogen gas. Do not smoke when near batteries. Do not cause flame or spark in battery area. Discharge static electricity from body before touching batteries by first touching a grounded metal surface.
- The operating environment should be maintained within the parameters stated in this manual.
- Keep surroundings uncluttered, clean, and free from excess moisture.
- Observe all DANGER, CAUTION, and WARNING notices affixed to the inside and outside of the equipment.

---

 **AVERTISSEMENT!**

---

- Les batteries peuvent présenter un risque de décharge électrique ou de brûlure par des courts-circuits de haute intensité. Prendre les précautions nécessaires.
- Pour le remplacement, utiliser le même nombre et modèle des batteries.

---

 **ATTENTION!**

---

- Une mise au rebut réglementaire des batteries est obligatoire. Consulter les règlements en vigueur dans votre localité.
  - Ne jamais jeter les batteries au feu. L'exposition aux flammes risque de les faire exploser.
  - Les accumulateurs au plomb-acide peuvent représenter un risque d'incendie, car ils génèrent de l'hydrogène gazeux. Ne pas fumer près des accumulateurs. Ne pas produire de flamme ou d'étincelle dans la zone de l'accumulateur. Dissiper l'électricité statique de votre corps en touchant une surface reliée à la terre avant de toucher les accumulateurs.
-



## Chapter 3 UPS Installation Plan and Unpacking

**Use the following basic sequence of steps to install the UPS:**

1. Create an installation plan for the UPS system.
2. Prepare your site for the UPS system.
3. Inspect and unpack the UPS cabinet.
4. Unload and install the UPS cabinet, and wire the system.
5. Complete the Installation Checklist.
6. Have authorized service personnel perform preliminary operational checks and start up the system.



---

**NOTE**

Startup and operational checks must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on the product's resources page become void. See [93PM Warranty](#) for details. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (a minimum two-week notice is required) to reserve a preferred startup date.

---

### 3.1 Creating an Installation Plan

Before installing the UPS system, read and understand how this manual applies to the system being installed. Use this chapter's procedures and illustrations and those in **Chapter 4 UPS System Installation** to create a logical plan for installing the system.

### 3.2 Preparing the Site

For the UPS system to operate at peak efficiency, the installation site should meet the environmental parameters outlined in this manual. The operating environment must meet the weight, clearance, and environmental requirements specified.

#### 3.2.1 Environmental and Installation Considerations

The UPS system installation must meet the following guidelines:

- The system must be installed on a level floor suitable for computer or electronic equipment.
- The system must be operated at an altitude no higher than 1500m (5000 ft) without derating. For additional assistance with high altitude operation, contact an Eaton service representative (see paragraph [1.9 Getting Help](#)).
- The system must be installed in a temperature and humidity controlled indoor area free of conductive contaminants.



**CAUTION**

Do not expose the UPS to overly aggressive environments, like salt mist or corrosive gases. High relative humidity accelerates the effects of contaminants. The UPS should be installed in a G1 environment (based on ANSI/ISA S-71.04 classifications). If the UPS is used in a more aggressive environment, it can cause reduced product life and possibly early failure. If the installation location does not meet the recommended environment, contact Eaton service representative for further information (see paragraph [1.9 Getting Help](#)).

---

- The environmental requirements specified below are for the air at the intake ports of the 93PM UPS, and are the maximum, not to exceed, ratings.
  - There shall be at least a 1.8°F (1.0°C) difference between the dry bulb temperature and the wet bulb temperature, at all times, to maintain a non-condensing environment.

- The maximum rate of temperature change shall be limited to 3°F over 5 minutes (36°F/hour), based on the ASHRAE Standard 90.1-2013.
- The newer, more energy efficient data center cooling methods (such as air side economization) can create much wider ranges of temperature and Relative Humidity (RH) in the UPS room and/or data center. There are two aspects of this increased operating environment that can, if ignored, create issues.
  - One is the creation of microclimates, which are persistent variations of temperature and/or RH within a single room. For example one side of the room is always cooler than the other side, no matter the actual temperature.
  - The other aspect is the rate of change of temperature and/or RH, which can occur during transitions within the cooling system. Examples: changing the mixture ratio of inside versus outside air, or external changes in the outside air when going from night to day, and back to night.
  - When ignored, either one of these aspects can create an undesirable microclimate at the UPS location. If the environment created by this microclimate exceeds the UPS operating specification, the UPS reliability, over time, will be reduced. These same environmental extremes will also create reliability concerns for any servers that are exposed to them.

Failure to follow guidelines may void your warranty.

The basic environmental requirements for operation of the UPS are:

- Ambient Temperature Range: 5–40°C (41–104°F)
- Recommended Operating Range: 5–40°C (41–104°F)
- Maximum Relative Humidity: 5–95%, noncondensing

---

 **CAUTION**

---

If battery systems are located in the same room as the UPS, the battery manufacturer's environmental requirements should be followed if they are more stringent than the UPS requirements. Operating temperatures above the recommended range will result in decreased battery life and performance, and may reduce or void the battery warranty.

---

The UPS ventilation requirements are shown in [Table 1](#). To allow for future power upgrades, Eaton recommends using air conditioning or ventilation sized for the fully rated UPS kW frame size installed instead of the derated kW ordered. Sizing the site cooling infrastructure to be capable of cooling the maximum kW frame size will allow a full power rating upgrade without having to modify the infrastructure.

**Table 1. Air Conditioning or Ventilation Requirements During Full Load Operation**

Model	UPS Rating	Max Heat Dissipation at 100% Load		Minimum Required Cooling Air Flow
		KW (BTU/Hr)		
Eaton 93PM-L 60-1 Eaton 93PM-L 60-2 (N+1)	10 kW	.90 (3063)		130 liter/sec (275 cfm) 212 liter/sec (450 cfm)
Eaton 93PM-L 60-1 Eaton 93PM-L 60-2 (N+1)	20 kW	1.80 (6125)		130 liter/sec (275 cfm) 212 liter/sec (450 cfm)
Eaton 93PM-L 60-2 Eaton 93PM-L 60-3 (N+1)	30 kW	2.69 (9188)		212 liter/sec (450 cfm) 295 liter/sec (625 cfm)
Eaton 93PM-L 60-2 Eaton 93PM-L 60-3 (N+1)	40 kW	3.59 (12250)		212 liter/sec (450 cfm) 295 liter/sec (625 cfm)
Eaton 93PM-L 60-3	50 kW	4.49 (15313)		295 liter/sec (625 cfm)
Eaton 93PM-L 60-3	60 kW	5.39 (18375)		295 liter/sec (625 cfm)

The UPS equipment operating environment must meet the weight requirements shown in [Table 2](#) through [Table 4](#) and the size requirements shown in [Figure 4](#) through [Figure 15](#). Dimensions are in millimeters (inches).

**Table 2. 93PM-L 60 kW UPS Cabinet Weights**

Model	Number of UPMs	Number of Battery Strings	Weight kg (lb)		
			Shipping	Installed	Point Loading
Eaton 93PM-L 60 kW UPS	1 UPM Installed	0 Battery Strings	290 (637)	259 (570)	4 at 65 (143)
		2 Battery Strings	515 (1132)	484 (1065)	4 at 121 (266)
		3 Battery Strings	604 (1327)	573 (1260)	4 at 143 (315)
		4 Battery Strings	692 (1522)	661 (1455)	4 at 165 (364)
	2 UPMs Installed	0 Battery Strings	321 (706)	290 (639)	4 at 73 (160)
		(1+1), 2 Battery Strings	546 (1396)	515 (1134)	4 at 129 (284)
		3 Battery Strings	635 (1396)	604 (1329)	4 at 151 (332)
		4 Battery Strings	724 (1591)	693 (1524)	4 at 173 (381)
	3 UPMs Installed	0 Battery Strings	353 (775)	322 (708)	4 at 81 (177)
		(2+1), 3 Battery Strings	666 (1465)	635 (1398)	4 at 159 (350)
		4 Battery Strings	755 (1660)	724 (1593)	4 at 181 (398)

**Table 3. 93PM-L 60 kW UPS with Top Entry Sidecar Cabinet Weights**

Model	Number of UPMs	Number of Battery Strings	Weight kg (lb)		
			Shipping	Installed	Point Loading
Eaton 93PM-L 60 kW UPS with Left or Right-Mounted Top Entry Sidecar (No Breakers)	1 UPM Installed	0 Battery Strings	368 (809)	337 (742)	6 at 56 (124)
		2 Battery Strings	593 (1304)	562 (1237)	6 at 94 (206)
		3 Battery Strings	682 (1499)	651 (1432)	6 at 109 (239)
		4 Battery Strings	771 (1694)	740 (1627)	6 at 123 (271)
	2 UPMs Installed	0 Battery Strings	400 (878)	369 (811)	6 at 62 (135)
		(1+1), 2 Battery Strings	625 (1373)	594 (1306)	6 at 99 (218)
		3 Battery Strings	713 (1568)	682 (1501)	6 at 114 (250)
		4 Battery Strings	802 (1763)	771 (1696)	6 at 129 (283)
	3 UPMs Installed	0 Battery Strings	431 (947)	400 (880)	6 at 67 (147)
		(2+1), 3 Battery Strings	745 (1637)	714 (1570)	6 at 119 (262)
		4 Battery Strings	833 (1832)	802 (1765)	6 at 134 (294)

**Table 4. 93PM-L 60 kW UPS with SIAC-B Cabinet Weights**

Model	Number of UPMs	Number of Battery Strings	Weight kg (lb)		
			Shipping	Installed	Point Loading
Eaton 93PM-L 60 kW UPS with Left or Right-Mounted Sidecar (2 Breakers)	1 UPM Installed	0 Battery Strings	436 (959)	405 (892)	6 at 68 (149)
		2 Battery Strings	661 (1454)	630 (1387)	6 at 105 (231)
		3 Battery Strings	750 (1649)	719 (1582)	6 at 120 (264)
		4 Battery Strings	839 (1844)	808 (1777)	6 at 135 (296)
	2 UPMs Installed	0 Battery Strings	468 (1028)	437 (961)	6 at 73 (160)
		(1+1), 2 Battery Strings	693 (1523)	662 (1456)	6 at 110 (243)
		3 Battery Strings	781 (1718)	750 (1651)	6 at 125 (275)
		4 Battery Strings	870 (1913)	839 (1846)	6 at 140 (308)
	3 UPMs Installed	0 Battery Strings	499 (1097)	468 (1030)	6 at 78 (172)
		(2+1), 3 Battery Strings	813 (1787)	782 (1720)	6 at 130 (287)
		4 Battery Strings	901 (1982)	870 (1915)	6 at 145 (319)

**Table 4. 93PM-L 60 kW UPS with SIAC-B Cabinet Weights (Continued)**


Model	Number of UPMs	Number of Battery Strings	Weight kg (lb)		
			Shipping	Installed	Point Loading
Eaton 93PM-L 60 kW UPS with Left or Right-Mounted Sidecar (3 Breakers)	1 UPM Installed	0 Battery Strings	456 (1001)	425 (934)	6 at 71 (156)
		2 Battery Strings	681 (1496)	650 (1429)	6 at 108 (238)
		3 Battery Strings	769 (1691)	738 (1624)	6 at 123 (271)
		4 Battery Strings	858 (1886)	827 (1819)	6 at 138 (303)
	2 UPMs Installed	0 Battery Strings	487 (1070)	456 (1003)	6 at 76 (167)
		(1+1), 2 Battery Strings	712 (1565)	681 (1498)	6 at 114 (250)
		3 Battery Strings	801 (1760)	770 (1693)	6 at 128 (282)
		4 Battery Strings	889 (1955)	858 (1888)	6 at 143 (315)
	3 UPMs Installed	0 Battery Strings	518 (1139)	487 (1072)	6 at 81 (179)
		(2+1), 3 Battery Strings	832 (1829)	801 (1762)	6 at 134 (294)
		4 Battery Strings	921 (2024)	890 (1957)	6 at 148 (326)
		1 UPM Installed	0 Battery Strings	471 (1036)	440 (969)
2 Battery Strings	696 (1531)		665 (1464)	6 at 111 (244)	
3 Battery Strings	785 (1726)		754 (1659)	6 at 126 (277)	
4 Battery Strings	874 (1921)		843 (1854)	6 at 141 (309)	
Eaton 93PM-L 60 kW UPS with Left or Right-Mounted Sidecar (4 Breakers)	2 UPMs Installed	0 Battery Strings	503 (1105)	472 (1038)	6 at 79 (173)
		(1+1), 2 Battery Strings	728 (1600)	697 (1533)	6 at 116 (256)
		3 Battery Strings	816 (1795)	785 (1728)	6 at 131 (288)
		4 Battery Strings	905 (1990)	874 (1923)	6 at 146 (321)
	3 UPMs Installed	0 Battery Strings	534 (1174)	503 (1107)	6 at 84 (185)
		(2+1), 3 Battery Strings	848 (1864)	817 (1797)	6 at 136 (300)
		4 Battery Strings	936 (2059)	905 (1992)	6 at 151 (332)

The UPS cabinet uses forced air cooling to regulate internal component temperature. Air inlets are in the front of the cabinet and outlets are on top or in the back of the cabinet. Allow clearance in front of and on top or in back of the cabinet for proper air circulation. The clearances required around the UPS cabinet are shown in the following table.

**Table 5. UPS Cabinet Clearances**


<b>From Front of Cabinet</b>	914 mm (36") working space
<b>From Top of Cabinet with Top Exhaust</b>	457 mm (18") minimum clearance for ventilation
<b>From Top of Cabinet with Rear Exhaust</b>	457 mm (18")
<b>From Back of Cabinet with Rear Exhaust</b>	457 mm (18") minimum clearance for ventilation
<b>From Back of Cabinet with Top Exhaust</b>	None Required
<b>From Right Side of Cabinet</b>	None Required
<b>From Left Side of Cabinet</b>	None Required

**Figure 4. UPS Cabinet Dimensions (Front and Right Side Views)**




Dimensions are in millimeters [inches]

**Figure 5. UPS Cabinet Dimensions (Top and Bottom Views)**



Dimensions are in millimeters [inches]

**Figure 6. UPS Cabinet Rear Floor Mounting Bracket Mounting Dimensions**




**NOTE**


The UPS Front Floor Mounting Bracket's mounting dimensions are identical to the Rear Floor Mounting Bracket dimensions.



**Figure 7. UPS Cabinet Floor Mounting Bracket Dimensions (Top Views)**




**Figure 8. UPS with Left or Right-Mounted Top Entry Sidecar Dimensions (Front Views)**




Dimensions are in millimeters [inches]

**Figure 9. UPS with Left or Right-Mounted Top Entry Sidecar Dimensions (Top and Bottom Views)**




Dimensions are in millimeters (inches)

**Figure 10. UPS with Left or Right-Mounted Bypass Sidecar (SIAC-B) Dimensions (Front Views)**




Dimensions are in millimeters [inches]

**Figure 11. UPS with Left or Right-Mounted Bypass Sidecar (SIAC-B) Dimensions (Top and Bottom Views)**



Dimensions are in millimeters (inches)

**Figure 12. UPS Cabinet Center of Gravity**




**Table 6. UPS – Center of Gravity Dimensions**


Model	Weight and Center of Gravity		Dimensions mm [in] See <a href="#">Figure 12</a> .			Weight kg [lb]
	Number of UPMs	Number of Battery Strings	A	B	C	
Eaton 93PM-L 60 kW UPS	1 UPM Installed	0 Battery Strings	974 [38.3]	545 [21.5]	280 [11]	259 (570)
		2 Battery Strings	982 [38.7]	551 [21.7]	280 [11]	484 (1065)
		3 Battery Strings	1013 [39.9]	550 [21.7]	280 [11]	573 (1260)
		4 Battery Strings	1054 [41.5]	548 [21.6]	280 [11]	661 (1455)
	2 UPMs Installed	0 Battery Strings	1039 [40.9]	548 [21.6]	280 [11]	290 (639)
		(1+1), 2 Battery Strings	1018 [40.1]	553 [21.8]	280 [11]	515 (1134)
		3 Battery Strings	1043 [41.1]	551 [21.7]	280 [11]	604 (1329)
		4 Battery Strings	1078 [42.4]	550 [21.7]	280 [11]	693 (1524)
	3 UPMs Installed	0 Battery Strings	1105 [43.5]	550 [21.7]	280 [11]	322 (708)
		(2+1), 3 Battery Strings	1076 [42.4]	552 [21.7]	280 [11]	635 (1398)
		4 Battery Strings	1105 [43.5]	551 [21.7]	280 [11]	724 (1593)

**Figure 13. UPS with Left or Right-Mounted Top Entry Wiring Sidecar Center of Gravity**

FRONT VIEW  
 SIDECAR CAN BE ON LEFT OR RIGHT SIDE



SIDE VIEW




**Table 7. UPS with Top Entry Wiring Sidecar - Center of Gravity dimensions**

Weight and Center of Gravity			Dimensions mm [in] See <a href="#">Figure 13</a> .			Weight kg [lb]
Model	Number of UPMs	Number of Battery Strings	A	B	C	
Eaton 93PM-L 60 kW UPS with Left Mounted Top Entry Sidecar (No Breakers)	1 UPM Installed	0 Battery Strings	943 [37.1]	545 [21.5]	394 [15.5]	337 (742)
		2 Battery Strings	963 [37.9]	550 [21.7]	430 [16.9]	562 (1237)
		3 Battery Strings	993 [39.1]	549 [21.6]	437 [17.2]	651 (1432)
		4 Battery Strings	1032 [40.6]	548 [21.6]	443 [17.4]	740 (1627)
	2 UPMs Installed	0 Battery Strings	998 [39.3]	547 [21.5]	402 [15.8]	369 (811)
		(1+1), 2 Battery Strings	998 [39.3]	552 [21.7]	433 [17.0]	594 (1306)
		3 Battery Strings	1020 [40.2]	550 [21.7]	439 [17.3]	682 (1501)
		4 Battery Strings	1054 [41.5]	549 [21.6]	444 [17.5]	771 (1696)
	3 UPMs Installed	0 Battery Strings	1054 [41.5]	549 [21.6]	408 [16.1]	400 (880)
		(2+1), 3 Battery Strings	1050 [41.3]	551 [21.7]	441 [17.4]	714 (1570)
		4 Battery Strings	1080 [42.5]	550 [21.7]	446 [17.6]	802 (1765)
		4 Battery Strings	1080 [42.5]	550 [21.7]	446 [17.6]	802 (1765)
Eaton 93PM-L 60 kW UPS with Right-Mounted Top Entry Sidecar (No Breakers)	1 UPM Installed	0 Battery Strings	943 [37.1]	545 [21.5]	369 [14.5]	337 (742)
		2 Battery Strings	963 [37.9]	550 [21.7]	333 [13.1]	562 (1237)
		3 Battery Strings	993 [39.1]	549 [21.6]	326 [12.8]	651 (1432)
		4 Battery Strings	1032 [40.6]	548 [21.6]	320 [12.6]	740 (1627)
	2 UPMs Installed	0 Battery Strings	998 [39.3]	547 [21.5]	361 [14.2]	369 (811)
		(1+1), 2 Battery Strings	998 [39.3]	552 [21.7]	402 [15.8]	594 (1306)
		3 Battery Strings	1020 [40.2]	550 [21.7]	324 [12.8]	682 (1501)
		4 Battery Strings	1054 [41.5]	549 [21.6]	319 [12.6]	771 (1696)
	3 UPMs Installed	0 Battery Strings	1054 [41.5]	549 [21.6]	355 [14.0]	400 (880)
		(2+1), 3 Battery Strings	1050 [41.3]	551 [21.7]	322 [12.7]	714 (1570)
		4 Battery Strings	1080 [42.5]	550 [21.7]	317 [12.5]	802 (1765)
		4 Battery Strings	1080 [42.5]	550 [21.7]	317 [12.5]	802 (1765)



**Figure 14. UPS with Left or Right-Mounted SIAC-B Center of Gravity**



**Table 8. UPS with Bypass Sidecar (SIAC-B) - Center of Gravity dimensions**


Weight and Center of Gravity			Dimensions mm [in] See <a href="#">Figure 14</a> .			Weight kg [lb]
Model	Number of UPMs	Number of Battery Strings	A	B	C	
Eaton 93PM-L 60 kW UPS with Left-Mounted Sidecar (2 Breakers)	1 UPM Installed	0 Battery Strings	940 [37.0]	563 [22.2]	438 [17.2]	405 (892)
		2 Battery Strings	959 [37.8]	561 [22.1]	494 [19.4]	630 (1387)
		3 Battery Strings	986 [38.8]	559 [22.0]	507 [20.0]	719 (1582)
		4 Battery Strings	1023 [40.3]	557 [21.9]	516 [20.3]	808 (1777)
	2 UPMs Installed	0 Battery Strings	986 [38.8]	564 [22.2]	450 [17.7]	437 (961)
		(1+1), 2 Battery Strings	988 [38.9]	562 [22.1]	499 [19.6]	662 (1456)
		3 Battery Strings	1011 [39.8]	559 [22.0]	510 [20.1]	750 (1651)
		4 Battery Strings	1043 [41.1]	558 [22.0]	519 [20.4]	839 (1846)
	3 UPMs Installed	0 Battery Strings	1035 [40.7]	564 [22.2]	459 [18.1]	468 (1030)
		(2+1), 3 Battery Strings	1039 [40.9]	560 [22.0]	514 [20.2]	782 (1720)
		4 Battery Strings	1068 [42.0]	558 [22.0]	522 [20.6]	870 (1915)
		4 Battery Strings	1068 [42.0]	558 [22.0]	522 [20.6]	870 (1915)
Eaton 93PM-L 60 kW UPS with Right-Mounted Sidecar (2 Breakers)	1 UPM Installed	0 Battery Strings	940 [37.0]	563 [22.2]	437 [17.2]	405 (892)
		2 Battery Strings	959 [37.8]	561 [22.1]	381 [15.0]	630 (1387)
		3 Battery Strings	986 [38.8]	559 [22.0]	368 [14.5]	719 (1582)
		4 Battery Strings	1023 [40.3]	557 [21.9]	359 [14.1]	808 (1777)
	2 UPMs Installed	0 Battery Strings	986 [38.8]	564 [22.2]	425 [16.7]	437 (961)
		(1+1), 2 Battery Strings	988 [38.9]	562 [22.1]	376 [14.8]	662 (1456)
		3 Battery Strings	1011 [39.8]	559 [22.0]	365 [14.4]	750 (1651)
		4 Battery Strings	1043 [41.1]	558 [22.0]	356 [14.0]	839 (1846)
	3 UPMs Installed	0 Battery Strings	1035 [40.7]	564 [22.2]	416 [16.4]	468 (1030)
		(2+1), 3 Battery Strings	1039 [40.9]	560 [22.0]	361 [14.2]	782 (1720)
		4 Battery Strings	1068 [42.0]	558 [22.0]	353 [13.9]	870 (1915)
		4 Battery Strings	1068 [42.0]	558 [22.0]	353 [13.9]	870 (1915)

**Table 8. UPS with Bypass Sidecar (SIAC-B) - Center of Gravity dimensions (Continued)**

Weight and Center of Gravity			Dimensions mm [in] See <a href="#">Figure 14</a> .			Weight kg [lb]
Model	Number of UPMs	Number of Battery Strings	A	B	C	
Eaton 93PM-L 60 kW UPS with Left-Mounted Sidecar (3 Breakers)	1 UPM Installed	0 Battery Strings	943 [37.1]	558 [22.0]	424 [16.7]	425 (934)
		2 Battery Strings	960 [37.8]	558 [22.0]	483 [19.0]	650 (1429)
		3 Battery Strings	987 [38.9]	556 [21.9]	496 [19.5]	738 (1624)
		4 Battery Strings	1022 [40.2]	556 [21.9]	507 [20.0]	827 (1819)
	2 UPMs Installed	0 Battery Strings	987 [38.9]	559 [22.0]	435 [17.1]	456 (1003)
		(1+1), 2 Battery Strings	989 [38.9]	559 [22.0]	488 [19.2]	681 (1498)
		3 Battery Strings	1011 [39.8]	557 [21.9]	500 [19.7]	770 (1693)
		4 Battery Strings	1043 [41.1]	555 [21.9]	510 [20.1]	858 (1888)
	3 UPMs Installed	0 Battery Strings	1034 [40.7]	560 [22.0]	446 [17.6]	487 (1072)
		(2+1), 3 Battery Strings	1039 [40.9]	558 [22.0]	504 [19.8]	801 (1762)
		4 Battery Strings	1066 [42.0]	556 [21.9]	513 [20.2]	890 (1957)
	Eaton 93PM-L 60 kW UPS with Right-Mounted Sidecar (3 Breakers)	1 UPM Installed	0 Battery Strings	943 [37.1]	558 [22.0]	451 [17.8]
2 Battery Strings			960 [37.8]	558 [22.0]	392 [15.4]	650 (1429)
3 Battery Strings			987 [38.9]	556 [21.9]	379 [14.9]	738 (1624)
4 Battery Strings			1022 [40.2]	556 [21.9]	368 [14.5]	827 (1819)
2 UPMs Installed		0 Battery Strings	987 [38.9]	559 [22.0]	440 [17.3]	456 (1003)
		(1+1), 2 Battery Strings	989 [38.9]	559 [22.0]	387 [15.2]	681 (1498)
		3 Battery Strings	1011 [39.8]	557 [21.9]	375 [14.8]	770 (1693)
		4 Battery Strings	1043 [41.1]	555 [21.9]	365 [14.4]	858 (1888)
3 UPMs Installed		0 Battery Strings	1034 [40.7]	560 [22.0]	429 [16.9]	487 (1072)
		(2+1), 3 Battery Strings	1039 [40.9]	558 [22.0]	371 [14.6]	801 (1762)
		4 Battery Strings	1066 [42.0]	556 [21.9]	362 [14.3]	890 (1957)

**Table 8. UPS with Bypass Sidecar (SIAC-B) - Center of Gravity dimensions (Continued)**

Weight and Center of Gravity			Dimensions mm [in] See <a href="#">Figure 14</a> .			Weight kg [lb]
Model	Number of UPMs	Number of Battery Strings	A	B	C	
Eaton 93PM-L 60 kW UPS with Left-Mounted Sidecar (4 Breakers)	1 UPM Installed	0 Battery Strings	944 [37.2]	550 [21.7]	414 [16.3]	440 (969)
		2 Battery Strings	960 [37.8]	553 [21.8]	475 [18.7]	665 (1464)
		3 Battery Strings	987 [38.9]	551 [21.7]	489 [19.3]	754 (1659)
		4 Battery Strings	1021 [40.2]	550 [21.7]	500 [19.7]	843 (1854)
	2 UPMs Installed	0 Battery Strings	987 [38.9]	551 [21.7]	426 [16.8]	472 (1038)
		(1+1), 2 Battery Strings	988 [38.9]	554 [21.8]	480 [18.9]	697 (1533)
		3 Battery Strings	1010 [39.8]	552 [21.7]	493 [19.4]	785 (1728)
		4 Battery Strings	1041 [41.0]	551 [21.7]	504 [19.8]	874 (1923)
	3 UPMs Installed	0 Battery Strings	1032 [40.6]	553 [21.8]	436 [17.2]	503 (1107)
		(2+1), 3 Battery Strings	1037 [40.8]	553 [21.8]	497 [19.6]	817 (1797)
		4 Battery Strings	1065 [41.9]	552 [21.7]	507 [20.0]	905 (1992)
		0 Battery Strings	944 [37.2]	550 [21.7]	464 [18.3]	440 (969)
Eaton 93PM-L 60 kW UPS with Right-Mounted Sidecar (4 Breakers)	1 UPM Installed	2 Battery Strings	960 [37.8]	553 [21.8]	402 [15.8]	665 (1464)
		3 Battery Strings	987 [38.9]	551 [21.7]	388 [15.3]	754 (1659)
		4 Battery Strings	1021 [40.2]	550 [21.7]	376 [14.8]	843 (1854)
		0 Battery Strings	987 [38.9]	551 [21.7]	452 [17.8]	472 (1038)
	2 UPMs Installed	(1+1), 2 Battery Strings	988 [38.9]	554 [21.8]	396 [15.6]	697 (1533)
		3 Battery Strings	1010 [39.8]	552 [21.7]	383 [15.1]	785 (1728)
		4 Battery Strings	1041 [41.0]	551 [21.7]	373 [14.7]	874 (1923)
		0 Battery Strings	1032 [40.6]	553 [21.8]	441 [17.4]	503 (1107)
	3 UPMs Installed	(2+1), 3 Battery Strings	1037 [40.8]	553 [21.8]	379 [14.9]	817 (1797)
		4 Battery Strings	1065 [41.9]	552 [21.7]	370 [14.6]	905 (1992)

**Figure 15. Remote EPO Switch Dimensions**

Dimensions are in millimeters (inches)

### 3.3 UPS System Power Wiring Preparation

Read and understand the following notes while planning and performing the installation:

---

#### **WARNING**

As a result of the connected loads high leakage current is possible. Connection to earth ground is required for safety and proper product operation. Do not check UPS operation by any action that includes removal of the earth (ground) connection with loads attached.

- Refer to national and local electrical codes for acceptable external wiring practices.
- To allow for future power upgrades, Eaton recommends installing the UPS using wiring and external overcurrent protection breakers sized for the fully rated UPS kW frame size instead of the derated kW ordered. Wiring for the maximum kW frame size will allow a full power rating upgrade without having to modify the site wiring infrastructure.
- For external wiring, use 75°C copper wire.

---

#### **IMPORTANT**

This product has been evaluated for use with **copper wire only**. For external wiring, use only 75°C copper wire.

Wire sizes listed in [Table 9](#) through are for copper wiring only. If wire is run in an ambient temperature greater than 40°C, larger size wire may be necessary. Wire sizes are based on using the specified breakers.

- The AC output and output ground wiring to the critical load should be sized the same as the UPS rectifier, bypass, and rectifier and bypass ground wiring if the recommended output breaker listed in [Table 18](#) is not installed in the system.

- Recommended wire sizes are based on NFPA National Electrical Code® (NEC®) 70 Table 310.15(B)(16) 75° C ampacity with 40°C ambient correction factors.
- The neutral conductor is sized the same as the phase conductor for balanced and resistive loads. Non-linear loads, up to the maximum of 1.5x the load current, require a larger neutral conductor and should be sized in accordance with NFPA NEC 70 Article 310.15(B)(5).
- Connect rectifier input to a 3 wire, grounded Wye source. A neutral conductor is not used from the rectifier source.
- Supported single source, single or dual feed power sources:
  - 3-wire grounded Wye (TN,TT) – Rectifier Input
  - 4-wire grounded Wye (TN,TT) – Bypass Input
- Supported dual source, dual feed power sources:
  - 3-wire grounded Wye (TN, TT) – Rectifier Input
  - 4-wire grounded Wye (TN, TT) – Bypass Input

---

 **CAUTION**

SINGLE HIGH IMPEDANCE GROUND SOURCE – In North American installations, the neutral conductor from the high impedance ground source of supply CANNOT be used.

---

- Phase rotation must be clockwise starting with phase A (rotation A, B, C).
- If installing an external maintenance bypass, all feeds to the UPS including the Rectifier Input Breaker (RIB) (if installed) must have a service disconnect independent of the maintenance bypass power path. Most maintenance bypass solutions provide UPS input feeds derived from but isolated from the maintenance bypass power path. If the maintenance bypass solution being installed does not provide such functionality, DO NOT use a single feeder breaker to supply both the UPS and the maintenance bypass.
- The Eaton 93PM-L UPS provides backfeed detection and protection through a shunt trip mechanism of the bypass input breaker.

---

 **IMPORTANT**

If an Eaton 93PM-L UPS is ordered with:

- a 3 or 4 breaker SIAC-B, the system as shipped from the factory will have the bypass protection pre-wired and tested.
- a 3 or 4 breaker wall-mount or floor mount bypass optional accessory kit; it will be packaged with all of the accessories for the bypass input breaker (BIB) but must be field installed.



**NOTE**

During installation, the installer needs to connect the Bypass Shunt Trip interface connections. See paragraph [4.6.5 Bypass Shunt Trip Connections](#).

---

- a 2-breaker bypass, the customer must provide their own bypass, or if the customer does not use a bypass, the upstream bypass input source must have a 48VDC shunt trip installed and wired back to the UPS to provide backfeed protection. The customer is also required to provide special electrical labeling outlined in the electrical code.



**NOTE**

During installation, the installer needs to connect the Bypass Shunt Trip interface connections. See paragraph [4.6.5 Bypass Shunt Trip Connections](#).


---

### 3.4 External Parallel UPS System Power Wiring Preparation

Read and understand the following notes in addition to the notes in paragraph [3.3 UPS System Power Wiring Preparation](#) while planning and performing the external parallel installation:

- All external parallel UPS rectifier inputs must come from one source and all bypass input feeds must come from one source.
- UPSs in an external parallel system may contain a different number of power modules but they must have identical rated static switches.
- Up to four (4) 93PM-L UPSs may be externally paralleled for a maximum output power rating up to 400 kW.
- External parallel UPS input wiring size recommendations and output wiring size recommendations from the UPSs to the panelboard are the same as listed in [Table 9](#) through [Table 12](#).
- The wall mounted tie panelboard must contain Module Output Breakers (MOBs) with dual auxiliary contacts for control of the system and to maintain critical load protection. With dual auxiliary MOBs, one UPM can be bypassed while the remaining UPMs support the load as long as the remaining UPMs have the capacity to do so.

**Figure 16. 93PM-L External Parallel Wire Length**



**NOTE 1** Required parallel system wire length must be equal to ensure approximately equal current sharing when in Bypass mode. For proper operation the following must be true:  
 $1A + 1B = 2A + 2B = 3A + 3B = 4A + 4B$



**NOTE 2** Any difference in wire length will result in decreased capacity of the UPS system while on bypass. For example, a 10% difference between the longest and shortest wire lengths will result in a decrease in bypass capacity of 10%.

For external wiring recommendations, including the minimum AWG size of external wiring, see [Table 9](#) through [Table 12](#). Wire sizes listed are for copper wiring only. For external wiring, use only 75°C copper wire.

**Table 9. Input/Output Ratings and Wiring Recommendations: 10– 30 kW (208/208)**

Basic Unit Rating	Units	Rating 50/60 Hz			
	kW	10	20	30	
<b>Input and Output Voltage</b>	Volts	208/208	208/208	208/208	
<b>AC Input to UPS Rectifier (0.99 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	Amps	36	71	107	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>A</b>	AWG or kcmil (each)	8 (1)	3 (1)	1/0 (1)
	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
<b>AC Input to UPS Bypass (Four-Wire, Dual-Feed)</b> Full Load Current (3) Phases – see Note, (1) Ground	Amps	36	71	107	
Neutral Current	Amps	36	71	107	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>B</b>	AWG or kcmil (each)	6 (1)	2 (1)	2/0 (1)
	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	6 (1)	2 (1)	2/0 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
<b>DC Input from External Battery (Line-Up-and-Match Eaton 93PM-L IBC-SW, IBC-LW or IBC-LHW)</b> For Line-Up-and-Match wiring refer to <i>Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded</i> or <i>Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate</i>					
<b>DC Input from External Battery (Standalone Eaton 93PM-L IBC)</b> (1) Positive, (1) Negative, (1) Ground	Total Amps	23	45	68	
Minimum Conductor Size (Phase Positive and Negative) Number per Pole	<b>C</b>	AWG or kcmil (each)	10 (1)	6 (1)	4 (1)
	–	AWG or kcmil (each)	10 (1)	10 (1)	8 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	10 (1)	8 (1)
<b>AC Output to Critical Load (Four-Wire)</b> Full Load Current (3) Phases – see Note, (1) Ground	Amps	28	56	83	
Neutral Current	Amps	28	56	83	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>D</b>	AWG or kcmil (each)	8 (1)	4 (1)	1 (1)
	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	8 (1)	4 (1)	1 (1)



**Table 9. Input/Output Ratings and Wiring Recommendations: 10– 30 kW (208/208) (Continued)**

Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
<p><b>NOTE</b> Callout letters <b>A, B, C</b> and <b>D</b> map to <a href="#">Figure 54</a>, <a href="#">Figure 55</a>, and <a href="#">Figure 56</a> 93PM-L System Oneline Schematics.</p> <p>Line-up-and-match battery wiring with a 105°C rating is factory supplied with the Eaton 93PM-L Integrated Battery Cabinet (IBC).</p> <p>Eaton recommends installing the UPS using wiring and external overcurrent protection breakers sized for the fully rated UPS kW frame size installed.</p>					

**Table 10. Input/Output Ratings and Wiring Recommendations: 40–60 kW (208/208)**

Basic Unit Rating	Units		Rating 50/60 Hz		
	kW	40	50	60	
<b>Input and Output Voltage</b>	Volts	208/208	208/208	208/208	
<b>AC Input to UPS Rectifier (0.99 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	Amps	142	178	213	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>A</b>	AWG or kcmil (each)	3/0 (1)	4/0 (1)	300 MCM (1)
	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
<b>AC Input to UPS Bypass (Four-Wire, Dual-Feed)</b> Full Load Current (3) Phases – see Note, (1) Ground	Amps	142	178	213	
Neutral Current	Amps	142	178	213	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>B</b>	AWG or kcmil (each)	4/0 (1)	250 MCM (1)	350 MCM (1)
	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	4/0 (1)	250 MCM (1)	2/0 (2)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
<b>DC Input from External Battery (Line-Up-and-Match Eaton 93PM-L IBC-SW, IBC-LW or IBC-LHW)</b> For Line-Up-and-Match wiring refer to <i>Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded</i> or <i>Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate</i>					
<b>DC Input from External Battery (Standalone Eaton 93PM-L IBC)</b> (1) Positive, (1) Negative, (1) Ground	Total Amps	90	113	136	
Minimum Conductor Size (Phase Positive and Negative) Number per Pole	<b>C</b>	AWG or kcmil (each)	2 (1)	1 (1)	2/0 (1)
	–	AWG or kcmil (each)	8 (1)	6 (1)	6 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	8 (1)	6 (1)	6 (1)
<b>AC Output to Critical Load (Four-Wire)</b> Full Load Current (3) Phases – see Note, (1) Ground	Amps	111	139	167	
Neutral Current	Amps	111	139	167	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>D</b>	AWG or kcmil (each)	2/0 (1)	3/0 (1)	250 MCM (1)
	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	2/0 (1)	3/0 (2)	250 MCM (1)

**Table 10. Input/Output Ratings and Wiring Recommendations: 40–60 kW (208/208) (Continued)**

Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	6 (1)	6 (1)	4 (1)
<p><b>NOTE</b> Callout letters <b>A, B, C</b> and <b>D</b> map to <a href="#">Figure 54</a>, <a href="#">Figure 55</a>, and <a href="#">Figure 56</a> 93PM-L System Oneline Schematics.</p> <p>Line-up-and-match battery wiring with a 105°C rating is factory supplied with the Eaton 93PM-L Integrated Battery Cabinet (IBC).</p> <p>Eaton recommends installing the UPS using wiring and external overcurrent protection breakers sized for the fully rated UPS kW frame size installed.</p>					

**Table 11. Input/Output Ratings and Wiring Recommendations: 10–30 kW (220/220)**

Basic Unit Rating	Units		Rating 50/60 Hz		
	kW	10	20	30	
<b>Input and Output Voltage</b>	Volts	220/220	220/220	220/220	
<b>AC Input to UPS Rectifier (0.99 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	Amps	34	67	101	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>A</b>	AWG or kcmil (each)	8 (1)	4 (1)	1 (1)
	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
<b>AC Input to UPS Bypass (Four-Wire, Dual-Feed)</b> Full Load Current: (3) Phases— see Note, (1) Ground	Amps	34	67	101	
Neutral Current	Amps	34	67	101	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>B</b>	AWG or kcmil (each)	8 (1)	3 (1)	1/0 (1)
	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	6 (1)	2 (1)	2/0 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
<b>DC Input from External Battery (Line-Up-and-Match Eaton 93PM-L IBC-SW, IBC-LW or IBC-LHW)</b> For Line-Up-and-Match wiring refer to <i>Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded</i> or <i>Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate</i>					
<b>DC Input from External Battery (Standalone Eaton 93PM-L IBC)</b> (1) Positive, (1) Negative, (1) Ground	Total Amps	23	45	68	
Minimum Conductor Size (Phase Positive and Negative) Number per Pole	<b>C</b>	AWG or kcmil (each)	10 (1)	6 (1)	4 (1)
	–	AWG or kcmil (each)	10 (1)	10 (1)	8 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	10 (1)	8 (1)
<b>AC Output to Critical Load (Four-Wire)</b> Full Load Current (3) Phases – see Note, (1) Ground	Amps	26	52	79	
Neutral Current	Amps	26	52	79	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>D</b>	AWG or kcmil (each)	8 (1)	4 (1)	2 (1)
	–	AWG or kcmil (each)	10 (1)	8 (1)	6 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	8 (1)	4 (1)	2 (1)

**Table 11. Input/Output Ratings and Wiring Recommendations: 10–30 kW (220/220) (Continued)**

Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	10 (1)	8 (1)	8 (1)
<p><b>NOTE</b> Callout letters <b>A, B, C</b> and <b>D</b> map to <a href="#">Figure 54</a>, <a href="#">Figure 55</a>, and <a href="#">Figure 56</a> 93PM-L System Oneline Schematics.</p> <p>Line-up-and-match battery wiring with a 105°C rating is factory supplied with the Eaton 93PM-L Integrated Battery Cabinet (IBC).</p> <p>Eaton recommends installing the UPS using wiring and external overcurrent protection breakers sized for the fully rated UPS kW frame size installed.</p>					

**Table 12. Input/Output Ratings and Wiring Recommendations: 40–60 kW (220/220)**

Basic Unit Rating	Units		Rating 50/60 Hz		
	kW	40	50	60	
<b>Input and Output Voltage</b>	Volts	220/220	220/220	220/220	
<b>AC Input to UPS Rectifier (0.99 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	Amps	134	168	202	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>A</b>	AWG or kcmil (each)	2/0 (1)	4/0 (1)	250 MCM (1)
	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
<b>AC Input to UPS Bypass (Four-Wire, Dual-Feed)</b> Full Load Current: (3) Phases– see Note, (1) Ground	Amps	134	168	202	
Neutral Current	Amps	134	168	202	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>B</b>	AWG or kcmil (each)	3/0 (1)	250 MCM (1)	350 MCM (1)
	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	4/0 (1)	250 MCM (1)	1/0 (2)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
<b>DC Input from External Battery (Line-Up-and-Match Eaton 93PM-L IBC-SW, IBC-LW or IBC-LHW)</b> For Line-Up-and-Match wiring refer to <i>Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded</i> or <i>Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate</i>					
<b>DC Input from External Battery (Standalone Eaton 93PM-L IBC)</b> (1) Positive, (1) Negative, (1) Ground	Total Amps	90	113	136	
Minimum Conductor Size (Phase Positive and Negative) Number per Pole	<b>C</b>	AWG or kcmil (each)	2 (1)	1 (1)	2/0 (1)
	–	AWG or kcmil (each)	8 (1)	6 (1)	6 (1)
Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	8 (1)	6 (1)	6 (1)
<b>AC Output to Critical Load (Four-Wire)</b> Full Load Current (3) Phases – see Note, (1) Ground	Amps	105	131	157	
Neutral Current	Amps	105	131	157	
Minimum Conductor Size (Phase A, B, and C) Number per Phase	<b>D</b>	AWG or kcmil (each)	1/0 (1)	3/0 (1)	4/0 (1)
	–	AWG or kcmil (each)	6 (1)	4 (1)	4 (1)
Neutral Wire Size Number	–	AWG or kcmil (each)	1/0 (1)	3/0 (1)	4/0 (1)

**Table 12. Input/Output Ratings and Wiring Recommendations: 40–60 kW (220/220) (Continued)**

Minimum Conductor Size (Ground) Number	–	AWG or kcmil (each)	6 (1)	6 (1)	6 (1)
<p><b>NOTE</b> Callout letters <b>A, B, C</b> and <b>D</b> map to <a href="#">Figure 54</a>, <a href="#">Figure 55</a>, and <a href="#">Figure 56</a> 93PM-L System Oneline Schematics.</p> <p>Line-up-and-match battery wiring with a 105°C rating is factory supplied with the Eaton 93PM-L Integrated Battery Cabinet (IBC).</p> <p>Eaton recommends installing the UPS using wiring and external overcurrent protection breakers sized for the fully rated UPS kW frame size installed.</p>					

 **IMPORTANT**

If a 4-pole Automatic Transfer Switch (ATS) is used to connect the UPS to a generator or alternative input source, it may interrupt the UPS input neutral during its transition between sources. This UPS should always have an input source neutral connected at the bypass input terminals. This neutral must be continuous and uninterrupted; even if there are no phase-to-neutral loads connected to the UPS output. If the UPS is fed from a 4-pole ATS that interrupts the neutral, a delta-to-wye isolation transformer, with its secondary neutral bonded to ground, must be placed in line with the bypass input of the UPS. This will provide an uninterrupted neutral to the UPS, regardless of the position of the ATS neutral contact.

**Note:** if an overlapping neutral or make-before-break ATS switch is used, the neutrals must overlap for a minimum of 50 msec during the transition. In these cases, a transformer is not needed.

Power wiring terminals E1 through E11 are 2-hole bus bar mountings for standard NEMA 2-hole barrel lugs. The power wiring connections for this equipment are rated at 90°C. See [Table 13](#) for external power cable terminations, [Table 14](#) for supplied external wiring terminal hardware, and [Table 15](#) for recommended installation parts and tools not supplied by Eaton.

[Figure 27](#) and [Figure 28](#), show the location of the UPS power cable terminals.

For a detailed view of the power terminals for the 2-, 3- and 4-Breaker SIAC-B configurations, see [Figure 30](#) for the 2-Breaker SIAC-B, [Figure 31](#) for the 3-Breaker SIAC-B, and [Figure 32](#) for the 4-Breaker SIAC-B.

**Table 13. UPS External Power Cable Terminations**

Terminal Function	Terminal	Function	Bus Landings (using back-to-back lugs)	Tightening Torque Nm (lb in)	Screw Size and Type
AC Input to UPS Rectifier	E1	Phase A	4 – 2 bolt mounting	35 (310)	M12 Hex
	E2	Phase B	4 – 2 bolt mounting	35 (310)	M12 Hex
	E3	Phase C	4 – 2 bolt mounting	35 (310)	M12 Hex
AC Input to Bypass	E6	Phase A	4 – 2 bolt mounting	35 (310)	M12 Hex
	E7	Phase B	4 – 2 bolt mounting	35 (310)	M12 Hex
	E8	Phase C	4 – 2 bolt mounting	35 (310)	M12 Hex
	E12	Neutral	8 – 2 bolt mounting	35 (310)	M12 Hex
AC Output to Critical Load	E9	Phase A	4 – 2 bolt mounting	35 (310)	M12 Hex
	E10	Phase B	4 – 2 bolt mounting	35 (310)	M12 Hex
	E11	Phase C	4 – 2 bolt mounting	35 (310)	M12 Hex
	E12	Neutral	8 – 2 bolt mounting	35 (310)	M12 Hex
DC Input from Battery	E4	Battery (+)	4 – 2 bolt mounting	35 (310)	M12 Hex
	E5	Battery (-)	4 – 2 bolt mounting	35 (310)	M12 Hex
Customer Ground	Ground	Ground	14 - #14-1/0 pressure termination	5.1 (45)	Slotted

**NOTE** Customer ground, sized in accordance with NEC Table 250.122, can be run in any conduit listed in [Table 16](#).



**Table 14. Supplied External Wiring Terminal Hardware Kit**

Part	Size	Quantity	Terminal Used On
Bolt, Grade 5	M12 x 35 mm	60	Rectifier Input, Bypass Input, Battery Input, and Output to Critical Load
Flat Washer	M12	60	Rectifier Input, Bypass Input, Battery Input, and Output to Critical Load
Conical Washer	M12	60	Rectifier Input, Bypass Input, Battery Input, and Output to Critical Load

**NOTE** For additional information (including part numbers and manufacturer information) and/or assistance contact an Eaton service representative (see paragraph [1.9 Getting Help](#)).

**Table 15. Recommended Installation Parts and Tools (Not Supplied by Eaton)**

Part	Size	Quantity	Notes
Long Barrel 2-Hole Lug	6 AWG	As Required	Copper wire only
	4 AWG		
	2 AWG		
	1 AWG		
	1/0 AWG		
	2/0 AWG		
	3/0 AWG		
	4/0 AWG		
	250 MCM		
	300 MCM		
350 MCM			
500 MCM			
Manual Hydraulic Crimp Tool	14 Ton	1	
Die Set	N/A	1	

**NOTE** For additional information (including part numbers and manufacturer information) and/or assistance contact an Eaton service representative (see paragraph [1.9 Getting Help](#)).

Conduit sizes were chosen from NEC Table 4, Electrical Metallic Tubing (EMT). See [Table 16](#) for conduit recommendations.

Per NEC article 300, 3(B), all three-phase conductors must be run in the same conduit. A ground wire must be run in the same conduit as the phase conductors.

When running parallel wires in multiple conduits a ground wire must be run in each conduit in accordance with NEC Table 250.122.

Conduit is sized to accommodate one ground conductor per conduit, sized in accordance with NEC Table 250.122.

Conduit sizes listed are for copper wiring only.

**Table 16. Power Cable Conduit Recommendations**

UPS Model	UPS Rating	Voltage	Terminal	Number of Wires in Conduit	Minimum Conduit Trade Size (inches)	Number of Conduits
93PM-L 60-1 93PM-L 60-2 (N+1)	10 kW	208 or 220 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	3/4	1
		208 Vac	AC Input to UPS Bypass (A, B, C, Neutral, Ground)	5	1	1
		220 Vac			3/4	
		208 or 220 Vac	AC Output (A, B, C, Neutral, Ground)	5	3/4	1
		DC	Battery (Positive, Negative, Ground)	3	1/2	1
93PM-L 60-1 93PM-L 60-2 (N+1)	20 kW		AC Input to UPS Rectifier (A, B, C, Ground)	4	1	1
		208 or 220 Vac	AC Input to UPS Bypass (A, B, C, Neutral, Ground)	5	1-1/4	1
					1-1/4	
		DC	Battery (Positive, Negative, Ground)	3	1/2	1
93PM-L 60-2 93PM-L 60-3 (N+1)	30 kW	208 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	1-1/4	1
		220 Vac			1-1/2	
		208 or 220 Vac	AC Input to UPS Bypass (A, B, C, Neutral, Ground)	5	2	1
		208 Vac			2	
		220 Vac	AC Output (A, B, C, Neutral, Ground)	5	1-1/4	1
DC	Battery (Positive, Negative, Ground)	3	3/4	1		
93PM-L 60-2 93PM-L 60-3 (N+1)	40 kW	208 or 220 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	2	1
		208 Vac	AC Input to UPS Bypass (A, B, C, Neutral, Ground)	5	2-1/2	1
		220 Vac			2	
		208 or 220 Vac	AC Output (A, B, C, Neutral, Ground)	5	2	1
		DC	Battery (Positive, Negative, Ground)	3	1	1

**Table 16. Power Cable Conduit Recommendations (Continued)**

UPS Model	UPS Rating	Voltage	Terminal	Number of Wires in Conduit	Minimum Conduit Trade Size (inches)	Number of Conduits
93PM-L 60-3	50 kW	208 or 220 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	2	1
		208 Vac 220 Vac	AC Input to UPS Bypass (A, B, C, Neutral, Ground)	5	3 2-1/2	1
		208 Vac 220 Vac	AC Output (A, B, C, Neutral, Ground)	5	2-1/2 2	1
		DC	Battery (Positive, Negative, Ground)	3	1-1/4	1
			AC Input to UPS Rectifier (A, B, C, Ground)	4	2-1/2	1
93PM-L 60-3	60 kW	208 or 220 Vac	AC Input to UPS Bypass (A, B, C, Neutral, Ground)	5	3	2
			AC Output (A, B, C, Neutral, Ground)	5	2-1/2	1
		DC	Battery (Positive, Negative, Ground)	3	1-1/4	1

**NOTE** Wires per conduit include neutral and ground wire.

External overcurrent protection and disconnect are not provided by this product, but are required by codes. Refer to [Table 9](#) through for wiring recommendations. If an output lockable disconnect is required, it is to be supplied by the customer.

[Table 17](#) lists the recommended rating for input and bypass circuit breakers.

**Table 17. Recommended Input and Bypass Circuit Breaker Ratings**

UPS Model	UPS Rating	Input Rating		
		Load Rating	208V	220V
Eaton 93PM-L 60-1	10 kW	80% Rated	45A	45A
Eaton 93PM-L 60-2 (N+1)		100% Rated	40A	35A
Eaton 93PM-L 60-1	20 kW	80% Rated	90A	90A
Eaton 93PM-L 60-2 (N+1)		100% Rated	80A	70A
Eaton 93PM-L 60-2	30 kW	80% Rated	150A	150A
Eaton 93PM-L 60-3 (N+1)		100% Rated	110A	110A
Eaton 93PM-L 60-2	40 kW	80% Rated	200A	175A
Eaton 93PM-L 60-3 (N+1)		100% Rated	150A	150A
Eaton 93PM-L 60-3	50 kW	80% Rated	225A	225A
		100% Rated	200A	175A
Eaton 93PM-L 60-3	60 kW	80% Rated	300A	300A
		100% Rated	225A	225A

---

 **CAUTION**

---

To reduce the risk of fire, connect only to a circuit provided with maximum input circuit breaker current ratings from [Table 18](#) in accordance with the NEC, ANSI/NFPA 70.

The line-to-line unbalanced output capability of the UPS is limited only by the full load per phase current values for AC output to critical load shown in [Table 9](#) through . The recommended line-to-line load unbalance is 50% or less.

Output overcurrent protection and Output disconnect switches are to be supplied by the customer. [Table 18](#) lists the recommended rating for output circuit breakers.

---

 **IMPORTANT**

---

If an output breaker is not provided, the wire between the output and the load must be sized the same as the bypass input wire.

---

**Table 18. Recommended Output Circuit Breaker Ratings**

UPS Model	UPS Rating	Output Rating		
		Load Rating	208V	220V
Eaton 93PM-L 60-1	10 kW	80% Rated	35A	35A
Eaton 93PM-L 60-2 (N+1)		100% Rated	30A	30A
Eaton 93PM-L 60-1	20 kW	80% Rated	70A	70A
Eaton 93PM-L 60-2 (N+1)		100% Rated	60A	60A
Eaton 93PM-L 60-2	30 kW	80% Rated	110A	100A
Eaton 93PM-L 60-3 (N+1)		100% Rated	90A	80A
Eaton 93PM-L 60-2	40 kW	80% Rated	150A	150A
Eaton 93PM-L 60-3 (N+1)		100% Rated	125A	110A
Eaton 93PM-L 60-3	50 kW	80% Rated	175A	175A
		100% Rated	150A	150A
Eaton 93PM-L 60-3	60 kW	80% Rated	225A	200A
		100% Rated	175A	175A

There is no manual DC disconnect device within the UPS.

Battery voltage is computed at 2 volts per cell as defined by Article 480 of the NEC. Rated battery current is computed based on 2 volts per cell.

If required, external DC input overcurrent protection and disconnect switch is to be supplied by the customer. [Table 19](#) lists the recommended ratings for circuit breakers satisfying the criteria for each battery voltage. Recommended disconnect size is based on a maximum full load discharge time less than 3 hours. For longer discharge times a larger disconnect may be required.

**Table 19. Recommended DC Input Battery Disconnect Circuit Breaker Ratings**

UPS Model	UPS Rating	Output Rating
		208V or 220V
Eaton 93PM-L 60-1 Eaton 93PM-L 60-2 (N+1)	10 kW	25A
Eaton 93PM-L 60-1 Eaton 93PM-L 60-2 (N+1)	20 kW	45A
Eaton 93PM-L 60-2 Eaton 93PM-L 60-3 (N+1)	30 kW	70A
Eaton 93PM-L 60-2 Eaton 93PM-L 60-3 (N+1)	40 kW	90A
Eaton 93PM-L 60-3	50 kW	125A
Eaton 93PM-L 60-3	60 kW	150A

## 3.5 UPS System Interface Wiring Preparation

Control wiring for features and options should be connected at the customer interface terminal blocks located inside the UPS.



Do not directly connect relay contacts to the mains related circuits.

Reinforced insulation to the mains is required.

---

Read and understand the following notes while planning and performing the installation:

- Use Class 1 wiring methods (as defined by the NEC) for interface wiring from 30V to 600V. The wire should be rated for 600V, 1A minimum. 12 AWG maximum wire size.
- Use Class 2 wiring methods (as defined by the NEC) for interface wiring up to 30V. Class 2 circuit wiring must be segregated from Class 1 wiring. The Class 2 wire should be rated for 150V, 1A minimum.
- Because of the battery shunt trip wiring route in the UPS cabinet, the wire should be rated for a minimum of 600V.
- Use twisted-pair wires for each input and return or common.
- All interface wiring and conduit is to be supplied by the customer.
- When installing external interface wiring between a building alarm, relay output, battery breaker trip, or Minislot and the UPS interface terminals, conduit must be installed between each device and the UPS cabinet.
- If using conduit, install the interface wiring in separate conduit from the power wiring.
- All building alarm inputs require an isolated normally-open contact or switch (rated at 24 Vdc, 20 mA minimum) connected between the alarm input and common terminal. All control wiring and switch contacts are customer-supplied.
- LAN and telephone drops for use with Minislot connectivity cards must be supplied by the customer.
- The UPS battery detect signal wiring from a UPS building alarm must be connected to the battery disconnect device.
- Program the battery detect building alarm to read battery open and for normally open contacts.
- A supplemental 48 Vdc shunt trip signal for the battery disconnect device is provided, but is not required for normal operation.
- Battery detect and 48 Vdc shunt trip wiring should be a minimum of 18 AWG.
- The REPO feature opens all switchgear in the UPS cabinet and isolates power from your critical load. Local electrical codes may also require tripping upstream protective devices to the UPS.
- The REPO switch must be a latching-type switch not tied to any other circuits.
- A jumper wire must be connected between pins 3 and 4 on the REPO terminal block if using a normally-closed REPO switch.
- REPO wiring should be a minimum of 18 AWG and a maximum of 16 AWG.
- The REPO switch wiring must be in accordance with NEC Article 725 Class 2 requirements.
- The maximum distance between the REPO and the UPS cannot exceed 150m (500 ft).
- Alarm relay contacts have a maximum current rating of 5A and a switched voltage rating of 30 Vac or 28 Vdc.
- Recommended alarm relay wiring size is 18 AWG.

### 3.6 Inspecting and Unpacking the UPS Cabinet

The cabinet is shipped bolted to a metal and wood pallet (see [Figure 17](#), [Figure 18](#), or [Figure 19](#)) with outer protective packaging material covering the cabinets.



#### NOTE

Startup and operational checks must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on the product's resources page become void. See [93PM Warranty](#) for details. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (a minimum two-week notice is required) to reserve a preferred startup date.



#### WARNING

The UPS cabinet is heavy (see [Table 2](#), [Table 3](#) or [Table 4](#)). If unpacking and unloading instructions are not closely followed, the cabinet may tip and cause serious injury or death.

- Carefully inspect the outer packaging for evidence of damage during transit.



#### CAUTION

Do not install a damaged cabinet. Report any damage to the carrier and contact an Eaton service representative immediately.



#### NOTE

For the following step, verify that the forklift or pallet jack is rated to handle the weight of the cabinet (see [Table 2](#), [Table 3](#) or [Table 4](#) for cabinet weight).

- Use a forklift or pallet jack to move the packaged cabinet to the installation site, or as close as possible, before unpacking. If possible, move the cabinet using the pallet. Insert the forklift or pallet jack forks between the supports on the bottom of the pallet (see [Figure 12](#), [Figure 13](#), or [Figure 14](#) and their corresponding Center of Gravity tables for the UPS cabinet center of gravity measurements).



#### CAUTION

Do not tilt the UPS cabinet more than 10° from vertical or the cabinet may tip over.


- Set the pallet on a firm, level surface, allowing a minimum clearance of 3m (10 ft) on each side for removing the cabinet from the pallet.
- Remove the protective packaging material from the cabinet and recycle in a responsible manner. Retain any parts kits packaged with the cabinet.
- Inspect the contents for any evidence of physical damage, and compare each item with the Bill of Lading. If damage has occurred or shortages are evident, contact an Eaton service representative immediately to determine the extent of the damage and its impact on further installation.




#### NOTE

While waiting for installation, protect the unpacked cabinet from moisture, dust, and other harmful contaminants. Failure to store and protect the UPS properly may void the warranty.

**Figure 17. UPS Cabinet as Shipped on Pallet**




**Figure 18. UPS Cabinet with Left or Right-Mounted Top Entry Wiring Sidecar as Shipped on Pallet**





**Figure 19. UPS Cabinet with Left or Right-Mounted Sidecar as Shipped on Pallet**





## Chapter 4 UPS System Installation

### 4.1 Preliminary Installation Information



---

Installation should be performed only by qualified personnel.

---

Refer to the following while installing the UPS system:

- Review **Chapter 3 UPS Installation Plan and Unpacking**, for cabinet dimensions, equipment weight, wiring and terminal data, and installation notes.
- Do not tilt the cabinets more than  $\pm 10^\circ$  during installation.
- Remove conduit landing plates to add conduit landing holes as required.
- If perforated floor tiles are required for ventilation, place them in front of the UPS.

### 4.2 Unloading the UPS Cabinet from the Pallet



- 
- The UPS cabinet is heavy (see [Table 2](#), [Table 3](#), or [Table 4](#)).
  - Do not tilt cabinet more than  $10^\circ$  from vertical.
  - Lift the cabinets only with a forklift or damage may occur.
  - Ensure the forklift is rated to handle the weight of the cabinet.

**Failure to follow these instructions may result in severe injury or death.**

---


The UPS cabinet is bolted to a pallet consisting of four metal angle supports secured to two wood supports.

To remove the pallet:

1. If not already accomplished, use a forklift or pallet jack to move the UPS cabinet to the installation area, or as close as possible, before unloading from the pallet. Insert the forklift or pallet jack forks between the supports on the bottom of the pallet (see [Figure 12](#), [Figure 13](#), or [Figure 14](#) and their corresponding Center of Gravity tables for the UPS cabinet center of gravity measurements).
2. Open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. Locate the four 1/2" jacking bolts from the parts kit and install them in the threaded holes in the front and rear supports as shown in [Figure 20](#). Place a floor protector from the parts kit underneath each jacking bolt, and screw the bolts down against them.

The floor protectors protect the floor from being marred by the jacking bolts.

**Figure 20. Removing the UPS Pallet Skids and Supports**



**⚠ WARNING**


Do not remove or loosen the cabinet mounting or cabinet support bolts until instructed. If unpacking and unloading instructions are not closely followed, the cabinet may tip and cause serious injury or death.

4. Loosen, but do not remove, the skid mounting bolts holding the pallet skids to the front and rear supports, and to the left and right side supports.
5. If a sidecar is attached to the UPS, loosen, but do not remove, the sidecar skid mounting bolts holding the sidecar pallet skids to the sidecar front and rear supports, and to the left and right supports (see [Figure 21](#) for the Top Entry Sidecar or [Figure 22](#) for the Bypass Sidecar (SIAC-B).


**⚠ WARNING**

**RISK OF INSTABILITY.** Turning the jacking bolts unevenly may cause the cabinet to become unbalanced. To prevent tipping the cabinet, raise the cabinet no more than 3 mm (1/8") above the floor (just enough to allow the removal of the pallet skids). Failure to follow these instructions can result in serious injury or death.

**Figure 21. Removing the Top Entry Sidecar Pallet Skids and Supports**



**Figure 22. Removing the Bypass Sidecar (SIAC-B) Pallet Skids and Supports**



6. Turn each jacking bolt consecutively, two full turns, until the pallet skids clear the floor by approximately 3 mm (1/8").
7. Remove the hardware loosened in **Step 4**.
8. If a sidecar is attached to the UPS, remove the hardware loosened in **Step 5**.
9. Pull the pallet skids out from under the metal angle supports without disturbing the jacking bolts. Recycle the pallet skids and hardware in a responsible manner.

---

 **CAUTION**

---

CABINET MAY FALL. Do not loosen the hardware attaching the front supports to the cabinet base. The cabinet must be lowered by the jacking bolts before the supports can be removed. If unpacking and unloading instructions are not closely followed, the cabinet may tip and cause serious injury or death.

---

10. Carefully and evenly **lower the cabinet by turning each jacking bolt consecutively two full turns (maximum)** until the casters contact the floor and the cabinet is no longer supported by the jacking bolts.
11. After the UPS is resting on the floor, remove the jacking bolts and floor protectors. Recycle them in a responsible manner.
12. Remove the cabinet support bolts fastening the front, rear, and side cabinet supports together and remove the side supports.
13. If a sidecar is attached to the UPS, loosen the bottom screws and completely remove the top screws securing the sidecar front panel. Lift the panel straight up to remove the panel.
14. If a sidecar is attached to the UPS, remove the sidecar mounting bolts holding the front and rear sidecar supports to the cabinet base.
15. Remove the cabinet mounting bolts holding the front and rear supports to the cabinet base.
16. If installing the cabinet permanently, retain the cabinet mounting bolts; otherwise, recycle the bolts along with the support brackets in a responsible manner.
17. Close the door and secure the latch.
18. If a sidecar is attached to the UPS, remove the screws securing sidecar rear shipping bracket. Remove the bracket and reinstall the screws (see [Figure 23](#)).
19. If the leveling feet are not retracted, turn all leveling feet until they are retracted as far into the cabinet as possible.

---

 **CAUTION**

---

To prevent tipping when rolling the cabinet, push the cabinet from the rear whenever possible.

---

20. Roll the cabinet to the final installation location.
21. Lower the UPS cabinet feet and using a level, adjust the cabinet height accordingly until the cabinet is level.



**NOTE**

An optional front and rear floor mounting bracket kit is available for permanently mounting the UPS.

---

22. If permanently mounting the UPS using the customer supplied left and right side floor mounting brackets, proceed to **Step 23**; if using the optional front and rear floor mounting bracket kit, proceed to **Step 27**; otherwise, proceed to **Step 30**.
23. Locate the customer supplied left and right side floor mounting brackets and hardware.


24. Using the retained cabinet mounting bolts, install the floor mounting brackets to the left and right side of the UPS with the angle facing outward.
25. Secure the cabinet to the floor with customer-supplied hardware.
26. Proceed to **Step 30**.
27. Locate the front and back floor mounting brackets from the optional floor mounting kit.
28. Using the retained cabinet mounting bolts, install the floor mounting brackets to the front and rear of the UPS with the angle facing outward.
29. Secure the cabinet to the floor with customer-supplied hardware.

**NOTE**

Black cover dots are provided, if side mounting bracket holes need to be covered for aesthetic reasons.

30. Locate the black cover dots from the parts kit and install over the left and right side bracket mounting holes.
31. Proceed to paragraph [4.3 Integrated Battery Cabinet Installation](#).

**Figure 23. Removing the Sidecar Rear Shipping Bracket – UPS with Right-Mounted Sidecar**



### 4.3 Integrated Battery Cabinet Installation

If installing Integrated Battery Cabinets (IBCs), refer to the *Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate*, or the *Eaton 93PM Integrated Battery Cabinet-Small Welded IBC-SW (432V and 480V) Installation Manual*, listed in paragraph [1.8 For More Information](#), for installation instructions.



#### IMPORTANT

If the Eaton 93PM-L UPS has a SIAC-B, the Integrated Battery Cabinet must be installed on the opposite side of the UPS away from the SIAC-B.

---

After the IBC is installed, proceed to paragraph [4.4 External AC Power Wiring Installation](#) to complete the wiring of the UPS.

### 4.4 External AC Power Wiring Installation

1. Open the UPS front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
2. Remove the screws securing the bottom internal safety shield panel and remove the panel to gain access to the input, output, and battery power wiring terminals. Retain the hardware for later use.
3. If the UPS has a Sidecar, loosen the bottom screws and completely remove the top screws securing the sidecar front panel. Lift the panel upwards and remove from the unit. Retain the hardware for later use.
4. Remove the screws securing the sidecar internal safety shield panel and remove the panel to gain access to the interior of the sidecar and the UPS inter-cabinet wiring access pass-through. Retain the hardware for later use.
5. If wiring via bottom entry, remove the bottom conduit plate, or plates if sidecar is installed. If wiring via top entry, remove the top entry conduit plate from the sidecar. For details on conduit plate locations see [Figure 24](#), [Figure 25](#) or [Figure 29](#).



#### NOTE

Top Entry Wiring for the Eaton 93PM-L is only available when the system is ordered with a sidecar.

---

6. Identify all conduit recommendations and mark their location.
7. Proceed to the appropriate wiring configuration:
  - **Standalone UPS or UPS with Top Entry Sidecar (No Breakers)**, go to Section [4.4.1 Standalone UPS or UPS with Top Entry Sidecar \(No Breakers\)](#).
  - **UPS with 2-Breaker Sidecar (MBP and MIS)**, go to Section [4.4.2 UPS with 2-Breaker Sidecar \(MBP and MIS\)](#).
  - **UPS with 3-Breaker Sidecar (BIB, MBP and MIS)**, go to Section [4.4.3 UPS with 3-Breaker Sidecar \(BIB, MBP and MIS\)](#).
  - **UPS with 4-Breaker Sidecar (RIB, BIB, MBP and MIS)**, go to Section [4.4.4 UPS with 4 -Breaker Sidecar \(RIB, BIB, MBP and MIS\)](#).



#### 4.4.1 Standalone UPS or UPS with Top Entry Sidecar (No Breakers).

1. Drill and punch all conduit holes in the appropriate conduit plate/s prior to mounting. Install the conduit plate/s and install all conduit runs. Pull the wiring through conduit into the wiring area.  
  
If Top Entry sidecar, pull wiring through conduit into sidecar and into the UPS via the inter-cabinet wiring access pass-through (see [Figure 26](#)).
2. Route the input and output cables to the UPS terminals. See [Figure 24](#) and [Figure 25](#) for wiring access information, and [Figure 27](#) for terminal locations.

---

 **WARNING**


---

As a result of the connected loads high leakage current is possible. Connection to earth ground is required for safety and proper product operation. Do not check UPS operation by any action that includes removal of the earth (ground) connection with loads attached.


---

3. Ground the UPS according to local and/or national electrical wiring codes by routing and connecting the ground wire to the input ground lug.
4. If wiring Single Input Feed, go to **Step 6**, otherwise continue to **Step 5**.
5. If Dual Feed Input, Connect phase A, B, and C Rectifier input power wiring from the utility source to the Rectifier input terminals. See [Figure 27](#) for terminal locations and [Figure 28](#) for terminal details. See paragraph [3.3 UPS System Power Wiring Preparation](#) for wiring and termination requirements.
6. Connect phase A, B, and C, and Neutral bypass input power wiring from the utility source to the bypass input terminals.
7. Route the output cables to the AC Output to Load terminals.
8. Connect phase A, B, and C, and Neutral power wiring from output terminals to the critical load.
9. Proceed to paragraph [4.5 Battery Power Wiring](#).

**Figure 24. UPS Conduit and Wire Entry Locations**



**Figure 25. UPS with Top Entry Sidecar Conduit and Wire Entry Locations**



**Figure 26. UPS Inter-Cabinet Wiring Access Location**




Figure 27. Power Terminal Locations





Figure 28. Eaton 93PM-L UPS Power Terminal Detail



#### 4.4.2 UPS with 2-Breaker Sidecar (MBP and MIS)

1. Drill and punch all conduit holes in the appropriate conduit plate/s prior to mounting. Install the conduit plate/s and install all conduit runs. pull wiring through conduit into sidecar and into the UPS via the inter-cabinet wiring access pass-through.
2. Route the input and output cables to the UPS terminals. See [Figure 29](#) for wiring access information, and [Figure 30](#) for terminal locations.



#### WARNING

As a result of the connected loads high leakage current is possible. Connection to earth ground is required for safety and proper product operation. Do not check UPS operation by any action that includes removal of the earth (ground) connection with loads attached.

---

3. Ground the UPS according to local and/or national electrical wiring codes by routing and connecting the ground wire to the input ground lug.
4. Connect the 2nd utility to Maintenance Bypass Phase A, B, and C (from customer supplied breaker) to the Maintenance Bypass Input terminals in the 2-Breaker sidecar (upper frame area).
5. Connect phase A, B, and C, and Neutral bypass input power wiring from the utility source to the bypass input terminals.
6. Route the output cables to the sidecar AC Output to Load terminals (lower frame area).
7. Connect phase A, B, and C, and Neutral power wiring from output terminals to the critical load. See paragraph [3.3 UPS System Power Wiring Preparation](#) for wiring and termination requirements.
8. Proceed to paragraph [4.5 Battery Power Wiring](#).

**Figure 29. UPS with Bypass Sidecar (SIAC-B) Conduit and Wire Entry Locations**







Figure 30. Eaton 93PM-L with SIAC-B (2-Breaker) Power Terminal Locations



### 4.4.3 UPS with 3-Breaker Sidecar (BIB, MBP and MIS)

1. Drill and punch all conduit holes in the appropriate conduit plate/s prior to mounting. Install the conduit plate/s and install all conduit runs. pull wiring through conduit into sidecar and into the UPS via the inter-cabinet wiring access pass-through.
2. Route the input and output cables to the UPS terminals. See [Figure 29](#) for wiring access information, and [Figure 31](#) for terminal locations.



#### **WARNING**


---

As a result of the connected loads high leakage current is possible. Connection to earth ground is required for safety and proper product operation. Do not check UPS operation by any action that includes removal of the earth (ground) connection with loads attached.

---

3. Ground the UPS according to local and/or national electrical wiring codes by routing and connecting the ground wire to the input ground lug.
4. Connect phase A, B, and C Bypass input power wiring from the utility source to the Bypass input terminals in the 3-Breaker sidecar (upper frame area). See paragraph [3.3 UPS System Power Wiring Preparation](#) for wiring and termination requirements.
5. Route the output cables to the sidecar AC Output to Load terminals (lower frame area).
6. Connect phase A, B, and C, and Neutral power wiring from output terminals to the critical load.
7. Proceed to paragraph [4.5 Battery Power Wiring](#).

Figure 31. Eaton 93PM-L with SIAC-B (3-Breaker) Power Terminal Locations



## 4.4.4 UPS with 4 -Breaker Sidecar (RIB, BIB, MBP and MIS)

1. Drill and punch all conduit holes in the appropriate conduit plate/s prior to mounting. Install the conduit plate/s and install all conduit runs. pull wiring through conduit into sidecar and into the UPS via the inter-cabinet wiring access pass-through.
2. Route the input and output cables to the UPS terminals. See [Figure 29](#) for wiring access information, and [Figure 32](#) for terminal locations.



### WARNING

As a result of the connected loads high leakage current is possible. Connection to earth ground is required for safety and proper product operation. Do not check UPS operation by any action that includes removal of the earth (ground) connection with loads attached.

- 
3. Ground the UPS according to local and/or national electrical wiring codes by routing and connecting the ground wire to the input ground lug.
  4. Connect phase A, B, and C Bypass input power wiring from the utility source to the Bypass input terminals in the 4-Breaker sidecar (upper frame area), see [Figure 32](#) for detail. See paragraph [3.3 UPS System Power Wiring Preparation](#) for wiring and termination requirements.
  5. If wiring Single Input Feed, go to **Step 7**, otherwise continue to **Step 6**.





### IMPORTANT

Neutral must still be supplied and terminated.

- 
6. If wiring for Dual Input Feed, in the SIAC-B 4-Breaker sidecar (upper frame area) disconnect the jumper from the Bypass Input terminals and the Rectifier Input Breaker.
  7. Connect phase A, B, and C Rectifier input power wiring from the utility source to the Rectifier Input Breaker.  
  
For a detailed view of the RIB breaker terminals, see [Figure 33](#). Tighten terminals to 31nm (275 lb in) torque.
  8. Route the output cables to the sidecar AC Output to Load terminals (lower frame area).
  9. Connect phase A, B, and C, and Neutral power wiring from output terminals to the critical load.
  10. Proceed to paragraph [4.5 Battery Power Wiring](#).

Figure 32. Eaton 93PM-L with SIAC-B (4-Breaker) Power Terminal Locations



**Figure 33. 93PM-L SIAC-B RIB Terminal Detail**

## 4.5 Battery Power Wiring

### CAUTION

When sizing the battery system, do not exceed the internal battery charger capabilities. See **Chapter 9 Product Specifications**, for maximum battery charger currents.

To install wiring:

1. Route and connect the battery cables between the UPS and battery cabinet or battery disconnect according to the instructions in the **Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded** or the **Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate**, listed in paragraph [1.8 For More Information](#). See [Figure 24](#), [Figure 25](#), and [Figure 29](#) for wiring access information, and [Figure 27](#) for terminal locations.
2. Connect the positive, negative, and ground DC power wiring from the battery cabinet or disconnect to the UPS cabinet battery and ground terminals. See paragraph [3.3 UPS System Power Wiring Preparation](#) for wiring and termination requirements. For a detailed view of the UPS terminal block, see [Figure 28](#).
3. After wiring the UPS system to the facility power and critical load, be sure to ground the system according to local and/or national electrical wiring codes.
4. If wiring interface connections, proceed to paragraph [4.6 Installing Interface Connections](#); otherwise, proceed to **Step 5**.
5. Reinstall all safety shield panels previously removed and secure with the retained hardware.
6. If removed, reinstall the sidecar front panel and secure with the retained hardware.
7. Close the UPS outside door and secure the latch.

## 4.6 Installing Interface Connections

Use the procedures in the following paragraphs to connect the various interface connections.

lists all of the available (if installed) interface and control wiring topics, install each based on customer request and options ordered with the UPS.

**Table 20. List of Interface and Control Wiring Connection Topics**

<b>If wiring:</b>	<b>Proceed to:</b>
Building Alarm and Relay Contact Connections	<a href="#">4.6.1 Installing Building Alarm and Relay Contact Connections</a>
Sidecar MIS and RIB Breaker Monitoring Connections	<a href="#">4.6.2 Sidecar MIS and RIB Breaker Monitoring Connections</a>
Battery Detect Connections	<a href="#">4.6.3 Installing Battery Detect Interface Connections</a>
Battery Shunt Trip and Battery Aux Connections	<a href="#">4.6.4 Installing Battery Shunt Trip and Battery Aux Interface Connections</a>
Bypass Shunt Trip Connections	<a href="#">4.6.5 Bypass Shunt Trip Connections</a>
Generator Interface Connections	<a href="#">4.6.6 Generator Interface Connections</a>
External Parallel CAN Control Wiring and Connections	<a href="#">4.6.7 External Parallel CAN Control Wiring and Connections</a>
External Parallel Pull Chain Control Wiring and Connections	<a href="#">4.6.8 External Parallel Pull Chain Control Wiring and Connections</a>
Minislot Interface Connections	<a href="#">4.6.9 Installing Minislot Interface Connections</a>
REPO (Remote Power Off) Switch Connections	<a href="#">4.7 Installing a REPO Switch</a>

### 4.6.1 Installing Building Alarm and Relay Contact Connections

- NOTE 1** If installing interface wiring connections between standalone cabinets or separate devices, conduit must be installed between each cabinet or device.
- NOTE 2** Disconnect terminal block plugs from terminal blocks to wire plugs.


To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If wiring the interface terminals from the bottom of the UPS, proceed to **Step 8**; otherwise, proceed to **Step 4**.
4. **Top Entry Wiring.** Remove the top interface entry conduit landing plates to drill or punch holes (see [Figure 24](#), [Figure 25](#), or [Figure 29](#)).
5. Reinstall the interface entry plates and install the conduit.


6. Route the UPS building alarm and relay output interface wiring through the top interface entry conduit landing plates to the UPS building alarm and relay output terminals. See [Figure 34](#) and [Figure 35](#) for UPS interface terminal locations.
7. Proceed to **Step 13**.
8. **Bottom Entry Wiring.** Remove the bottom interface entry conduit landing plates to drill or punch holes (see [Figure 36](#)).
9. Reinstall the interface entry plates and install the conduit.
10. Route the UPS building alarm and relay output interface wiring through the bottom interface entry conduit landing plates to the bottom access interface wiring channel along the inside of the front door.
11. Route the wiring along the interface wiring channel.
12. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
13. Connect the building alarm interface wiring to the building alarm terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#) and [Table 21](#) for wiring and termination requirements, and [Figure 38](#) for terminal assignments.
14. Connect the relay output interface wiring to the relay output terminals. See [Table 22](#) for wiring and termination requirements, and [Figure 39](#) for terminal assignments.
15. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 16**.
16. Close the UPS outside door and secure the latch.




**Figure 34. Interface Terminal Locations**




**Figure 35. Interface Terminal Detail**



**Figure 36. Bottom Access Interface Wiring Location**




**Figure 37. Wire Tie Anchors**



**Table 21. Building Alarm Connections and Wire Terminations**

Terminal	Name	Description	Recommended Minimum Wire Size	Size of Pressure Termination	Tightening Torque
10	Building Alarm 1				
9	Building Alarm 1 Return				
8	Building Alarm 2				
7	Building Alarm 2 Return				
6	Building Alarm 3	Input: Programmable UPS alarm, activated by a remote dry contact closure	Twisted Pair Wires #18 AWG	#14 #30 AWG	2 lb in (0.22-0.25 Nm)
5	Building Alarm 3 Return				
4	Building Alarm 4				
3	Building Alarm 4 Return				
2	Building Alarm 5				
1	Building Alarm 5 Return				


**Figure 38. Building Alarm Terminal Block Connector Assignments**



**Table 22. Relay Contact Connections and Wire Terminations**

Terminal	Name	Description	Recommended Minimum Wire Size	Size of Pressure Termination	Tightening Torque
1	Relay Contact NC	Output: General purpose normally-closed (NC) relay contact	Twisted Pair Wires #18 AWG	#14 #30 AWG	2 lb in (0.22-0.25 Nm)
3	Relay Contact Common				
2	Relay Contact NO	Output: General purpose normally-open (NO) relay contact			
3	Relay Contact Common				

**Figure 39. Relay Contact Terminal Block Connector Assignments**



#### 4.6.2 Sidecar MIS and RIB Breaker Monitoring Connections

**NOTE 1** In a 2 Breaker Sidecar; only the Maintenance Bypass Breaker (MBP) is pre-wired for monitoring.



**NOTE 2** In a 3 or 4 Breaker Sidecar; both the Maintenance Bypass Breaker (MBP) and the Bypass Input Breaker (BIB) are pre-wired for monitoring.


To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already removed, loosen the bottom screws and completely remove the top screws securing the sidecar front panel. Lift the panel upwards and remove from the unit. Retain the hardware for later use.
3. Route the wiring along the sidecar interface wiring channel to the sidecar terminals, TB1 and TB2.
4. Secure the wiring to the wire tie anchors provided using Zip ties.
5. If 2, 3 or 4 Breaker Sidecar and monitoring of the Maintenance Isolation Breaker (MIS) is required, connect the building alarm interface wiring to TB1. See paragraph [3.5 UPS System Interface Wiring Preparation](#) and [Table 23](#) for wiring and termination requirements, and [Figure 40](#) for terminal assignments.
6. If 4 Breaker Sidecar and monitoring of the Rectifier Input Breaker (RIB) is required, connect the building alarm interface wiring to TB2.
7. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 8**.
8. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
9. Reinstall the sidecar front panel and secure with the retained hardware.
10. Close the UPS outside door and secure the latch.

**Table 23. Sidecar MIS and RIB Breaker Monitoring Connection and Wire Terminations**

Terminal Block	Terminal	Name	Recommended Minimum Wire Size	Size of Pressure Termination	Tightening Torque
TB1	9	MIS - Aux COM	Twisted Pair Wires #18 AWG	#14 #30 AWG	2 lb in (0.22-0.25 Nm)
	10	MIS - Aux NC			
TB2	9	RIB - Aux COM			
	10	RIB - Aux NC			

**Figure 40. Sidecar TB1 and TB2 Terminal Locations**



### 4.6.3 Installing Battery Detect Interface Connections

**NOTE 1** If installing interface wiring connections between standalone cabinets, conduit must be installed between cabinets.

**NOTE 2** Refer to the *Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded* or the *Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate*, listed in paragraph [1.8 For More Information](#), for battery cabinet wiring access information and instructions.

To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If wiring the battery detect connections using the inter-cabinet wiring access pass-through (line-up-and-match configurations), proceed to [Step 4](#); if wiring the battery interface connections using bottom entry access, proceed to [Step 6](#); if wiring the battery interface connections using top entry access, proceed to [Step 10](#).
4. **Pass-through Wiring.** Route the battery detect wiring from the battery cabinet through the bottom UPS inter-cabinet wiring access pass-through and static switch shelf bushing to the UPS battery shunt trip terminals (CN8 terminal block). See [Figure 26](#) for UPS wiring access information, and [Figure 34](#) for terminal location.
5. Proceed to [Step 13](#).
6. **Bottom Entry Wiring.** Route the battery detect wiring from the battery cabinet through the bottom interface entry conduit landing plate to the bottom access interface wiring channel along the inside of the front door. (See [Figure 36](#)).
7. Route the wiring along the interface wiring channel to the UPS battery shunt trip terminals (CN8 terminal block), see [Figure 34](#) for terminal location.
8. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
9. Proceed to [Step 13](#).
10. **Top Entry Wiring.** Route the battery detect wiring from the battery cabinet through the top interface entry conduit landing plate to the UPS battery shunt trip terminals (CN8 terminal block).
11. Route the wiring along the interface wiring channel to the UPS battery shunt trip terminals (CN8 terminal block), see [Figure 34](#) for terminal location.
12. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
13. Connect the wiring to the assigned terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#) and [Table 24](#) for wiring and termination requirements, and [Figure 41](#) for terminal assignments.
14. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to [Step 15](#).
15. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
16. If removed, reinstall the sidecar front panel and secure with the retained hardware.
17. Close the UPS outside door and secure the latch.

#### 4.6.4 Installing Battery Shunt Trip and Battery Aux Interface Connections

**NOTE 1** If installing interface wiring connections between standalone cabinets, conduit must be installed between cabinets.



**NOTE 2** Refer to the *Eaton 93PM Integrated Battery Cabinet Installation Manual-Small Welded* or the *Eaton 93PM Universal Integrated Battery Cabinet Installation Manual-Large and Large High Rate*, listed in paragraph [1.8 For More Information](#), for battery cabinet wiring access information and instructions.


To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If not already removed, remove the screws securing the bottom internal safety shield panel and remove the panel. Retain the hardware for later use.
4. Remove the screws securing the internal safety shield panel above the bottom safety panel and remove the panel to gain access to the battery shunt trip wiring terminals. Retain the hardware for later use.
5. If wiring the battery shunt trip and/or battery aux connections using the inter-cabinet wiring access pass-through (line-up-and-match configurations), proceed to [Step 6](#); if wiring the battery shunt trip and/or battery aux connections using bottom entry access, proceed to [Step 8](#); if wiring the battery shunt trip and/or battery aux connections using top entry access, proceed to [Step 12](#).
6. **Pass-through Wiring.** Route the battery shunt trip wiring (and/or battery aux wiring) from the battery cabinet through the bottom UPS inter-cabinet wiring access pass-through and static switch shelf bushing to the UPS battery shunt trip terminals (CN8 terminal block). See [Figure 26](#) for UPS wiring access information, and [Figure 34](#) for terminal location.
7. Proceed to [Step 15](#).
8. **Bottom Entry Wiring.** Route the battery shunt trip wiring (and/or battery aux wiring) from the battery cabinet through the bottom interface entry conduit landing plate to the bottom access interface wiring channel along the inside of the front door. (See [Figure 36](#)).
9. Route the wiring along the interface wiring channel to the UPS battery shunt trip terminals (CN8 terminal block), see [Figure 34](#) for terminal location.
10. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
11. Proceed to [Step 15](#).
12. **Top Entry Wiring.** Route the battery shunt trip wiring (and/or battery aux wiring) from the battery cabinet or battery disconnect through the top of the UPS sidecar and the bottom UPS inter-cabinet wiring access pass-through and static switch shelf bushing to the CN8 terminal block.
13. Route the wiring along the interface wiring channel to the UPS battery shunt trip terminals (CN8 terminal block), see [Figure 34](#) for terminal location.
14. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
15. Connect the wiring to the assigned terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#) and [Table 24](#) for wiring and termination requirements, and [Figure 41](#) for terminal assignments.
16. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to [Step 17](#).
17. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.



18. If removed, reinstall the sidecar front panel and secure with the retained hardware.
19. Close the UPS outside door and secure the latch.

**Figure 41. Bypass Shunt Trip, Battery Shunt Trip and Detect Terminal Detail**



**Table 24. Shunt Trip and Battery Detect Connections and Wire Terminations**

Terminal	Name	Description	Recommend- ed Minimum Wire Size	Size of Pressure Termination	Tightening Torque
1	48 Vdc Bypass Shunt Trip –	Output: Contacts used to open bypass breaker or disconnect	Twisted Pair Wires #18 AWG	#14 #30 AWG	2 lb in (0.22-0.25 Nm)
2	48 Vdc Bypass Shunt Trip +				
5	48 Vdc Battery Shunt Trip –	Output: Contacts used to open battery breaker or disconnect			
6	48 Vdc Battery Shunt Trip +				
7	48 Vdc Battery Aux 1–A	Input: Contacts used to monitor auxiliary contacts on battery breaker or disconnect			
8	48 Vdc Battery Aux 1–B				

#### 4.6.5 Bypass Shunt Trip Connections

- 
- NOTE 1** If installing interface wiring connections between standalone cabinets, conduit must be installed between cabinets.
- NOTE 2** Disconnect terminal block plugs from terminal blocks to wire plugs.
- 

To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If not already removed, remove the screws securing the bottom internal safety shield panel and remove the panel. Retain the hardware for later use.
4. If wiring the bypass shunt trip connections using bottom entry access, proceed to [Step 5](#); if wiring the bypass shunt trip connections using top entry access, proceed to [Step 7](#).
5. **Bottom Entry Wiring.** Route the bypass shunt trip wiring through the bottom of the UPS to the UPS bypass shunt trip terminals. See [Figure 24](#), [Figure 25](#), or [Figure 29](#) for UPS wiring access information, and [Figure 34](#) and [Figure 35](#) for UPS terminal locations.
6. Proceed to **Step 8**.
7. **Top Entry Wiring.** Route the bypass shunt trip wiring through the top of the UPS and the bottom UPS inter-cabinet wiring access pass-through to the UPS bypass shunt trip terminals.
8. Connect the wiring to the bypass shunt trip terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#) and [Table 24](#) for wiring and termination requirements, and [Figure 41](#) for terminal assignments.
9. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 10**.
10. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
11. If removed, reinstall the sidecar front panel and secure with the retained hardware.
12. Close the UPS outside door and secure the latch.

#### 4.6.6 Generator Interface Connections

If ESS is enabled and the UPS will be fed by a site generator at any time, the On Generator building alarm must be wired and configured to a Building Alarm Input. Wiring the On Generator sensing circuit to a building alarm allows the UPS to optimize its operation with the generator by transferring the UPS from ESS mode to Normal (double conversion) mode.

- 
- NOTE 1** A UPS building alarm input is used to indicate On Generator.
- NOTE 2** Any pair of unused building alarm terminals may be used for On Generator connections.
- NOTE 3** Program the building alarm to read On Generator and for either Normally Open (default) or Normally Closed as required by the generator sensing output.
- NOTE 4** If installing interface wiring connections between standalone cabinets, conduit must be installed between cabinets.
- NOTE 5** Disconnect terminal block plugs from terminal blocks to wire plugs.
- 

To Install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If wiring the interface terminals from the bottom of the UPS, proceed to **Step 8**; otherwise, proceed to **Step 4**.
4. **Top Entry Wiring.** Remove the top interface entry conduit landing plates to drill or punch holes (see [Figure 24](#), [Figure 25](#), or [Figure 29](#)).
5. Reinstall the interface entry plates and install the conduit.
6. Route the UPS building alarm interface wiring through the top interface entry conduit landing plates to the UPS building alarm terminals. See [Figure 34](#) and [Figure 35](#) for UPS interface terminal locations.
7. Proceed to **Step 13**.
8. **Bottom Entry Wiring.** Remove the bottom interface entry conduit landing plates to drill or punch holes (see [Figure 36](#)).
9. Reinstall the interface entry plates and install the conduit.
10. Route the UPS building alarm interface wiring through the bottom interface entry conduit landing plates to the bottom access interface wiring channel along the inside of the front door .
11. Route the wiring along the interface wiring channel.
12. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
13. Connect the building alarm interface wiring to the building alarm terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#) and [Table 21](#) for wiring and termination requirements.
14. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 15**.
15. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
16. If removed, reinstall the sidecar front panel and secure with the retained hardware.
17. Close the UPS outside door and secure the latch.

#### 4.6.7 External Parallel CAN Control Wiring and Connections



**NOTE 1** If installing interface wiring connections between standalone cabinets, conduit must be installed between each cabinet.

**NOTE 2** Disconnect terminal block plugs from terminal blocks to wire plugs.

To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If wiring the external parallel CAN connections using the inter-cabinet wiring access pass-through (line-up-and-match configurations), proceed to **Step 4**; if wiring the external parallel CAN connections using bottom entry access, proceed to **Step 6**; if wiring the external parallel CAN connections using top entry access, proceed to **Step 12**.
4. **Pass-through Wiring.** Route the external parallel CAN control wiring between UPS cabinets through the top UPS inter-cabinet wiring access pass-through to the UPS external parallel terminals. See [Figure 24](#),

[Figure 25](#), or [Figure 29](#) for UPS wiring access information, and [Figure 34](#) and [Figure 35](#) for UPS interface terminal locations.

5. Proceed to **Step 15**.
6. **Bottom Entry Wiring.** Remove the bottom interface entry conduit landing plate to drill or punch holes.
7. Reinstall the interface entry plate and install the conduit.
8. Route the external parallel CAN control wiring through the bottom interface entry conduit landing plate to the bottom access interface wiring channel along the inside of the front door.
9. Route the wiring along the interface wiring channel to the UPS external parallel terminals.
10. Secure the wiring to the wire tie anchors provided using Zip ties.
11. Proceed to **Step 15**.
12. **Top Entry Wiring.** Remove the top interface entry conduit landing plate to drill or punch holes.
13. Reinstall the interface entry plate and install the conduit.
14. Route the external parallel CAN control wiring through the top interface entry conduit landing plate to the UPS external parallel terminals.
15. Connect the external parallel CAN wiring to the CAN terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#), [Table 25](#), and [Table 26](#) for wiring and termination requirements, and [Figure 42](#) between UPSs and [Figure 43](#) for wiring information and terminal assignments.
16. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 17**.
17. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
18. If removed, reinstall the sidecar front panel and secure with the retained hardware.
19. Close the UPS outside door and secure the latch.


**Table 25. External Parallel CAN and Pull Chain Connections**

External Parallel Terminal Block	Name	Description
1	Pull Chain	External parallel pull chain connections between UPSs.
2	Pull Chain Ground	
3	CAN H In	External parallel CAN input connections from previous UPS.
4	CAN L In	
5	Ground	
6	Earth	Not Used
7	CAN H Out	External parallel CAN output connections to next UPS.
8	CAN L Out	
9	Ground	
10	Earth	Not Used

**Table 26. External Parallel CAN and Pull Chain Terminal Block Terminations**

Terminal Function	Recommended Minimum Wire Size	Size of Pressure Termination	Tightening Torque Nm (lb in)	Type Screw	Comments
CAN	#18 AWG	#26-#16	0.4 (3.5) - 0.8 (7.1)	Slotted	Use shielded twisted-pair wires with drain wire for each input and return or common. Strip wire insulation back 10 millimeters to wire terminal blocks.
Pull Chain					Use twisted-pair wires for each input and return or common. Strip wire insulation back 10 millimeters to wire terminal blocks.


**Figure 42. External Parallel CAN Connections Between UPSs**



**NOTE 1** External parallel CAN connections between UPS cabinets require shielded twisted pair wire with drain wire.



**NOTE 2** Terminations are 121 ohm 1% resistors installed in the terminal block in the first and last UPS.

**Figure 43. External Parallel Terminal Block**

### External Parallel Terminal Block

#### 4.6.8 External Parallel Pull Chain Control Wiring and Connections

**NOTE 1** A UPS building alarm input is used to indicate an open MOB.

**NOTE 2** Any pair of unused building alarm terminals may be used for the MOB Aux 1 connections.



**NOTE 3** Program the MOB building alarm to read MOB open and for normally closed contacts.

**NOTE 4** If installing interface wiring connections between standalone cabinets, conduit must be installed between cabinets.


**NOTE 5** Disconnect terminal block plugs from terminal blocks to wire plugs.

To install wiring:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If wiring the external parallel pull chain connections using the inter-cabinet wiring access pass-through (line-up-and-match configurations), proceed to **Step 4**; if wiring the external parallel CAN connections using bottom entry access, proceed to **Step 6**; if wiring the external parallel CAN connections using top entry access, proceed to **Step 12**.
4. **Pass-through Wiring.** Route the external parallel pull chain control wiring between UPS cabinets through the top UPS inter-cabinet wiring access pass-through to the UPS external parallel terminals. See [Figure 24](#), [Figure 25](#), or [Figure 29](#) for UPS wiring access information, and [Figure 34](#) and [Figure 35](#) for UPS interface terminal locations.
5. Proceed to **Step 15**.
6. **Bottom Entry Wiring.** Remove the bottom interface entry conduit landing plate to drill or punch holes.

7. Reinstall the interface entry plate and install the conduit.
8. Route the external parallel pull chain control wiring through the bottom interface entry conduit landing plate to the bottom access interface wiring channel along the inside of the front door.
9. Route the wiring along the interface wiring channel to the UPS external parallel terminals.
10. Secure the wiring to the wire tie anchors provided using Zip ties.
11. Proceed to **Step 15**.
12. **Top Entry Wiring.** Remove the top interface entry conduit landing plate to drill or punch holes.
13. Reinstall the interface entry plate and install the conduit.
14. Route the external parallel CAN control wiring through the top interface entry conduit landing plate to the UPS external parallel terminals.
15. Connect the external parallel pull chain wiring to the pull chain and building alarm terminals. See paragraph [3.5 UPS System Interface Wiring Preparation](#), [Table 25](#), and [Table 26](#) for wiring and termination requirements, and [Figure 44](#) and [Figure 43](#) for wiring information and terminal assignments.
16. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 17**.
17. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
18. If removed, reinstall the sidecar front panel and secure with the retained hardware.
19. Close the UPS outside door and secure the latch.

**Figure 44. External Parallel Pull Chain Wiring**



**NOTE 1** External parallel pull chain connections between the UPS and MOB Aux contacts require twisted pair wire.



**NOTE 2** NC and NO designations on MOB AUX contacts are defined with breaker in OFF (open) position.

**NOTE 3** Always confirm contact operation prior to wiring.

**NOTE 4** Any pair of unused building alarm terminals may be used for the MOB Aux 1 connections.



#### 4.6.9 Installing Minislot Interface Connections

**NOTE 1** LAN drop for use with Minislot cards must be provided by the customer.



**NOTE 2** When installing interface wiring connections, conduit must be installed between each device and the UPS cabinet.

**NOTE 3** Remove the cabinet stiffener bar (see [Figure 34](#)) before installing or removing Minislot cards. Reinstall the bar after the procedure is completed.

For installation and setup of a Minislot card, contact an Eaton service representative (see paragraph [1.9 Getting Help](#)).

To install wiring:

1. If not already installed, install the LAN drop.
2. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
3. If wiring a Minislot card from the bottom of the UPS, proceed to **Step 8**; otherwise, proceed to **Step 4**.
4. Remove the top interface entry conduit landing plate to drill or punch holes (see [Figure 24](#), [Figure 25](#), or [Figure 29](#)).
5. Reinstall the interface entry plate and install the conduit.
6. Route the Minislot card interface wiring through the top interface entry conduit landing plate to the Minislot card terminals. See [Figure 34](#) Minislot card locations.
7. Proceed to **Step 13**.
8. Remove the bottom interface entry conduit landing plate to drill or punch holes (see [Figure 36](#)).
9. Reinstall the interface entry plate and install the conduit.
10. Route the Minislot card interface wiring through the bottom interface entry conduit landing plate to the bottom access interface wiring channel along the inside of the front door.
11. Route the wiring along the interface wiring channel to the Minislot card terminals.
12. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
13. Install the LAN and other cables to the appropriate Minislot cards. Refer to the manual supplied with the Minislot card for terminal assignments.
14. Refer to the manual supplied with the Minislot card for operator instructions.
15. If wiring additional interface or control wiring options, see [Table 20](#) for next option to install; otherwise, proceed to **Step 16**.
16. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
17. If removed, reinstall the sidecar front panel and secure with the retained hardware.
18. Close the UPS outside door and secure the latch.


## 4.7 Installing a REPO Switch

A latching-type Remote Emergency Power-off (REPO) switch can be used in an emergency to shut down the UPS and remove power to the critical load from a location away from where the UPS is installed. [Figure 45](#) shows a REPO switch.

- 
- NOTE 1** Before installing a REPO switch, verify that the UPS was installed according to the instructions in paragraphs [4.2 Unloading the UPS Cabinet from the Pallet](#) through [4.5 Battery Power Wiring](#).
- NOTE 2** When installing the REPO switch, you must install conduit between the device and the UPS cabinet for wiring the switch.
- NOTE 3** The REPO switch must be a Normally-open or Normally-closed latching-type switch not tied into any other circuits.
- NOTE 4** This procedure is intended for installing the Eaton-supplied REPO switch. If installing another manufacturer's switch, use this procedure, and [Figure 47](#) and [Figure 48](#) as a guide.
- NOTE 5** The REPO switch wiring must be in accordance with NEC Article 725 Class 2 requirements.
- NOTE 6** Disconnect terminal block plugs from terminal blocks to wire plugs.
- 


To Install a REPO switch:

1. Verify the UPS system is turned off and all power sources are removed. See **Chapter 6 UPS Operating Instructions**, for shutdown instructions.
2. Securely mount the REPO switch. Recommended locations include operator's consoles or near exit doors. See [Figure 15](#) for enclosure dimensions and wiring knockouts.
3. If not already opened, open the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
4. If wiring the REPO terminals from the bottom of the UPS, proceed to **Step 9**; otherwise, proceed to **Step 5**.
5. Remove the top interface entry conduit landing plate to drill or punch holes (see [Figure 24](#), [Figure 25](#), or [Figure 29](#)).
6. Reinstall the interface entry plate and install the conduit.
7. Route the REPO wiring through the top interface entry conduit landing plate to the REPO terminals. See [Figure 34](#) and [Figure 35](#) for UPS interface terminal locations.
8. Proceed to **Step 14**.
9. Remove the bottom interface entry conduit landing plate to drill or punch holes (see [Figure 36](#)).
10. Reinstall the interface entry plate and install the conduit.

**Figure 45. REPO Switch**

11. Route the REPO wiring through the bottom interface entry conduit landing plate to the bottom access interface wiring channel along the inside of the front door.
12. Route the wiring along the interface wiring channel.
13. Secure the wiring to the wire tie anchors provided (see [Figure 37](#)) using Zip ties.
14. Connect the REPO wiring as shown in [Table 27](#) and [Figure 47](#) for a normally-open REPO or [Table 28](#) and [Figure 48](#) for a normally-closed REPO for a normally-closed REPO. See paragraph [3.5 UPS System Interface Wiring Preparation](#) for wiring and termination requirements, and [Figure 46](#) for terminal assignments.
15. If using a normally-closed REPO switch, connect a jumper wire between pins 3 and 4 on the REPO terminal block.
16. If you are installing multiple REPO switches, wire additional switches in parallel with the first REPO.
17. If required, install wiring from the REPO switch to the trip circuitry of the upstream protective devices. A second contact block is provided on the REPO switch for this function (see [Figure 45](#)). The REPO switch wiring must be in accordance with NEC Article 725 Class 2 requirements.
18. If removed, reinstall all safety shield panels previously removed and secure with the retained hardware.
19. If removed, reinstall the sidecar front panel and secure with the retained hardware.
20. Close the UPS outside door and secure the latch.


**Figure 46. REPO Terminal Block Connector Assignments**



**Table 27. Normally-Open REPO Connections and Wire Terminations**


From REPO Station Switch Contact Block (Either Block)	UPS REPO Terminal	Name	Description	Recommended Minimum Wire Size	Size of Wire Termination	Tightening Torque
3 NO	3	EPO_A	Input: Normally-open dry contact used to activate UPS EPO from a remote switch	Twisted Pair Wires #18 AWG	#16 #30 AWG	2 lb in (0.22-0.25 Nm)
4 NO	4	EPO_B				

**Figure 47. Normally-Open REPO Switch Wiring**



**Table 28. Normally-Closed REPO Connections and Wire Terminations**

From REPO Station Switch Contact Block (Either Block)	UPS REPO Terminal	Name	Description	Recommended Minimum Wire Size	Size of Wire Termination	Tightening Torque
3 NO	1	EPO_A_B	Input: Normally-closed dry contact used to activate UPS EPO from a remote switch.	Twisted Pair Wires #18 AWG	#16 #30 AWG	2 lb in (0.22-0.25 Nm)
4 NO	2	GND-ISO				

**Figure 48. Normally-Closed REPO Switch Wiring**

## 4.8 Initial Startup

Startup may be performed by the customer's battery qualified electrical contractor for single (not parallel) UPS installations without any accessory cabinets such as an External Battery Cabinet.

Startup and operational checks for parallel systems or installations with accessory cabinets must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on the product's resources page become void. See [Chapter 10 Warranty](#) for details. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (usually a two-week notice is required) to reserve a preferred startup date.

## 4.9 Completing the Installation Checklist

The final step in installing the UPS system is completing the following Installation Checklist. This checklist ensures that you have completely installed all hardware, cables, and other equipment. Complete all items listed on the checklist to ensure a smooth installation. Make a copy of the Installation Checklist before filling it out, and retain the original.

After the installation is complete, an Eaton Customer Service Engineer must verify the operation of the UPS system and commission it to support the critical load. The service representative cannot perform any installation tasks other than verifying software and operating setup parameters. Service personnel may request a copy of the completed Installation Checklist to verify all applicable equipment installations have been completed.

**NOTE**

The Installation Checklist **MUST** be completed prior to starting the UPS system for the first time.

---

### 4.10 Installation Checklist

- All packing materials and restraints have been removed from each cabinet.
- The UPS cabinet is placed in its installed location.
- All conduits and cables are properly routed to the UPS and any ancillary cabinets.
- All power cables are properly sized and terminated.
- Battery cables are terminated on E4 (+) and E5 (-).
- Battery shunt trip signal wiring is connected from the UPS to the battery disconnect.
- Battery detect signal wiring is connected from the UPS to the battery disconnect.
- A ground conductor is properly installed.
- Building alarms and alarm relays are wired appropriately. (Optional)
- LAN drops are installed. (Optional)
- LAN connections have been completed. (Optional)
- The REPO device is mounted in its installed location and its wiring is terminated inside the UPS cabinet. (Optional)
- A jumper wire is connected between pins 3 and 4 on the REPO terminal block if using a normally-closed REPO switch. (Optional)
- All internal safety shields are installed.
- Accessories are mounted in installed locations and wiring is terminated inside the UPS cabinet. (Optional)
- Air conditioning equipment is installed and operating correctly.
- The area around the installed UPS system is clean and dust-free. (Eaton recommends that the UPS be installed on a level floor suitable for computer or electronic equipment.)
- Adequate workspace exists around the UPS and other cabinets.
- Adequate lighting is provided around all UPS equipment.
- A 120 Vac service outlet is located within 7.5m (25 ft) of the UPS equipment.
- Startup and operational checks are performed by an authorized Eaton Customer Service Engineer for parallel systems or installations with accessory cabinets.
- Visit [www.eaton.com/pg/register](http://www.eaton.com/pg/register) to register your new Eaton UPS / Eaton UPS Accessory.

**Notes**

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---





## Chapter 5 Understanding UPS Operation

### 5.1 UPS System Overview

The Eaton 93PM-L UPS is a continuous-duty, solid-state, transformerless, three-phase, true online system that provides conditioned and uninterruptible AC power to the UPS system's output and critical load.

The basic system consists of a rectifier, battery converter, inverter, monitoring/operation control panel, integrated communication server, and digital signal processor (DSP) logic. [Figure 49](#) shows the main elements of the UPS system.

If utility power is interrupted or falls outside the parameters specified in **Chapter 9 Product Specifications**, the UPS uses a backup battery supply to maintain power to the critical load for a specified period of time or until the utility power returns. For extended power outages, the UPS allows you to either transfer to an alternative power system (such as a generator) or shut down your critical load in an orderly manner.

The emergency bypass consists of a continuous duty static switch. The static switch is armed and ready during normal operation.




#### IMPORTANT

In case of customer installed bypass breaker, the shunt trip and auxiliary should be connected to the static switch. The shunt trip voltage provided by the UPS is 48V DC.

This unit is a four-wire device. The loss of a single input phase or the loss of neutral with unbalanced four-wire loads will be considered a complete loss of input power and discharge the battery to provide power to the load.

**Figure 49. Main Elements of the UPS System**



### 5.2 Single UPS

A single UPS operates independently to support an applied load from the inverter, providing conditioned and uninterruptible AC power to the critical load from the output of the module. During an outage, the inverter continues to operate, supporting power to the load from the battery supply. If the unit requires service, applied loads are transferred to the internal bypass either automatically or manually. With the exception of an optional external battery cabinet, no other cabinets or equipment are required for the single UPS to successfully support its applied loads.

#### 5.2.1 Modes

The Eaton 93PM-L UPS supports a critical load in four different modes of operation:

- In Energy Saver System (ESS) mode, commercial AC power is supplied directly to the critical load through the internal bypass and transfers automatically to Normal mode (double-conversion on demand) if an abnormal condition is detected. The battery charger also provides charging current for the battery, if needed.
- In Normal (double-conversion) mode, the critical load is supplied by the inverter, which derives its power from rectified utility AC power. In this mode, the battery charger also provides charging current for the battery, if needed.
- In Bypass mode, the critical load is directly supported by utility power. The battery charger also provides charging current for the battery, if needed.
- In Battery mode, the battery provides DC power, which maintains inverter operation. The battery supports the critical load.

The following paragraphs describe the differences in the UPS operating modes, using block diagrams to show the power flow during each mode of operation.

#### 5.2.2 Energy Saver System Mode


When the UPS is operating in ESS mode, commercial AC power is supplied directly to the critical load through the internal bypass with the power module in a standby state. Surge protection and some filtering is also provided, ensuring that clean power is delivered to the load equipment. If a commercial power brownout, blackout, overvoltage, undervoltage, out-of-tolerance frequency condition occurs, or any other disturbance is detected in the incoming power, the system forward transfers to normal mode (double-conversion on demand). In case of a complete utility outage or if input power is outside the tolerances of the system, the UPS transfers to battery mode and continues to supply conditioned, clean power to the critical load. When the input line returns to normal operating range, the UPS returns to ESS operation. For charging batteries, the UPS will not enter ESS mode until charger output is 25% or less of maximum charger current.

When operating in ESS, the UPS detection and control algorithms continuously monitor incoming power quality and allow the fast engagement of power converters. Typical transition time to double conversion is less than two milliseconds, which is practically seamless. If the UPS detects a fault condition while operating in ESS, it is also able to detect and determine whether the fault is caused by the load or if it is upstream from the UPS. A fault at the bypass source results in an immediate switch over to the inverter. A fault in the utility switches the UPS out of Energy Saver System (ESS) mode while a fault in the load keeps the UPS in ESS mode.

When power conditions are within acceptable limits, the UPS operates as a high-efficiency, energy-saving system — providing surge protection for IT equipment and ensuring clean power is delivered to the critical load. Energy saver system increases system efficiency to 99% at 100% linear load and nominal  $V_{in}$ .

[Figure 50](#) shows the path of electrical power through the UPS system when the UPS is operating in Energy Saver System Mode.

ESS mode is a normal operating mode, and not an alarm condition. While the UPS is in this mode, the NORMAL light on the front display will illuminate.

**Figure 50. Path of Current Through the UPS in Energy Saver System Mode**

### 5.2.3 Normal Mode

During Normal mode, power for the system is derived from a utility input source through the rectifier switchgear. Three-phase AC input power is converted to DC using IGBT devices to produce a regulated DC voltage to the inverter. When the battery switchgear is closed the battery is charged directly from the regulated rectifier output through a buck or boost DC converter, depending on the system voltage and the size of the battery string attached to the unit.

[Figure 51](#) shows the path of electrical power through the UPS system when the UPS is operating in Normal mode.

The battery converter derives its input from the regulated DC output of the rectifier and provides a bucked regulated DC voltage charge current to the battery. The battery is always connected to the UPS and ready to support the inverter should the utility input become unavailable.


The inverter produces a three-phase AC output to a customer's load without the use of a transformer. The inverter derives regulated DC from the rectifier and uses IGBT devices and pulse-width modulation (PWM) to produce a regulated and filtered AC output. The AC output of the inverter is delivered to the system output through the inverter switchgear.

If the utility AC power is interrupted or is out of specification, the UPS automatically switches to Battery mode to support the critical load without interruption. When utility power returns, the UPS returns to Normal mode.

If the UPS becomes overloaded or unavailable, the UPS switches to Bypass mode. The UPS automatically returns to Normal mode when the overload condition is cleared and system operation is restored within specified limits.

If the UPS suffers an internal failure and is configured for capacity, it switches automatically to Bypass mode and remains in that mode until the failure is corrected and the UPS is back in service.

**Figure 51. Path of Current Through the UPS in Normal Mode**



### 5.2.4 Bypass Mode

**⚠ CAUTION**

The critical load is not protected from voltage or frequency fluctuations or power outages while the UPS is in Bypass mode.


The UPS automatically switches to Bypass mode if it detects an overload, load fault, or internal failure (if configured for capacity). If configured for redundancy (N+1) the UPS would remain on line in Normal mode if one UPM failed. The UPS can also be transferred from Normal mode to Bypass mode manually. The bypass source supplies the commercial AC power to the load directly. [Figure 52](#) shows the path of electrical power through the UPS system when operating in Bypass mode.

In Bypass mode, the output of the system is provided with three-phase AC power directly from the system input. While in this mode, the output of the system is not protected from voltage or frequency fluctuations or power outages from the source. Some power line filtering and spike protection is provided to the load but no active power conditioning or battery support is available to the output of the system in the Bypass mode of operation.

The internal bypass is comprised of a solid-state, silicon-controlled rectifier (SCR) continuous static switch. The static switch is used instantaneously anytime the inverter is unable to support the applied load. The continuous static switch is wired in parallel with the rectifier and inverter.

The static switch, being an electronically-controlled device, can be turned on immediately to pick up the load from the inverter while the inverter switchgear opens to isolate the inverter.

If the UPS transfers to Bypass mode from Normal mode due to any reason other than operator intervention, the UPS automatically attempts to transfer back to Normal mode (up to three times within a ten minute period). The fourth transfer locks the critical load to the bypass source and requires operator intervention to transfer.

**Figure 52. Path of Current Through the UPS in Bypass Mode**

### 5.2.5 Battery Mode

The UPS automatically transfers to Battery mode if a utility power outage occurs, or if the utility power does not conform to specified parameters. In Battery mode, the battery provides emergency DC power that the inverter converts to AC power.


[Figure 53](#) shows the path of electrical power through the UPS system when operating in Battery mode.

During a utility power failure, the rectifier no longer has an AC utility source from which to supply the DC output voltage required to support the inverter. The rectifier switchgear opens and the battery instantaneously supplies energy to the battery converter. The converter boosts the voltage so that the inverter can support the customer's load without interruption. The opening of the rectifier switchgear prevents system voltages from bleeding backwards through the static switch and rectifier snubber components to the utility source.

If the input power fails to return or is not within the acceptance windows required for normal operation, the battery continues discharging until a DC voltage level is reached where the inverter output can no longer support the connected loads. When this event occurs, the UPS issues another set of audible and visual alarms indicating SHUTDOWN IMMINENT. Unless the rectifier has a valid AC input soon, the output can be supported for only two minutes before the output of the system shuts down. If the bypass source is available, the UPS transfers to bypass instead of shutting down.

If at any time during the battery discharge the input power becomes available again, the rectifier switchgear closes and the rectifier begins to supply DC current to the converter and inverter. At this point, the unit returns to Normal mode. Depending on the total load and the duration of the battery discharge, battery current limit alarms may be seen for a short time due to the current required to recharge the battery.

**Figure 53. Path of Current Through the UPS in Battery Mode**



### 5.3 Single UPS Unit System Online Configurations

The system online drawings in this section show the simplified internal structure of the UPS, battery supply, and basic maintenance bypass.

Online Drawing	UPS Model	Voltage		System Type
		Input	Output	
See <a href="#">Figure 54</a>	93PM-L 60			Single three UPM reverse transfer UPS with internal and/or external battery
See <a href="#">Figure 55</a>	Eaton 93PM-L 60 with Top Entry Sidecar	208 or 220	208 or 220	Single three UPM reverse transfer UPS with internal and/or external battery with Top Entry Sidecar
See <a href="#">Figure 56</a>	Eaton 93PM-L 60 with Bypass Sidecar (SIAC-B)			Single three UPM reverse transfer UPS with internal and/or external battery with Bypass Sidecar (SIAC-B)

Figure 54. Eaton 93PM-L 60 UPS System Online








Figure 55. Eaton 93PM-L 60 UPS with Top Entry Sidecar System Online



NOTES:

1. AC INPUT TO RECTIFIER IS NOT USED IN SINGLE FEED CONFIGURATION.
2. DASHED LINES INSIDE OF UPS BOX INDICATE OPTIONAL UPM'S OR INTERNAL BATTERIES. CONFIGURABLE FROM 1-3 UPM'S.
3. DASHED LINES OUTSIDE OF UPS OR TOP ENTRY SIDECAR BOX INDICATE OPTIONAL EQUIPMENT CABINETS.
4. BACKFEED PROTECTION IS NOT PROVIDED AS A PART OF UPS. CUSTOMER SUPPLIED BYPASS INPUT BREAKER WITH 48-60VDC SHUNT TRIP IS REQUIRED.

Figure 56. Eaton 93PM-L 60 UPS with Bypass Sidecar (SIAC-B) System Online



NOTES:

1. AC INPUT TO RECTIFIER IS NOT USED IN SINGLE FEED CONFIGURATION.
2. DASHED LINES INSIDE OF UPS BOX INDICATE OPTIONAL UPM'S OR INTERNAL BATTERIES. CONFIGURABLE FROM 1-3 UPM'S.
3. DASHED LINES INSIDE OF SIAC-B BOX INDICATE OPTIONAL COMPONENTS OR BYPASS JUMPER.
4. DASHED LINES OUTSIDE OF UPS OR SIAC-B BOX INDICATE OPTIONAL EQUIPMENT CABINETS.
5. BACKFEED PROTECTION IS NOT PROVIDED AS A PART OF UPS. CUSTOMER SUPPLIED BYPASS INPUT BREAKER WITH 48-60VDC SHUNT TRIP IS REQUIRED IF BYPASS SIDE CAR DOES NOT INCLUDE BIB BREAKER.
6. THE SINGLE-FEED JUMPER (UPS) IS FACTORY INSTALLED WHEN THE UPS IS ORDERED WITH A 2 OR 3 BREAKER SIDE CAR.
7. THE SINGLE FEED JUMPER (SIAC-B) IS FACTORY INSTALLED WHEN THE UPS IS ORDERED WITH A 4-BREAKER SIDE CAR. THE JUMPER MUST BE REMOVED FOR A DUAL FEED INSTALLATIONS. THE 4-BREAKER SIDE CAR IS ONLY AVAILABLE WITH A DUAL FEED UPS.

## Chapter 6 UPS Operating Instructions


This section describes how to operate the UPS.

- 
- NOTE 1** Before starting the UPS, ensure all installation tasks are complete and a preliminary startup has been performed by authorized service personnel. The preliminary startup verifies all electrical interconnections to ensure the installation was successful and the system operates properly.
- NOTE 2** Read this section of the manual and have thorough knowledge of UPS operation before attempting to operate any of the controls.
- 

### 6.1 UPS Controls and Indicators

The controls and indicators identified and described in this section are used to set up, control, and monitor UPS operation. [Figure 57](#) shows the control panel location on the front door of the UPS. For a description of the UPS control panel functions, and how to control and monitor UPS operation, see paragraph [6.2 Using the Control Panel](#).


**Figure 57. UPS Controls and Indicators**



## 6.2 Using the Control Panel

The following paragraphs describe the UPS control panel, including controls and indicators, and how to monitor UPS operation. The control panel is shown in [Figure 58](#).

**Figure 58. UPS Control Panel**



The control panel consists of:

- A color liquid crystal touch screen display (1).
- A horizontal row of status indicators (2). See paragraph [6.2.1 Status Indicators](#).

The following paragraphs describe using the UPS control panel to monitor the UPS. See paragraph [6.2.3 Using the LCD Touch Screen](#) for use of the operational controls.





When the unit powers up, the screen displays the as shown in [Figure 58](#).

### 6.2.1 Status Indicators

The four symbols on the bottom of the control panel are status indicators. These colored light emitting diode (LED) lamps work with the alarm horn to provide the operating status of the UPS.

[Table 29](#) describes the status indicators.

**Table 29. Status Indicators**

Indicator	Status	Description
 Green	On	The UPS is in Double Conversion mode. The power module is supplying power to the critical load.
	Off	The UPS is turned off.
 Yellow	On	The UPS is in Battery mode. Because Battery mode is a normal condition of the UPS, the normal indicator also remains illuminated.
 Yellow	On	The UPS is in Bypass mode. The critical load is supported by the bypass source. The normal indicator is not illuminated when the system is in Bypass mode.
 Red	On	The UPS has an active alarm and requires immediate attention. The LCD shows the highest priority active alarms. All alarms are accompanied by an audible horn. To silence the horn, touch any control panel button. The Alarm indicator may be illuminated along with other indicators.
	Flashing	There is a new UPS alarm condition. The indicator flashes until acknowledged by touching any control panel button once.

### 6.2.2 System Events

When the UPS system is running in Double Conversion mode, it continually monitors itself and the incoming utility power. In Battery or Bypass modes, the UPS may issue alarms to let you know exactly what event caused the change from Double Conversion mode. System events on the UPS can be indicated by horns, lights, messages, or all three.

Select the **LOGS** tab from the navigation bar on main menu screen to display the active events screen. This screen shows any currently active alarms, notices, or commands. For more information on using the events screen, see paragraph [6.2.6 Display Menu Operation](#).


- **System Event Horns** – The system event horn beeps to alert an operator that an event needing attention is taking place. The horn cycles at a half-second rate. To silence the horn, touch any control panel button.
- **System Event Indicators** – The status indicators on the UPS control panel work with the event horn to let the operator know when the UPS is operating in any mode other than double conversion. Only the normal mode indicator is illuminated during normal UPS system operation. The other indicators illuminate to indicate alarms or events. When an alarm occurs, first check these indicators to see what type of event has taken place. For descriptions of the status indicators, see paragraph [6.2.1 Status Indicators](#).
- **System Event Messages** – When a system event occurs, a message appears on the LCD in the UPS status area. This message is also written to the Events Log and may be added to the History Log. The messages are divided into four categories: alarms, notices, status, and commands.

### 6.2.3 Using the LCD Touch Screen

The LCD touch screen on the control panel provides an operator interface with the UPS system. [Figure 59](#) identifies the display areas discussed in the following sections.

All functions and commands are accessed by touching or tapping the screen tabs or buttons. When text input is required, either a Qwerty keyboard or numeric keypad will be displayed.

Figure 59. Parts of the LCD



**A: Status Bar** displays the UPS name, UPS state, current date and time, meter information, active alarms and notices, and a sign in/sign out button. For more information about alarms and notices, see paragraph [6.2.2 System Events](#).

**B: Main Menu Navigation Bar** displays main menu functions and selections as tab buttons. To select a screen function touch the tab name.

**C: Secondary Menu Navigation Bar** displays functions and selections related to the current screen as tab buttons. To select a screen function touch the tab name.

**D: Information Area** contains status data, operational controls, acknowledgments, action confirmations, and screen prompts.

You can use the LCD touch screen to:

- Look at a log of UPS events (alarms, notices, and commands)
- Monitor UPS operation
- Set UPS parameters
- Control UPS operations

For details on these operations, see paragraphs [6.2.6 Display Menu Operation](#) and [6.2.8 System Controls](#).

#### 6.2.4 Using the Menu

The UPS navigation tab menu bar allows you to display data in the information area to help you monitor and control UPS operation. [Table 30](#) shows the basic menu structure.

**Table 30. Display Function Menu Map**

Menu Option	Description
HOME	Displays the system status both graphically (mimic) and written.
METERS	Displays performance meters for the system or critical load.
CONTROLS	Displays the Controls screen.
MIMIC	Displays the mimic screens and access to system information screens.
LOGS	Displays the list of active events and provides access to historical system events.
STATISTICS	Displays UPS statistical data (uptime, downtime, maintenance, efficiency, etc).
SETTINGS	Allows access to various screen controlled variables for the system operation. Settings include date and time for the time stamp, display language, the unit name, meter subscripts, password, and view the firmware version numbers Used only by service personnel.



**NOTE**


Screens shown are representative examples of system operation. The screen data will vary based on system activity at the time of observation.

**6.2.5 Mimic Screen**

[Figure 60](#) shows the Main Menu and Mimic screen.

The Mimic screen shows the internal components of the UPS cabinet and a real-time graphical representation of the operating status of the system.

**Figure 60. Main Menu and Mimic Screen**



## 6.2.6 Display Menu Operation

[Table 31](#) describes the menu functions and how to use them.

**Table 31. Display Menu Operation**

Function	Subfunction	Operation
Home		An overview of UPS operation, including information on load, efficiency and consumption.
Meters – UPS		The meter screens show the UPS meter readings for the unit. The default voltage displayed on these screens is phase-to-neutral. These can be changed to display the voltage phase-to-phase (A-B, B-C, C-A). Tap the <b>METERS</b> tab on the main menu navigation bar to display the <b>METER SUMMARY</b> screen (see <a href="#">Figure 61</a> ). The current UPS readings are displayed in the information area of the screen. To display individual meter details, tap the desired meter button to display the detailed meter screen.
	Output – UPS	The Output screen shows output voltage (phase to neutral), output current (each phase), and frequency being supplied by the UPS, as well as the kVA, kW, and power factor measurements.
	Input – UPS	The Input screen shows input voltage (phase to neutral), input current (each phase), and frequency of the incoming utility source, as well as the kVA, kW, and power factor measurements.
	Bypass	The Bypass screen shows the bypass input voltage (phase to neutral), input current (each phase), and frequency of the incoming utility source, as well as the kVA, kW, and power factor measurements.
	Battery – UPS	The Battery screen displays the battery voltage (Vdc) and the battery current (Idc).
Mimics	UPS Mimic	Tap the <b>MIMICS</b> tab on the main menu navigation bar to display an overview of UPS operation, including information on load, efficiency and consumption. If there is an error, an error indicator is displayed next to the affected part. Active events log can be opened by tapping the error indicator.
	UPS Module Map	Tap the <b>UPS MODULE MAP</b> tab on the secondary menu navigation bar to display the status of each UPM.
	System Overview	Tap the <b>SYSTEM OVERVIEW</b> tab on the secondary menu navigation bar to display the status and meters summary for each UPS.
	ESS	Tap the <b>ESS</b> tab on the secondary menu navigation bar to display the approximate consumption and energy savings of ESS mode.
Logs	Active	Tap the <b>LOGS</b> tab on the main menu navigation bar to display the <b>ACTIVE EVENTS</b> screen (see <a href="#">Figure 62</a> ). A listing of all system events that are currently active is displayed. The most recent event is listed first. As events clear, they are removed from the Events listing. To scroll through the events, press the up or down scroll bar.
	System Log (Historical)	Tap the <b>SYSTEM LOG</b> tab on the secondary menu navigation bar to display the <b>SYSTEM LOG</b> screen (see <a href="#">Figure 63</a> ). The history Log lists up to 512 events in chronological order, with the most recent event listed last (once 512 is reached, the earliest event is overwritten). The end of the log (the most recent events) is displayed first; scroll upward to view older event listings. To scroll through the events, press the up or down scroll bar.



**Table 31. Display Menu Operation (Continued)**

Function	Subfunction	Operation
Settings		Configurable system settings. Tap the <b>SETTINGS</b> tab on the main menu navigation bar to display the settings screen. Settings may be password restricted. Settings Level 2 default password is <b>0101</b> .
	User	Tap the <b>USER</b> tab on the secondary menu navigation bar to display the USER screen (see <a href="#">Figure 64</a> ). Tap the <b>INFORMATION</b> or <b>ABOUT</b> button to display system information (see <a href="#">Figure 65</a> and <a href="#">Figure 66</a> ).
	Configuration	Tap the <b>CONFIGURATION</b> tab on the secondary menu navigation bar to display the screen. Tap the function to be changed. Make and save the changes. Follow screen prompts to accept or abort changes. For additional functions, tap the 2 button. See <a href="#">Figure 67</a> and <a href="#">Figure 68</a> for configuration screens.
Statistics	Statistics Summary	Tap the <b>STATISTICS</b> tab on the main menu navigation bar to display a summary of UPS statistics (see <a href="#">Figure 69</a> ).
	Statistics Details	Tap the desired statistic button to display the detailed statistic screen.
Controls		See paragraph <a href="#">6.2.8 System Controls</a> for details.

**Figure 61. Typical Meters Summary Screen**




Figure 62. Typical Active Events Screen




Figure 63. Typical System Log Screen




Figure 64. Typical Settings User Screen




Figure 65. Typical Information Screen




Figure 66. Typical About Screen




Figure 67. Typical Settings Configuration 1 Screen




Figure 68. Typical Settings Configuration 2 Screen





Figure 69. Typical Statistics Screen



### 6.2.7 Sign In

The Controls and Setting screens are restricted. The user must sign in using a password to gain access.

---

**CAUTION**

To prevent inadvertent or unauthorized power disruption to the critical load or auxiliary lighting system, change the Level 1 and Level 2 default passwords when system commissioning startup is performed.

---

To Sign in:

1. Tap the lock button in the upper right corner of the screen. The sign in screen is displayed (see [Figure 70](#)).
2. Tap the password entry area on the screen.
3. Enter the password using the keypad displayed and tap the return key (see [Figure 71](#)).

Level 1 default password is **1111**. Settings Level 2 default password is **0101**.

4. Sign in is complete. Tap continue to return to previous screen.

**Figure 70. Sign In Password Screen**





Figure 71. Sign In Keypad



6.2.8 System Controls

Tap the **CONTROLS** tab on the main menu navigation bar to display the Controls screen. Double conversion operation, transfer to bypass, shutdown, and charger control commands are controlled through this screen. In addition, the screen displays the current status of the UPS.

[Table 32](#) describes the control functions and provides instructions to access and use the command menu screens.

[Table 33](#) lists the typical System Status Screen Messages that are displayed during UPS operation.

[Figure 72](#) through [Figure 76](#) show the major control screens.

Table 32. Controls Menu Operation

Function	Subfunction	Operation
System Controls		The <b>CONTROLS</b> tab on the main menu navigation bar displays the System Controls screen.
	System Status	<b>GO ONLINE</b> starts the UPS in Double Conversion mode or transfers the UPS to Double Conversion mode from Bypass mode.
	Bypass	<b>GO TO BYPASS</b> starts the UPS in Bypass mode or transfers the UPS to Bypass mode from Double Conversion mode.
	Charger	<b>TURN ON CHARGER/TURN OFF CHARGER</b> sets the battery charger on or off.
	Battery Test	<b>RUN BATTERY TEST</b> starts the battery test.

**Table 33. Typical System Status Messages**

Function	Message
UPS	Double Conversion; Bypass; ESS
Bypass	Off; On; Available
Charger	Charger Resting; Charger

**Figure 72. Typical System Control Screen**






Figure 73. Typical UPS Control Screen




Figure 74. Typical UPM Select Screen




Figure 75. Typical UPM Control Screen





Figure 76. Typical EAA Control Screen



## 6.3 Single UPS Operation

---

**NOTE 1** If an Integrated Battery Cabinet (IBC) is installed, refer to its installation and operation manual, listed in **Chapter 1 Introduction, For More Information** section, for IBC battery breaker location.

 **NOTE 2** If a Sidecar Integrated Accessory Cabinet (SIAC) or an Integrated Accessory Cabinet (IAC) is installed, refer to its installation and operation manual, listed in **Chapter 1 Introduction, For More Information** section, for operating instructions.

**NOTE 3** This unit is a four-wire device. The loss of a single input phase or the loss of neutral with unbalanced four-wire loads will be considered a complete loss of input power and discharge the battery to provide power to the load.

---

### 6.3.1 Starting the UPS in Double Conversion Mode

To start the UPS system:

1. Close the UPS input feeder circuit breaker.
2. If dual feed, close the UPS bypass feeder circuit breaker.
3. If IBCs are installed, close the battery breakers. (If internal batteries are installed, close the internal battery breaker.)
4. Observe the UPS control panel display becoming active, indicating logic power.
5. Verify no alarms are active.
6. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
7. Tap the **GO ONLINE** button.
8. If requested, enter the Level 1 password. Default password is **1111**.

The rectifier and inverter turn on. The inverter continues to ramp up to full voltage.

Once the inverter reaches full voltage, the UPS inverter switchgear closes and the static switch turns off. Power is now supplied to the critical load in double conversion mode. It takes approximately one minute for the UPS to achieve the double conversion mode.

The Normal status indicator is illuminated.

### 6.3.2 Starting the UPS in Bypass Mode

If the inverter output of the UPS is not available and the critical load needs to be energized:



In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

---

1. Close the UPS input feeder circuit breaker.
2. If dual feed, close the UPS bypass feeder circuit breaker.
3. If IBCs are installed, close the battery breakers.
4. Observe the UPS control panel display becoming active, indicating logic power.
5. Verify no alarms are active.
6. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
7. Tap the **GO TO BYPASS** button.

The critical load is immediately supplied by the bypass source, in Bypass mode.

The **BYPASS** status indicator is illuminated.

### 6.3.3 Starting the UPS via DC Start Button

---

 **IMPORTANT**

---


Secure the UPS output. Performing DC start will energize UPS Output and customer loads (verify that no work is being done downstream).

If installed, verify that the Maintenance Bypass Breaker (MBP) is Open.

---

1. Open the UPS front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open.
2. Verify that the UPS input breaker is open.
3. Close the UPS input feeder circuit breaker.
4. If dual feed, close the UPS bypass feeder circuit breaker.
5. Close the UPS input breaker.
6. If the UPS contains a Rectifier Input Breaker (RIB), close the Rectifier Input Breaker.
7. If the UPS contains a battery breaker, close the UPS battery breaker.
8. If Integrated Battery Cabinets (IBCs) are installed, close the IBC battery breakers.
9. Press the DC Start button on the front of each UPM to power on the UPM power supply. (See [Figure 77](#) for DC Start Button location).

**Figure 77. DC Start Button Location**



10. Close the door and secure the latch.
11. Observe the UPS control panel display becoming active, indicating logic power.
12. Verify no alarms are active.
13. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
14. Tap the **GO ONLINE** button.

If requested, enter the Level 1 password. Default password is **1111**.

The unit will start on battery power. Restoration of utility power during this time will transfer the system to normal operation.

#### 6.3.4 Starting the UPMs

To start the power modules without transferring the critical load to Double Conversion mode:

1. Close the UPS input feeder circuit breaker.
2. If dual feed, close the UPS Bypass input feeder circuit breaker.
3. Observe the UPS control panel becoming active, indicating logic power.
4. Verify no alarms are active.
5. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
6. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
7. On the UPM Select screen, select UPM 1. The UPM Control Screen is displayed.
8. Tap the **START MODULE** button.

The UPM 1 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

9. Repeat **Steps 5** through **Step 8** selecting UPM 2 to start UPM 2.

The UPM 2 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

10. Repeat **Steps 5** through **Step 8** selecting UPM 3 to start UPM 3.

The UPM 3 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

#### 6.3.5 Starting a Single UPM

To Start a single UPM:

1. Close the UPS input feeder circuit breaker.
2. If dual feed, close the UPS Bypass input feeder circuit breaker.
3. Observe the UPS control panel becoming active, indicating logic power.
4. Verify no alarms are active.
5. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
6. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
7. On the UPM Select screen, select the UPM to start. The UPM Control Screen is displayed.
8. Tap the **START MODULE** button.

The UPM rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

#### 6.3.6 Transfer from Double Conversion to Bypass Mode

To transfer the critical load to Bypass mode:

---

 **CAUTION**


---

In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

---

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **GO TO BYPASS** button.

The UPS transfers to Bypass mode, and the critical load is immediately supplied by the bypass source. If the bypass source is not available, the power module remains on and an alarm sounds.

The **BYPASS** status indicator is illuminated. The power module remains on.

---

 **WARNING**


---

Power is present inside the UPS cabinet.

---

### 6.3.7 Transfer from Bypass to Double Conversion Mode

To transfer the critical load to Normal mode:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **GO ONLINE** button.

The UPS transfers to Double Conversion mode. If the power module is not available, the system remains on bypass and an alarm sounds.

The **NORMAL** status indicator is illuminated.

### 6.3.8 Transfer from ESS Mode to Double Conversion Mode

To transfer the load to Standard Normal mode:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **EAA CONTROLS** tab on the secondary Control menu navigation bar. The **EAA CONTROLS** screen is displayed.
3. Tap the **DISABLE ESS** button.

The UPS transfers to Double Conversion mode.

The **NORMAL** status indicator is illuminated.

### 6.3.9 Transfer from Double Conversion Mode to ESS Mode

To transfer the load to HE Normal mode:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **EAA CONTROLS** tab on the secondary Control menu navigation bar. The **EAA CONTROLS** screen is displayed.
3. Tap the **ENABLE ESS** button.

The UPS transfers to ESS mode if no abnormal power conditions are detected. If abnormal power conditions are detected, the UPS will wait and transfer to ESS mode when conditions are cleared.

The **NORMAL** status indicator is illuminated.

### 6.3.10 Transfer from Double Conversion to Bypass Mode and Shut Down UPMs

To transfer the critical load to Bypass mode and shut down the UPMs:

1. Transfer the critical load to bypass by performing the procedure in paragraph [6.3.6 Transfer from Double Conversion to Bypass Mode](#).
2. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
3. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
4. On the UPM Select screen, select UPM 1. The UPM Control Screen is displayed.
5. Tap the **SHUT DOWN MODULE** button.  
The UPM status indicates SHUTDOWN. The power module is turned off.  
Logic power remains on.
6. Repeat **Steps 2** through **Step 5** selecting UPM 2 to shut down UPM 2.  
The UPM status indicates SHUTDOWN. The power module is turned off.  
Logic power remains on.
7. Repeat **Steps 2** through **Step 5** selecting UPM 3 to shut down UPM 3.  
The UPM status indicates SHUTDOWN. The power module is turned off.  
Logic power remains on.

### 6.3.11 Single UPM Shutdown

To shut down a single UPM:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
3. On the UPM Select screen, select the UPM to shutdown. The UPM Control Screen is displayed.
4. Tap the **SHUT DOWN MODULE** button.  
The UPM status indicates SHUTDOWN. The power module is turned off. The remaining UPMs continue to supply the critical load.  
Logic power remains on.

### 6.3.12 Single UPM Restart

To restart a single UPM from a shutdown state:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
3. On the UPM Select screen, select the UPM to start. The UPM Control Screen is displayed.
4. Tap the **START MODULE** button.  
The UPM rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

### 6.3.13 UPS and Critical Load Shutdown

To perform maintenance or service on the critical load, shut down power to the load:

1. Turn off all equipment that is being powered by the UPS.
2. Perform the Load Off procedure in paragraph [6.3.16 Using the UPS LOAD OFF Command](#).

The inverter switchgear is open, and the power module is turned off.

3. Perform the battery charger off procedure in paragraph [6.3.14 Charger Control](#).

The rectifier and battery switchgear open.

---

 **WARNING**

---

Power is present inside the UPS cabinet until the upstream input feeder circuit breakers and battery breakers are opened. Wait at least 5 minutes before accessing internal components.

---

4. Open the UPS input feeder circuit breaker.
5. If dual feed, open the UPS bypass feeder circuit breaker.
6. If IBCs are installed, open all battery breakers.

### 6.3.14 Charger Control

To turn the battery charger on:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **UPS CONTROLS** tab on the secondary navigation bar. The UPS Control screen is displayed.
3. Tap the **TURN ON CHARGER** button.

To turn the battery charger off:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **UPS CONTROLS** tab on the secondary navigation bar. The UPS Control screen is displayed.
3. Tap the **TURN OFF CHARGER** button.

### 6.3.15 Battery Test

---

**NOTE 1** The UPS has a user initiated battery test intended to determine if the batteries are able to support the load.



**NOTE 2** The battery test is only able to be initiated when the battery is fully charged. This normally occurs within 72 hours of the start of a charging cycle. The command will not be shown if the test is not able to be run.

---

To start the battery test:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **UPS CONTROLS** tab on the secondary navigation bar. The UPS Control screen is displayed.
3. Tap the **RUN BATTERY TEST** button.

### 6.3.16 Using the UPS LOAD OFF Command

A UPS shutdown is initiated by the **LOAD OFF** command on the UPS Control screen. The **UPS LOAD OFF** controls the UPS output by powering down the UPS and de-energizing the critical load.

The UPS (including Bypass) remains off until restarted.

To use the **LOAD OFF** command:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.



---

 **CAUTION**


---

All power to the critical load is lost when LOAD OFF is selected in the following step. You should use this feature only when you want to de-energize the critical load.

---

2. Tap the **LOAD OFF** button.

An action confirmation screen is displayed. Follow the on screen prompts to shut down the UPS or to cancel the shutdown. Selecting **YES** will immediately shut down the UPS and de-energize the critical load. Selecting **NO** will abort the shutdown.

---

 **CAUTION**


---

Do not attempt to restart the system after Load Off until the cause of the shutdown has been identified and cleared.

---

3. To restart the UPS after using the **LOAD OFF** follow the procedure in paragraph [6.3.1 Starting the UPS in Double Conversion Mode](#) or [6.3.2 Starting the UPS in Bypass Mode](#).
- 

 **WARNING**


---

Power is present inside the UPS cabinet until the upstream input feeder circuit breakers and battery breakers are opened. Wait at least 5 minutes before accessing internal components.

---

### 6.3.17 Using the Remote Emergency Power-off Switch

---

 **WARNING**


---

Emergency Power Off (EPO) and Remote Emergency Power Off (REPO) functionality is disabled for UPS systems configured for UL 924 auxiliary lighting. To remove power from the system a LOAD OFF command (see paragraph [6.3.16 Using the UPS LOAD OFF Command](#)) must be given using the front panel controls and all breakers opened.

---

A UPS emergency power-off is initiated by the REPO pushbutton switch. In an emergency, you can use this switch to control the UPS output. The REPO switch de-energizes the critical load and powers down the UPS immediately, without asking for verification.

The UPS, including Bypass, remains off until restarted.


---

 **CAUTION**


---

All power to the critical load is lost when the REPO switch is activated in the following step. You should use this feature only when you want to de-energize the critical load.

---

 **NOTE** The following instructions are for the Eaton-supplied REPO switch. If a customer-supplied REPO switch is used, it may not activate in the same manner; refer to the operating instructions provided with the switch.

---

To use the REPO switch:

1. Firmly push the red pushbutton until it locks into place. The switch latches into the activated state (see [Figure 78](#)).

The rectifier, inverter, and battery switchgear open, and the power module is turned off immediately, without asking for verification.

---

**⚠ CAUTION**

---

Do not attempt to restart the system after the REPO until the cause of the shutdown has been identified and cleared.

---

2. To deactivate the REPO switch in preparation for restarting the UPS, insert the supplied key and rotate clockwise until the red pushbutton releases (see [Figure 78](#)). To remove the key, rotate the key back to the vertical position.
  3. Restart the UPS by following the procedure in paragraph [6.3.1 Starting the UPS in Double Conversion Mode](#) or [6.3.2 Starting the UPS in Bypass Mode](#).
- 


**⚡ WARNING**

---

Power is present inside the UPS cabinet until the upstream input feeder circuit breakers and battery breakers are opened. Wait at least 5 minutes before accessing internal components.

---

**Figure 78. REPO Operation**



## 6.4 Multiple External Parallel System Operation

---

- NOTE 1** If an Integrated Battery Cabinet (IBC) is installed, refer to its installation and operation manual, listed in **Chapter 1 Introduction, For More Information** section, for IBC battery breaker location.
- i NOTE 2** If a Sidecar Integrated Accessory Cabinet (SIAC) or an Integrated Accessory Cabinet (IAC) is installed, refer to its installation and operation manual, listed in **Chapter 1 Introduction, For More Information** section, for operating instructions.
- NOTE 3** This unit is a four-wire device. The loss of a single input phase will be considered a complete loss of input power and discharge the battery to provide power to the load.
- 

### 6.4.1 Starting the Parallel System in Double Conversion Mode

To start the UPS system:

1. Close all Module Output Breakers (MOBs).
2. Close the UPS input feeder circuit breaker.

3. If dual feed, close the UPS bypass feeder circuit breaker.
4. If IBCs are installed, close the battery breakers.
5. Observe the UPS control panel display becoming active, indicating logic power.
6. Verify no alarms are active.
7. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
8. Tap the **GO ONLINE** button.
9. If requested, enter the Level 1 password. Default password is **1111**.

The rectifier and inverter turn on. The inverter continues to ramp up to full voltage.

Once the inverter reaches full voltage, all UPS inverter switchgear close and the static switches turn off. Power is now supplied to the critical load in dual conversion mode from all UPSs. It takes approximately one minute for the UPSs to achieve the dual conversion mode.

The Normal status indicator is illuminated.

#### 6.4.2 Starting the Parallel System in Bypass Mode

If the inverter output of the UPS is not available and the critical load needs to be energized:



#### CAUTION

---

In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

---

1. Close all Module Output Breakers (MOBs).
2. Close the UPS input feeder circuit breaker.
3. If dual feed, close the UPS bypass feeder circuit breaker.
4. If IBCs are installed, close the battery breakers.
5. Observe the UPS control panel display becoming active, indicating logic power.
6. Verify no alarms are active.
7. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
8. Tap the **GO TO BYPASS** button.

The critical load is immediately supplied by the bypass source, in Bypass mode from all UPSs.

The **BYPASS** status indicator is illuminated.

#### 6.4.3 Starting the Parallel System UPMs

To start the power modules without transferring the critical load to Double Conversion mode:

1. Close the UPS input feeder circuit breaker.
2. If dual feed, close the UPS Bypass input feeder circuit breaker.
3. Observe the UPS control panel becoming active, indicating logic power.
4. Verify no alarms are active.
5. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
6. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
7. On the UPM Select screen, select UPM 1. The UPM Control Screen is displayed.

8. Tap the **START MODULE** button.  
The UPM 1 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.
9. Repeat **Step 5** though **Step 8** selecting UPM 2 to start UPM 2.  
The UPM 2 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.
10. Repeat **Step 5** though **Step 8** selecting UPM 3 to start UPM 3.  
The UPM 3 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.
11. Repeat **Step 1** through **Step 10** for each UPS in the parallel system.

#### 6.4.4 Starting a Single UPM

To Start a single UPM:

1. Close the UPS input feeder circuit breaker.
2. If dual feed, close the UPS Bypass input feeder circuit breaker.
3. Observe the UPS control panel becoming active, indicating logic power.
4. Verify no alarms are active.
5. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
6. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
7. On the UPM Select screen, select the UPM to start. The UPM Control Screen is displayed.
8. Tap the **START MODULE** button.

The UPM rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

#### 6.4.5 Transfer from Double Conversion to Bypass Mode

To transfer the critical load to Bypass mode:



In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

---

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **GO TO BYPASS** button.

All of the UPSs transfer to Bypass mode, and the critical load is immediately supplied by the bypass source. If the bypass source is not available, the power module remains on and an alarm sounds.

The **BYPASS** status indicator is illuminated. The power module remains on.

---



Power is present inside the UPS cabinet.

---

#### 6.4.6 Transfer from Bypass to Double Conversion Mode

To transfer the critical load to Normal mode:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **GO ONLINE** button.

All of the UPSs transfer to Double Conversion mode. If the power module is not available, the system remains on bypass and an alarm sounds.

The **NORMAL** status indicator is illuminated.

#### 6.4.7 Transfer from ESS Mode to Double Conversion Mode

To transfer the load to Standard Normal mode:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **EAA CONTROLS** tab on the secondary Control menu navigation bar. The **EAA CONTROLS** screen is displayed.
3. Tap the **DISABLE ESS** button.

All of the UPSs transfer to Double Conversion mode.

The **NORMAL** status indicator is illuminated.

#### 6.4.8 Transfer from Double Conversion Mode to ESS Mode

To transfer the load to HE Normal mode:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **EAA CONTROLS** tab on the secondary Control menu navigation bar. The **EAA CONTROLS** screen is displayed..
3. Tap the **ENABLE ESS** button.

All of the UPSs transfer to ESS mode if no abnormal power conditions are detected. If abnormal power conditions are detected, the UPSs will wait and transfer to ESS mode when conditions are cleared.

The **NORMAL** status indicator is illuminated.

#### 6.4.9 Transfer from Double Conversion to Bypass Mode and Shutdown all UPMs

To transfer the critical load to Bypass mode and shutdown the UPMs:

1. Transfer the critical load to bypass by performing the procedure in paragraph [6.3.6 Transfer from Double Conversion to Bypass Mode](#).
2. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
3. Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
4. On the UPM Select screen, select UPM 1. The UPM Control Screen is displayed.
5. Tap the **SHUTDOWN MODULE** button.  
The UPM status indicates SHUTDOWN. The power module is turned off.  
Logic power remains on.
6. Repeat **Step 2** through **Step 5** selecting UPM 2 to shutdown UPM 2.  
The UPM status indicates SHUTDOWN. The power module is turned off.  
Logic power remains on.
7. Repeat **Step 2** through **Step 5** selecting UPM 3 to shutdown UPM 3.  
The UPM status indicates SHUTDOWN. The power module is turned off.

Logic power remains on.

- Repeat **Step 2** through **Step 7** for each UPS in the parallel system.

#### 6.4.10 Single UPM Shutdown

To shutdown a single UPM:

- Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
- Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
- On the UPM Select screen, select the UPM to shutdown. The UPM Control Screen is displayed.
- Tap the **SHUTDOWN MODULE** button.

The UPM status indicates SHUTDOWN. The power module is turned off. The remaining UPMs continue to supply the critical load.

Logic power remains on.

#### 6.4.11 Single UPM Restart

To restart a single UPM from a shutdown state:

- Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
- Tap the **MODULES CONTROLS** tab on the secondary Control menu navigation bar. The UPM Select screen is displayed.
- On the UPM Select screen, select the UPM to start. The UPM Control Screen is displayed.
- Tap the **START MODULE** button.

The UPM rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to the Double Conversion mode and supply the critical load.

#### 6.4.12 Single UPS Shutdown

To Shutdown a single UPS:



#### NOTE

To shut down a single UPS, MOB's with dual auxiliary contacts must be installed and connected according to the procedure in **Chapter 4 UPS System Installation, Installing Interface Connections** section.

---

To shut down a single UPS:

- Open the MOB for the UPS being shut down.  
UPS will load off. Logic power remains on.
- Open the UPS input feeder circuit breaker.
- If dual feed, open the UPS bypass feeder circuit breaker.
- Open all battery breakers, internal and external IBCs if installed.

The UPS is now completely shut down.

#### 6.4.13 Single UPS Restart

To restart a single UPS from a shutdown state:

- Close the MOB for the UPS being restarted.
- Close the UPS input feeder circuit breaker for the UPS being restarted.

3. If dual feed, close the UPS bypass feeder circuit breaker for the UPS being restarted.
4. If IBCs are installed, close the battery breakers for the UPS being restarted.
5. On the UPS being restarted, observe the UPS control panel display becoming active, indicating logic power.
6. Verify no alarms are active.
7. On the UPS being restarted, tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
8. Tap the **GO ONLINE** button.
9. If requested, enter the Level 1 password. Default password is **1111**.

The rectifier and inverter turn on. The inverter continues to ramp up to full voltage.

Once the inverter reaches full voltage, all UPS inverter switchgear close and the static switches turn off. Power is now supplied to the critical load in dual conversion mode from all UPSs. It takes approximately one minute for the UPSs to achieve the dual conversion mode.

The Normal status indicator is illuminated.



**NOTE**

If the UPS is starting on a bus with other online paralleled UPSs, the UPS will not go to bypass during startup. The UPS will start, sync to the other UPSs online, and go online.

---

#### 6.4.14 Parallel System and Critical Load Shutdown

To perform maintenance or service on the critical load, shutdown power to the load:

1. Turn off all equipment that is being powered by the UPS parallel system.
2. Transfer the UPSs to bypass by performing the procedure in paragraph [6.4.5 Transfer from Double Conversion to Bypass Mode](#).
3. Perform the Load Off procedure in paragraph [6.4.17 Using the LOAD OFF Command](#).  
The inverter and bypass switchgear open, and the power module is turned off on all UPSs.
4. Perform the battery charger off procedure in paragraph [6.4.15 Charger Control](#).  
The rectifier and battery switchgear open.



**WARNING**

Power is present inside the UPS cabinet until the upstream input feeder circuit breakers and battery breakers are opened. Wait at least 5 minutes before accessing internal components.

---

5. Open the all of the UPSs input feeder circuit breaker.
6. If dual feed, open all of the UPSs bypass feeder circuit breaker.
7. If IBCs are installed, open all battery breakers.

#### 6.4.15 Charger Control

To turn the battery charger on:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **UPS CONTROLS** tab on the secondary navigation bar. The UPS Control screen is displayed.
3. Tap the **TURN ON CHARGER** button.

To turn the battery charger off:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The Control screen is displayed.
2. Tap the **UPS CONTROLS** tab on the secondary navigation bar. The UPS Control screen is displayed.
3. Tap the **TURN OFF CHARGER** button.

#### 6.4.16 Battery Test

---

**NOTE 1** This UPS has a user initiated battery test intended to determine if the batteries are able to support the load.



**NOTE 2** The battery test is only able to be initiated when the battery is fully charged. This normally occurs within 72 hours of the start of a charging cycle. The command will not be shown if the test is not able to be run.

---

To start the battery test:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
2. Tap the **UPS CONTROLS** tab on the secondary navigation bar. The UPS Control screen is displayed.
3. Tap the **RUN BATTERY TEST** button.

#### 6.4.17 Using the LOAD OFF Command

A UPS shutdown is initiated by the **LOAD OFF** command on the UPS Control screen. The UPS **LOAD OFF** controls the UPSs output by powering down all of the UPSs and de-energizing the critical load.

The UPSs (including Bypass) remains off until restarted.

To use the **LOAD OFF** command:

1. Tap the **CONTROLS** tab on the main menu navigation bar. The System Control screen is displayed.
- 

### CAUTION

---

All power to the critical load is lost when **LOAD OFF** is selected in the following step. You should use this feature only when you want to de-energize the critical load.

---

2. Tap the **LOAD OFF** button.

An action confirmation screen is displayed. Follow the on screen prompts to shutdown the UPS or to cancel the shutdown. Selecting **YES** will immediately shutdown the UPS and de-energize the critical load. Selecting **NO** will abort the shutdown.

---

### CAUTION

---

Do not attempt to restart the system after Load Off until the cause of the shutdown has been identified and cleared.

---

3. To restart the UPS after using the **LOAD OFF** follow the procedure in paragraph [6.4.1 Starting the Parallel System in Double Conversion Mode](#) or [6.4.2 Starting the Parallel System in Bypass Mode](#).
- 

### WARNING

---

Power is present inside the UPS cabinet until the upstream input feeder circuit breakers and battery breakers are opened. Wait at least 5 minutes before accessing internal components.

---



### 6.4.18 Using the Remote Emergency Power-off Switch

---

#### WARNING

---

Emergency Power Off (EPO) and Remote Emergency Power Off (REPO) functionality is disabled for UPS systems configured for UL 924 auxiliary lighting. To remove power from the system a LOAD OFF command (see paragraph [6.4.17 Using the LOAD OFF Command](#)) must be given using the front panel controls and all breakers opened.

---

A UPS emergency power-off is initiated by the REPO pushbutton switch. In an emergency, you can use this switch to control the UPS output. The REPO switch de-energizes the critical load and powers down the UPSs immediately, without asking for verification.

The UPSs, including Bypass, remains off until restarted.


---

#### CAUTION

---

All power to the critical load is lost when the REPO switch is activated in the following step. You should use this feature only when you want to de-energize the critical load.

---

 **NOTE** The following instructions are for the Eaton-supplied REPO switch. If a customer-supplied REPO switch is used, it may not activate in the same manner; refer to the operating instructions provided with the switch.

---

To use the REPO switch:

1. Firmly push the red pushbutton until it locks into place. The switch latches into the activated state (see [Figure 78](#)).

The rectifier, inverter, battery, and bypass switchgear open, and the power module is turned off immediately on all UPSs, without asking for verification.

---

#### CAUTION

---

Do not attempt to restart the system after the REPO until the cause of the shutdown has been identified and cleared.

---

2. To deactivate the REPO switch in preparation for restarting the UPS, insert the supplied key and rotate clockwise until the red pushbutton releases (see [Figure 78](#)). To remove the key, rotate the key back to the vertical position.
  3. Restart the UPS by following the procedure in paragraph [6.4.1 Starting the Parallel System in Double Conversion Mode](#) or [6.4.2 Starting the Parallel System in Bypass Mode](#).
- 

#### WARNING

---

Power is present inside the UPS cabinet until the upstream input feeder circuit breakers and battery breakers are opened. Wait at least 5 minutes before accessing internal components.

---



## Chapter 7 Communication

This chapter describes the communication features of the Eaton 93PM-L UPS.

### 7.1 Minislot Cards

The Eaton 93PM-L UPS has four standard, factory-installed Minislot communication bays. The UPS is compatible with the following Minislot cards (see [Figure 79](#)):


- The Power Xpert Gateway Minislot (PXGMS) card provides Web-enabled, real-time monitoring of Eaton 93PM uninterruptible power systems (UPSs) through standard Web pages, Power Xpert software, Intelligent Power Manager (IPM), Intelligent Power Protector (IPP), or third-party software. As an integral part of the Eaton Power Xpert Architecture®, the PXGMS card provides a central point to connect UPSs to the Ethernet network.

Network managers can view critical downstream device information, such as status, power, energy, and power quality data with an easy-to-use interface.

- Industrial Relay Card-Minislot (IRC-MS) – can be used to indicate the operating status of the UPS system using the customer's monitoring equipment. The Industrial Relay Card uses five isolated normally-open or normally-closed dry relay contacts to indicate the UPS status. Normal, Bypass, Battery, and Alarm modes can be monitored. See [Table 34](#) for default triggers. The contact ratings and wire range are listed in the IRC-MS installation guide. One input can be activated by a switch or dry contact. The voltage source is provided by the card, no external voltage source is needed.

For installation and setup of a Minislot card, contact an Eaton service representative (see paragraph [1.9 Getting Help](#)). Refer to the manual supplied with the Minislot card for user instructions.

**Figure 79. Optional Minislot Cards**



**Table 34. IRC-MS Default Triggers**

Relay	Trigger
K1	UPS supporting the load
K2	UPS on Battery
K3	Summary alarm
K4	UPS on bypass
K5	UPS battery low

### 7.2 Building Alarm Monitoring

This standard feature lets you connect the UPS to your building alarms, such as smoke detectors or overtemperature alarms. The building alarm customer interface terminals for external are located inside the UPS. Use twisted-pair wires for each alarm input and common.

The building alarms can be programmed to display the alarm functional name.

### 7.3 General Purpose Relay Contact

One general purpose relay contact is provided as a standard feature on the UPS. The relay contact customer interface terminals are located inside the UPS. Use twisted-pair wires for the normally-closed or normally-open and common connections.

Normally-closed or normally-open contacts can be used. If the state of the contact changes from the state specified as normal, a signal is issued. This contact can be connected to equipment at the facility (such as a light or an alarm bell) to notify the operator when an alarm is active on the UPS. This feature is useful if the UPS is located in a remote area where the UPS horn may not be heard immediately.

---

#### CAUTION

---

Contacts should not be operated in excess of 30 Vac or 28 Vdc @ 5A.

---



#### NOTE

If contact ratings are required that can be operated above the rated voltage and current available with the UPS general purpose relay contacts, an IRC-MS card should be used.

---

### 7.4 PredictPulse Remote Monitoring and Management Service

The Eaton 93PM-L UPS supports Eaton's PredictPulse remote monitoring and management service. PredictPulse is a subscription monitoring and management service that collects and analyzes data from connected power infrastructure devices, providing us with the insight needed to make recommendations and take action on your behalf. It's also powered by CA Technologies, bringing together the best in hardware and software. PredictPulse Service is included at no charge during the first year of Eaton 93PM-L UPS operation (warranty period) along with the required connectivity parts. Beyond that, it may be purchased with Eaton Support Agreements or as a standalone subscription after the initial warranty expires. PredictPulse may also be subscribed to for free as part of a 90-day trial period. PredictPulse availability and first year bundled offers may vary by market. For more information, visit [www.eaton.com/predictpulse](http://www.eaton.com/predictpulse).

#### 7.4.1 PredictPulse Service Features

PredictPulse provides proactive monitoring, an online dashboard, mobile app with alarm status information and a monthly report detailing the ongoing health of your Eaton 93PM-L UPS. Features include:

- Proactive monitoring that automatically analyzes the status of the Eaton 93PM-L UPS 96 times every day (every 15 minutes). All health data gathered from the unit, current and historical, is analyzed at the Customer Reliability Center (CRC). Algorithms and sophisticated analytics software is constantly scanning your UPS's data for potential failures. Anomalies are escalated to a Software and Monitoring analyst or Technical Support specialist. Critical events are remotely diagnosed to expedite repairs, including smart dispatch of field technicians with probable cause and likely parts (avoiding return visits due to lack of required parts). Through this service, the CRC can take pre-emptive, corrective action to ensure the highest level of availability of your Eaton 93PM-L UPS.
- Easy self-installation in minutes from a wizard installer or directly from the PXGMS card. PredictPulse uses standard Eaton connectivity hardware, requiring no special software (devices only need to be connected to a network).
- Ability to give an unlimited number of coworkers access to the real-time data and reports found in PredictPulse's online dashboard and mobile app. This allows you to collaborate and Eaton to notify the most appropriate person responsible for a specific site or device.
- Real-time access to key performance information, alarms and trended health data about your Eaton 93PM-L UPS via the PredictPulse online dashboard. Depending on the model, the dashboard aggregates all subscribed devices and provides detailed information about voltages, loads, energy savings, service levels, external factors such as temperature and humidity, attached batteries, and system availability. All of these factors contribute to the Relative Performance Index (RPI) score that allows you to compare your unit's health relative to Eaton's optimum UPS operating levels.

- Real-time alarm events for all subscribed devices via the PredictPulse mobile app (Apple and Android). You can track all alarms by device. As critical alarms occur, Eaton will acknowledge them so you know when Eaton has diagnosed the alarm (and pending notification of resolution).
- A monthly summary report that delivers key performance information, alarms and trended health data about your Eaton 93PM-L UPS, based on the prior month's data.
- A foundation based on CA Technologies' leading Data Center Infrastructure Management (DCIM) software application. This enables powerful reporting, analytics, security, and compatibility with hundreds of power infrastructure devices.

### 7.4.2 Installing PredictPulse

A quick start guide and self-installation wizard tool are available at [www.eaton.com/predictpulse](http://www.eaton.com/predictpulse). The latest updates, installation tips and information on connecting PredictPulse are also available at that link. For installation support or questions about PredictPulse, contact [predictpulsesupport@eaton.com](mailto:predictpulsesupport@eaton.com).

PredictPulse relies on a PXGMS card installed with the UPS to send one-way outbound SMTP e-mails to Eaton, as well as an Environmental Monitoring Probe (EMP) for battery temperature/humidity monitoring. PredictPulse is secure as Eaton never communicates through your firewall—it only listens for health data and alarm data—and uses industry-standard security protocols. By using a common e-mail transport mechanism, you do not have to open your network to proprietary or potentially unsecure protocols and transports. The PXGMS Connectivity Card gathers information directly from the UPS and any external sensors that are attached, and transmits that data every 15 minutes (or 96 times per day), enabling real-time monitoring and advanced virtual preventive maintenance.



## Chapter 8 UPS Maintenance

The components inside the UPS cabinet are secured to a sturdy metal frame. All repairable parts and assemblies are located for easy removal, with very little disassembly. This design allows authorized service personnel to perform routine maintenance and servicing quickly.

You must schedule periodic performance checks of your UPS system to keep it running properly. Regular routine checks of operation and system parameters enable your system to function efficiently for many trouble-free years.

### 8.1 Important Safety Instructions

Remember that your UPS system is designed to supply power **EVEN WHEN DISCONNECTED FROM THE UTILITY POWER**. The UPS module interiors are unsafe until the DC power source is disconnected and the electrolytic capacitors are discharged. After disconnecting the utility power and the DC power, authorized service personnel should wait at least five minutes for capacitor bleedoff before attempting internal access to the UPS module.



- Servicing and maintenance should be performed by qualified service personnel only.
- **LETHAL VOLTAGE PRESENT.** This unit should not be operated with the cabinet doors open or protective panels removed. Do not make any assumptions about the electrical state of any cabinet in the UPS system.

---

Each battery string is an energy source in itself. **DO NOT ATTEMPT TO ACCESS ANY INTERNAL AREA OF THE BATTERY STRING YOURSELF. VOLTAGES ARE ALWAYS PRESENT IN THE BATTERY STRING.** If you suspect that a battery string needs service, contact an Eaton service representative.

Observe these precautions when working on or around batteries:

- Remove watches, rings, or other metal objects.
- Use tools with insulated handles.
- Wear rubber gloves and boots.
- Do not lay tools or metal parts on top of batteries.
- Disconnect the charging source prior to connecting or disconnecting terminals.
- Determine if the battery is inadvertently grounded. If it is, remove the source of the ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock is reduced if such grounds are removed during installation and maintenance.
- When replacing batteries, use the same number of sealed, lead-acid batteries.
- Proper disposal of batteries is required. Refer to your local codes for disposal requirements.
- Do not dispose of batteries in a fire. Batteries may explode when exposed to flame.
- Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

### 8.2 Performing Preventive Maintenance

The UPS system requires very little preventive maintenance. However, the system should be inspected periodically to verify that the units are operating normally and that the batteries are in good condition.

### 8.2.1 DAILY Maintenance

Perform the following steps daily:

1. Check the area surrounding the UPS system. Ensure the area is not cluttered, allowing free access to the unit.
2. Ensure the air intakes (vents on the front door of the UPS cabinet and the exhaust openings (on the rear of the UPS cabinet) are not blocked.
3. Ensure the operating environment is within the parameters specified in **Chapter 9 Product Specifications**.
4. Ensure the UPS is in Normal mode (Normal status indicator is illuminated). If an alarm lamp is illuminated or the Normal status indicator is not illuminated, contact an Eaton service representative.

### 8.2.2 MONTHLY Maintenance

Perform the following steps monthly:

1. Monitor system parameters as described in paragraph [6.2 Using the Control Panel](#).
2. Check the UPS air filter (located behind the front door) and wash or replace as necessary. See [Figure 80](#) for filter location. Contact an Eaton service representative for replacement filters.

---

 **CAUTION**

---

Verify the spare washed filter is thoroughly dry before installing.

---

To remove the filters:

- a. Unfasten the front door by lifting the latch from the bottom and turning to the right (counterclockwise) and swing the door open (see [Figure 80](#)).
- b. Remove the foam filters from the frame on the front door.
- c. Install the customer's spare foam filters, either washed or new foam filters, into the frame on the front door.

---

 **IMPORTANT**


---

The foam filters are to be replaced with new or washed filter immediately. The ups is not meant to be run without filters installed.

---

- d. Close the front door and secure the latch.
3. Record maintenance results and any corrective actions in a suitable log.



**Figure 80. Air Filter Location****8.2.3 PERIODIC Maintenance**

Periodic inspections of the UPS should be made to determine if components, wiring, and connections exhibit evidence of overheating. Particular attention should be given to the compression lug connections. Maintenance procedures should specify that the compression lug connections be retorqued to values listed in this manual.

**8.2.4 ANNUAL Maintenance**

Annual preventive maintenance should be performed only by authorized service personnel familiar with maintenance and servicing of the UPS system. Contact an Eaton service representative for more information about service offerings.

**8.2.5 BATTERY Maintenance**

Contact an Eaton service representative for battery maintenance. Battery replacement and maintenance should be performed only by authorized service personnel.

**8.3 Installing Batteries****NOTE**

There is no manual DC disconnect device within the UPS.

Install batteries in accordance with the battery and battery system manufacturer's instructions.

## 8.4 Recycling the Used Battery or UPS

Contact your local recycling or hazardous waste center for information on proper disposal of the used battery or UPS.

---



---

 **WARNING**

---

- Do not dispose of the battery or batteries in a fire. Batteries may explode. Proper disposal of batteries is required. Refer to your local codes for disposal requirements.
- Do not open or mutilate the battery or batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.
- A battery can cause electrical shock, burn from high short-circuit current, or fire. Observe proper precautions.

---



---

 **ATTENTION!**

---

- Une batterie peut présenter un risque de choc électrique, de brûlure, ou d'incendie. Suivre les précautions qui s'imposent.
- Pour le remplacement, utiliser le même nombre et modèle des batteries.
- L'élimination des batteries est réglementée. Consulter les codes locaux à cet effet.

---



---

 **CAUTION**

---

Do not discard the UPS or the UPS batteries in the trash. This product contains sealed, lead-acid batteries and must be disposed of properly. For more information, contact your local recycling/reuse or hazardous waste center.

---



---

 **CAUTION**

---

Do not discard waste electrical or electronic equipment (WEEE) in the trash. For proper disposal, contact your local recycling/reuse or hazardous waste center.

## 8.5 Maintenance Training

A basic training course, available from Eaton, gives you a competent working knowledge of the UPS system operation and teaches you how to perform first level corrective maintenance. For more information about training and other services, contact the Customer Reliability Center (see paragraph [1.9 Getting Help](#)).

## Chapter 9 Product Specifications

### 9.1 Models

The UPS is housed in a free-standing cabinet with safety shields behind the door. The UPS is available in 50 or 60 Hz with various output power ratings.

Model	Power Rating
Eaton 93PM-L 60-1 Eaton 93PM-L 60-2 (N+1)	10 kW
Eaton 93PM-L 60-1 Eaton 93PM-L 60-2 (N+1)	20 kW
Eaton 93PM-L 60-2 Eaton 93PM-L 60-3 (N+1)	30 kW
Eaton 93PM-L 60-2 Eaton 93PM-L 60-3 (N+1)	40 kW
Eaton 93PM-L 60-3	50 kW
Eaton 93PM-L 60-3	60 kW

### 9.2 Specifications

The following sections detail the input, output, environmental, and battery specifications for the UPS.

#### 9.2.1 UPS Input

<b>Operating Input Voltage</b>	Rectifier: 208 or 220 Vac Wye, 3W + ground. Neutral not used. Bypass: 208 or 220 Vac Wye, 4W + ground.
<b>Operating Input Frequency Range</b>	50/60 Hz
<b>Operating Input Current</b>	See <a href="#">Table 9</a> through . <b>Reduced for Generator</b> Adjustable
<b>Input Current Harmonic Content</b>	≤ 3.5% THD at full load
<b>Power Factor</b>	Minimum 0.99
<b>Line Surges</b>	6 kV OC, 3 kA SC per ANSI 62.41 and IEC 801 4
<b>Battery Voltage</b>	240 cell – 480Vdc
<b>Battery Charging Capacity</b>	17 A maximum per 20 kW module at full load at nominal input voltage

#### 9.2.2 UPS Output

<b>UPS Output Capacity</b>	100% rated current
<b>Output Voltage Regulation</b>	± 1% (10% to 100% load)

<b>Output Voltage</b>	208 or 220 Vac Wye, 3W or 4W + ground
<b>Output Voltage Harmonic Content</b>	< 1.6% maximum THD (linear load) 5% maximum THD (nonlinear load)
<b>Output Current</b>	See <a href="#">Table 9</a> through .
<b>Output Voltage Balance</b>	< 2% for 100% maximum load imbalance (linear load)
<b>Output Voltage Phase Displacement</b>	< 2.5° for 100% maximum load imbalance (linear load)
<b>Frequency Regulation</b>	0.1 Hz free running
<b>Synchronous to Bypass</b>	± 4 Hz (default setting)
<b>Frequency Slew Rate</b>	1 Hz per second (default setting)
<b>Load Compatibility</b>	0.8 pF Leading 0.8 pF Lagging
<b>Overload Capability</b>	<110% for 10 minutes <125% for 60 seconds <150% for 10 seconds >150% for 300 milliseconds

### 9.2.3 UPS Environmental

<b>Operating Temperature</b>	5 to 40° C (41 to 104° F) without derating. The recommended operating temperature is 25° C (77 °F).
<b>Operating Altitude</b>	Maximum 1500m (5000 ft) at 40° C without derating
<b>Storage Temperature</b>	-25 to +55° C, excluding batteries (prolonged storage above 40° C causes rapid battery self-discharge)
<b>Relative Humidity (operating and storage)</b>	5 to 95%, noncondensing
<b>Acoustical Noise</b>	60 kW at 100% load – 65 dBA at a 1m distance, per ISO 7779
<b>Agency Markings</b>	Safety: UL1778 5th Ed./CSA22.2 No. 107.3–14 3rd Ed.
<b>EMI Emissions</b>	Meets IEC 62040-2 C2, CISPR 22, VCCI and FCC Part 15 Subpart B Class A limits.
<b>Immunity / Electrostatic Discharge (ESD)</b>	Meets IEC 61000-4-2 Level 3 specifications and CISPR 24. Withstands up to 4 kV contact pulse without damage and with no disturbance or adverse effect to the critical load.

## Chapter 10 Warranty

To view the UPS warranty please click on the link or copy the address to download from the Eaton website:  
[UPS Product Warranty](#)

<https://www.eaton.com/content/dam/eaton/products/backup-power-ups-surge-it-power-distribution/backup-power-ups/portfolio/eaton-three-phase-ups-warranty.pdf>

### EQUIPMENT REGISTRATION

Please visit [www.eaton.com/pg/register](http://www.eaton.com/pg/register) to register your new Eaton UPS / Eaton UPS Accessory.

**Model Number:**

---

**Serial Number:**

---



P-164000711 05